Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BRAS220E AS2.2

Braun BRAS220E AS2.2 IONTEC Air Styler User Manual

Model: BRAS220E AS2.2 | Brand: Braun

1. Important Safety Information

Please read all instructions carefully before using this appliance. Keep this manual for future reference.

- **Water Warning:** Do not use this appliance near water, in bathtubs, showers, basins, or other vessels containing water.
- **Electrical Safety:** Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting. Always unplug the appliance after use and before cleaning.
- **Children:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- **Heat:** The appliance becomes hot during use. Avoid direct contact with hot surfaces. Allow to cool before handling or storing.
- **Cord:** Do not wrap the power cord around the appliance. Do not use if the cord is damaged.
- **Attachments:** Only use attachments supplied by the manufacturer.

2. Product Overview

The Braun BRAS220E AS2.2 IONTEC Air Styler is designed for efficient hair drying and styling. It features IONTEC technology to reduce frizz and enhance shine, along with multiple heat/speed settings for versatile styling.

Components:

- Main Styler Unit
- Thermal Brush (40 mm)
- Concentrator Nozzle
- Removable Filter
- Cleaning Brush



Figure 2.1: The Braun BRAS220E AS2.2 IONTEC Air Styler, showcasing its sleek design and the thermal brush attachment.



Figure 2.2: A detailed view of the 40mm thermal brush, designed for creating volume and waves.



Figure 2.3: The control panel of the air styler, featuring power settings (0, I, II) and a cool shot button (snowflake icon).

3. Setup

Before first use, ensure all packaging materials are removed.

Attaching Accessories:

1. Align the desired attachment (thermal brush or concentrator nozzle) with the main styler unit.
2. Push the attachment onto the unit until it clicks securely into place. The attachments are lockable for secure use.
3. To remove, press the release button (if present, typically a slider or button near the attachment point) and pull the attachment off.



Figure 3.1: Illustrates the method for attaching the concentrator nozzle to the main styler body.



Figure 3.2: The concentrator nozzle, used for precise drying and styling.

4. Operating Instructions

Power and Temperature Settings:

1. Plug the appliance into a suitable power outlet.
2. Use the slider switch on the handle to select your desired setting:
    - **0:** Off
    - **I:** Low heat/speed setting
    - **II:** High heat/speed setting
3. The IONTEC feature is automatically active when the appliance is on, releasing millions of active ions to reduce static and enhance shine.

Using the Cool Shot Function:

Press and hold the snowflake button (cool shot button) to deliver a burst of cool air. This helps to set your hairstyle and provide a long-lasting hold.

Styling Tips:

- For drying, use the concentrator nozzle to direct airflow.
- For volume and waves, use the thermal brush. Work in sections, wrapping hair around the brush and directing airflow.
- Always ensure hair is towel-dried before styling to reduce drying time and potential heat damage.

5. Maintenance

Regular cleaning ensures optimal performance and extends the life of your appliance.

Cleaning the Air Filter:

1. Ensure the appliance is switched off and unplugged from the power outlet.
2. Locate the removable filter cover at the rear of the styler.
3. Gently twist or pull to remove the filter cover.
4. Use the provided cleaning brush or a soft, dry cloth to remove any accumulated dust, lint, or hair from the filter mesh.
5. Replace the filter cover, ensuring it clicks securely back into place.



Figure 5.1: The rear of the air styler, highlighting the removable air intake filter for cleaning.

Cleaning Attachments and Body:

- Wipe the styler body and attachments with a damp cloth. Do not use abrasive cleaners or solvents.
- Ensure all parts are completely dry before storing or reusing.

Storage:

Store the appliance in a cool, dry place, away from direct sunlight and moisture. Do not wrap the cord tightly around the appliance.

6. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly; Power outlet malfunction; Appliance fault.	Check power connection; Try a different outlet; Contact customer support if problem persists.
Low airflow or overheating.	Air intake filter is blocked.	Clean the air intake filter as described in Section 5.
Attachments do not stay on.	Attachment not fully engaged; Locking mechanism fault.	Ensure attachment is pushed on until it clicks; Check for damage to the locking mechanism.

7. Specifications

Feature	Detail
Model Number	BRAS220E AS2.2
Power	700W
Technology	IONTEC
Heat/Speed Settings	3 (0, I, II, plus Cool Shot)
Attachments	Concentrator Nozzle, 40mm Thermal Brush
Cord Length	195cm swivel cord
Dimensions (Product)	3.1 x 5.6 x 5.9 cm
Weight	929 grams
Manufacturer	Con Air LLC

8. Warranty and Support

This product is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.

For technical support, service, or warranty claims, please contact your local Braun dealer or the manufacturer directly.

Manufacturer Contact Information:
Con Air LLC

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FZCGZRFF

More documents and user manuals: **https://manuals.plus/**