Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO TKFEK

TRESKO TKFEK 1800W Smart Electric Fireplace Heater

User Manual

1. Introduction

Thank you for purchasing the TRESKO TKFEK 1800W Smart Electric Fireplace Heater. This manual provides essential information for the safe operation, installation, and maintenance of your new electric fireplace. Please read this manual thoroughly before use and retain it for future reference.

2. Important Safety Instructions

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 1 meter (3 feet) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.
- Do not use outdoors.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable

liquids are used or stored.

- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- This product is equipped with a safety device that automatically turns off the heater if it overheats. If the heater turns off, immediately unplug it and inspect for any objects on or adjacent to the heater that may have caused the high temperatures.

3. Package Contents

Please check that all items are present and in good condition:

- TRESKO TKFEK Electric Fireplace Heater
- Remote Control
- User Manual

4. Product Overview

Familiarize yourself with the components of your TRESKO Electric Fireplace Heater.



Figure 4.1: TRESKO Electric Fireplace Heater, showcasing the main unit, remote control, and smartphone app interface for smart home integration.



Figure 4.2: Rear view of the TRESKO Electric Fireplace Heater, highlighting the main power switch, the robust handle, the 1800W motor, and the efficient heat shaft for optimal performance.

5. Setup and Placement

Follow these steps to set up your electric fireplace heater:

1. **Unpacking:** Carefully remove the heater from its packaging. Retain the packaging for future storage or transport.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 1 meter (3 feet) of clear space around the front, sides, and rear of the heater to prevent fire hazards and ensure proper ventilation. Do not place it directly under a power outlet.
3. **Power Connection:** Ensure the main power switch on the back of the unit is in the 'OFF' position. Plug the power cord into a grounded 220-240V AC outlet.



Figure 5.1: Dimensions of the TRESKO Electric Fireplace Heater, showing a height of 74.5cm, width of 44cm, and depth of 34.5cm, alongside the included remote control.

6. Operating Instructions

Your TRESKO Electric Fireplace Heater offers multiple control options and customizable settings.

6.1 Control Methods

The heater can be controlled via the included remote control, the integrated LCD display, or the Tuya Smart App.

6.1.1 Remote Control

The remote control allows convenient adjustment of all functions from a distance.



Figure 6.1: Detailed view of the remote control, illustrating buttons for power, flame effect, brightness, heating levels, timer, and temperature adjustment.

- **Power Button (U):** Turns the heater ON/OFF.
- **Flame Effect Button (fire icon):** Cycles through different flame and ember color combinations.
- **Brightness Button (sun icon):** Adjusts the brightness of the flame effect (5 levels).
- **Heating Level Button (heater icon):** Selects between 900W (P1) and 1800W (P2) heating modes.
- **Timer Button (clock icon):** Sets the automatic shut-off timer (1-8 hours).
- **Temperature Buttons (+ / -):** Adjusts the desired thermostat temperature (15-35 °C).
- **°C/°F Button:** Toggles temperature display between Celsius and Fahrenheit.

6.1.2 LCD Display

The integrated LCD display on the unit provides visual feedback and allows direct control of all functions.

6.1.3 Tuya Smart App (WiFi Control)

For advanced control and smart home integration, download the Tuya Smart App on your smartphone. The app allows

you to control the heater remotely, set schedules, and integrate with voice assistants like Alexa and Google Home.



Figure 6.2: The electric fireplace heater demonstrating its two heat levels (900W and 1800W) and its compatibility with the Tuya Smart App for remote control.

6.2 Heating Functions

The heater offers two distinct heating levels and a thermostat for precise temperature control.

- **Heat Level 1 (P1):** 900W for gentle heating or smaller spaces.
- **Heat Level 2 (P2):** 1800W for rapid heating or larger spaces (up to 30 m²).
- **Thermostat:** Set your desired room temperature between 15°C and 35°C. The heater will automatically turn on or off to maintain the set temperature.

6.3 Flame and Ember Effects

Enjoy a realistic fireplace ambiance with customizable flame and ember effects. These can be used independently of the heating function.



Figure 6.3: The electric fireplace heater showcasing its diverse range of flame and ember color options, allowing for personalized ambiance.

- **Flame Colors:** Choose from 9 different flame colors to match your mood or decor.
- **Ember Colors:** Select from 9 different ember bed colors for enhanced realism.
- **Brightness Levels:** Adjust the intensity of the flame effect with 5 brightness settings.

6.4 Timer Function

The integrated timer allows you to set the heater to automatically turn off after a specified period, ranging from 1 to 8 hours.

7. Maintenance

Regular maintenance ensures the longevity and efficient operation of your electric fireplace heater.

7.1 Cleaning

1. Always unplug the heater from the power outlet and allow it to cool completely before cleaning.
2. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners, sprays, or harsh chemicals.
3. Ensure no water enters the interior of the heater.
4. Periodically clean the air intake and exhaust vents with a vacuum cleaner to remove dust and debris.

7.2 Storage

When not in use for extended periods, store the heater in a cool, dry place, preferably in its original packaging, away from direct sunlight and moisture.

8. Troubleshooting

If you encounter any issues with your heater, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Heater does not turn on.	No power, main switch off, power cord not plugged in, safety cut-off activated.	Check power outlet, ensure main switch is ON, plug in cord securely, unplug and allow to cool for 10 minutes if safety cut-off activated.
No heat output.	Heating function not activated, thermostat set too low, safety cut-off activated.	Activate heating function via remote/app/LCD, increase thermostat setting, unplug and allow to cool.
Flame effect not working.	Flame effect not activated, LED malfunction.	Press the flame effect button on the remote or LCD. If issue persists, contact customer support.
Remote control not working.	Dead batteries, obstruction, out of range.	Replace batteries, remove obstructions, ensure you are within range of the heater.

9. Technical Specifications

Feature	Specification
Brand	TRESKO
Model Number	TKFEK
Power Output	900W / 1800W
Voltage	220-240V
Material	Metal
Dimensions (H x W x D)	74.5 cm x 44 cm x 34.5 cm

Feature	Specification
Weight	13.8 kg
Special Features	LED Flame Effect, Multicolor Flame, Overheat Protection, Timer, Smart Home WiFi App Control, Remote Control
Thermostat Range	15-35 °C
Timer Range	1-8 hours

10. Warranty and Customer Support

TRESKO products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official TRESKO website. If you have any questions, require technical assistance, or need to report a problem, please contact our customer support team. Contact details can typically be found on our website or on your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FZCRMSLF

More documents and user manuals: **https://manuals.plus/**