Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DUMOS ADMS-ET40HS

DUMOS 40 Inch Electric Standing Desk User Manual

Model: ADMS-ET40HS

1. Product Overview

The DUMOS 40 Inch Electric Standing Desk is designed to provide a versatile and ergonomic workspace, allowing seamless transitions between sitting and standing positions. This desk features a quiet electric height adjustment system, programmable memory presets, and a spacious desktop for enhanced productivity.



Image: The DUMOS 40 Inch Electric Standing Desk, black finish, set up with a monitor, laptop, and accessories in a modern office environment.

2. Safety Information

- Ensure all components are securely fastened before use.
- Keep children and pets away from the desk during height adjustments.
- Do not overload the desk; the maximum weight capacity is 176 lbs (80 kg).
- Avoid placing liquids directly on the control panel or near electrical components.
- If any unusual noise or movement occurs, discontinue use and consult the troubleshooting section or contact customer support.

3. Setup and Assembly

The DUMOS Electric Standing Desk is designed for quick and tool-free assembly. Follow these steps for a smooth setup:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all parts are present according to the included parts list.
2. **Assemble Frame:** Attach the desk legs to the crossbar, ensuring all screws are tightened.
3. **Attach Desktop:** Secure the desktop panels to the assembled frame. The desk features a dual-panel design.
4. **Connect Control Panel:** Plug the control panel and motor cables into the main control box.
5. **Install Accessories:** Attach the headphone hook and any other included accessories to your preferred locations on the desk.
6. **Power On:** Plug the power cord into a wall outlet.



Image: Various components of the DUMOS Electric Standing Desk, including the desktop, legs, and control panel, laid out for assembly.



Image: The sturdy steel frame of the DUMOS Electric Standing Desk assembled, ready for the desktop to be attached.

4. Operating Instructions

4.1 Height Adjustment

The desk features a quiet electric motor for smooth height adjustments. The height can be adjusted from 28.7 inches (72.9 cm) to 46.5 inches (118.1 cm).

- **Raise Desk:** Press and hold the **Up (▲)** button on the control panel until the desired height is reached.
- **Lower Desk:** Press and hold the **Down (▼)** button on the control panel until the desired height is reached.



Image: Close-up of the multi-function control panel with an LED display showing the current height and buttons for up, down, and memory presets.

4.2 Memory Presets

The desk allows you to save up to three preferred height settings for quick adjustments.

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the **S** button. The LED display will flash.
3. Immediately press one of the number buttons (**1**, **2**, or **3**) to save the current height to that preset.
4. To recall a saved height, simply press the corresponding number button (**1**, **2**, or **3**). The desk will automatically move to the saved position.

4.3 Child Lock Function

To prevent accidental adjustments, the desk includes a child lock feature.

- **Activate Child Lock:** Press and hold the **Up (▲)** and **Down (▼)** buttons simultaneously for 5 seconds. The LED display will show "LOC" and the buttons will be disabled.
- **Deactivate Child Lock:** Press and hold the **Up (▲)** and **Down (▼)** buttons simultaneously for 5 seconds

again. The "LOC" indicator will disappear, and the buttons will be re-enabled.



Image: A child reaching for the desk's control panel, which displays 'LOC', indicating the child lock feature is active.

4.4 Anti-Collision Technology

The desk is equipped with anti-collision technology to prevent damage or injury. If an obstacle is detected during height adjustment, the desk will automatically stop and reverse slightly.



Image: A diagram showing the anti-collision feature, where the desk detects an obstacle and reverses its movement to prevent impact.

5. Maintenance

To ensure the longevity and optimal performance of your DUMOS Electric Standing Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surface and frame with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Cable Management:** Ensure all cables are neatly managed and not pinched or tangled, which could affect desk operation or cause damage.

6. Troubleshooting

If you encounter any issues with your DUMOS Electric Standing Desk, please refer to the following common

problems and solutions:

- **Desk Not Moving:**
  - Check if the power cord is securely plugged into both the desk and the wall outlet.
  - Ensure the child lock is not activated (refer to Section 4.3).
  - If the display shows an error code, try unplugging the desk for 10 seconds and plugging it back in to reset.
- **Uneven Movement:**
  - Ensure the desk is placed on a level surface.
  - Check that the weight on the desk is evenly distributed and does not exceed the maximum capacity.
- **Unusual Noises:**
  - Minor motor sounds during adjustment are normal. If you hear grinding or loud noises, stop operation immediately.
  - Check for any obstructions under or around the desk legs.

If the problem persists after attempting these solutions, please contact DUMOS customer support for further assistance.

7. Specifications

Feature	Detail
Brand	DUMOS
Model Number	ADMS-ET40HS
Product Dimensions	23.6"D x 40"W x 46.5"H (60cm D x 101.6cm W x 118.1cm H)
Adjustable Height Range	28.7" to 46.5" (72.9 cm to 118.1 cm)
Desktop Material	Wood
Frame Material	Alloy Steel
Color	Black
Maximum Weight Capacity	176 lbs (80 kg)
Noise Level	Under 55 dB
Special Features	Adjustable Height, Electric, Ergonomic, Memory Presets, Anti-collision, Child Lock
Included Components	Computer Desk, Headphone Hook

8. Warranty and Support

For warranty information or to contact customer support, please visit the official DUMOS store or refer to your purchase documentation.
You can find more information about DUMOS products at their official store:DUMOS Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G3X1JMPC

More documents and user manuals: **https://manuals.plus/**