Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gourmia GTF1188SSA

Gourmia GTF1188SSA Digital Air Fryer Oven Instruction Manual

Model: GTF1188SSA

Introduction

Thank you for choosing the Gourmia Digital Air Fryer Oven. This versatile appliance combines the functions of a toaster oven and an air fryer, offering a wide range of cooking possibilities. Designed for convenience and efficiency, it features 12 preset functions and FryForce 360° Technology for healthier, crispy results.
Please read this manual thoroughly before use to ensure safe and optimal operation.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury. These include:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversize foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
- A fire may occur if the toaster oven is covered or touching flammable material, including curtains, drapes, walls, and the

like, when in operation.

- Do not place any of the following materials in the oven: paper, cardboard, plastic, and the like.
- Do not store any materials, other than manufacturer's recommended accessories, in this oven when not in use.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, and the like.
- Do not cover crumb tray or any part of the oven with metal foil. This will cause overheating of the oven.
- Extreme caution should be exercised when removing tray or disposing of hot grease.
- To disconnect, turn any control to "off", then remove plug from wall outlet.

What's in the Box

Your Gourmia Digital Air Fryer Oven comes with the following components:

- Air Fryer Convection Oven Body
- Air Fry Basket
- Oven Rack
- Baking Pan
- Crumb Tray



Image: Gourmia Digital Air Fryer Oven and its accessories. This includes the main oven unit, an air fry basket, an oven rack, a baking pan, and a crumb tray, all designed for versatile cooking.

Setup

1. **Unpack:** Carefully remove the oven and all accessories from the packaging. Remove any protective films or stickers from the appliance.
2. **Placement:** Place the oven on a stable, heat-resistant surface, ensuring adequate ventilation around all sides. Do not place it directly under cabinets or near flammable materials.
3. **Clean Accessories:** Wash the air fry basket, oven rack, baking pan, and crumb tray with warm, soapy water. Rinse thoroughly and dry completely before first use.
4. **Initial Run:** Before cooking food, run the oven empty for about 15 minutes at 400°F (200°C) to burn off any manufacturing residues. A slight odor or smoke is normal during this process. Ensure the area is well-ventilated.
5. **Insert Crumb Tray:** Slide the crumb tray into the lowest position at the bottom of the oven.



Image: The Gourmia oven on a counter, highlighting its compact design. An inset shows a hand placing a removable, dishwasher-safe tray into a dishwasher, emphasizing ease of cleaning.

Operating Instructions

The Gourmia Digital Air Fryer Oven features an intuitive digital control panel for easy operation.

Digital Control Panel

The control panel includes 12 one-touch presets, temperature and time adjustments, and a convection mode button.



Image: The digital control panel of the Gourmia oven, illustrating the one-touch presets and the clear display for temperature and time. French fries are visible inside the oven, ready for air frying.

Using Presets

1. **Select Preset:** Tap the desired preset icon (e.g., Air Fry, Bake, Roast) on the control panel. The oven will display a default temperature and time for that function.
2. **Adjust Settings (Optional):** Use the "TEMP/TIME" buttons (+/-) to adjust the temperature or cooking time if needed.
3. **Start Cooking:** Press the "START/STOP" button to begin the cooking cycle. The oven will preheat if necessary.
4. **Add Food:** Once preheating is complete (if applicable), the oven will prompt you to add food. Carefully place your food inside using the appropriate accessory.
5. **Enjoy:** The oven will automatically stop when the cooking cycle is complete.



Image: A visual guide to using the oven: 1. Select a preset, 2. Add food, 3. Enjoy your meal. This demonstrates the simple, intuitive operation of the appliance.

Convection Mode

The convection mode utilizes a high-speed fan to circulate hot air evenly throughout the oven. This results in faster cooking times and crispier, more consistent results, especially for air frying and roasting.

- **FryForce 360° Technology:** This patented technology ensures rapid airflow for golden, crispy food using little to no oil.
- **Even Heat Distribution:** Promotes uniform cooking and browning.



Image: The convection mode in action, with a whole chicken cooking. The image also highlights the FryForce 360° Technology, which uses powerful air circulation for crispy results with minimal oil.

Cooking Functions

The Gourmia Digital Air Fryer Oven offers 12 versatile cooking presets:

- **Air Fry:** Ideal for achieving crispy textures with little to no oil.
- **Bake:** Perfect for cakes, cookies, and other baked goods.
- **Roast:** For cooking meats and vegetables to tender perfection.
- **Toast:** For perfectly browned toast and bread.
- **Bagel:** Optimized for toasting bagels.
- **Broil:** For quick browning and melting.
- **Dehydrate:** Create healthy snacks like fruit chips and jerky.
- **Popcorn:** Enjoy fresh, homemade popcorn.
- **Fries:** Dedicated setting for crispy french fries.
- **Wings:** For perfectly cooked chicken wings.
- **Snacks:** General setting for various snack items.
- **Keep Warm:** Maintains food at a warm temperature for up to 4 hours.



Image: The dehydrate mode in use, showing various fruit slices being prepared for healthy snacks. This highlights one of the many versatile functions of the oven.

Capacity and Design

The Gourmia Digital Air Fryer Oven is designed with a generous capacity while maintaining a compact footprint suitable for most kitchen countertops.

- **Large Capacity:** Comfortably fits a 9-inch pizza, 4 slices of bread, or family-sized portions.
- **3 Rack Positions:** Adjustable rack levels provide flexibility for different food items and cooking methods.
- **XL Glass Window:** Allows easy monitoring of food during cooking without opening the door, helping to maintain consistent temperatures.



Image: The large capacity of the Gourmia oven is demonstrated by showing it can accommodate 4 slices of toast, a 9-inch pizza, and a whole chicken simultaneously.



Image: Dimensions of the Gourmia Digital Air Fryer Oven, including exterior measurements (15" W x 8.5" H x 10.5" D) and interior measurements (10.5" W x 6.5" H x 8" D), illustrating its compact yet spacious design.

Care and Maintenance

Proper care and maintenance will ensure the longevity and optimal performance of your Gourmia Digital Air Fryer Oven.

- **Cleaning:** Always unplug the oven and allow it to cool completely before cleaning.
- **Dishwasher-Safe Parts:** The air fry basket, oven rack, baking pan, and crumb tray are all dishwasher safe for easy cleanup.
- **Exterior:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners or scouring pads.
- **Interior:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn stains, use a non-abrasive sponge.
- **Crumb Tray:** Regularly remove and empty the crumb tray to prevent buildup and potential fire hazards.



Image: Demonstrates the ease of cleaning with dishwasher-safe parts. A hand places a removable tray into a dishwasher, emphasizing convenience.

Troubleshooting

If you encounter any issues with your Gourmia Digital Air Fryer Oven, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker.
Food is not cooking evenly.	Overcrowding; incorrect rack position; insufficient cooking time/temperature.	Avoid overcrowding the basket/pan. Use the recommended rack position. Adjust cooking time or temperature as needed. Flip or shake food halfway through cooking.
White smoke coming from the appliance.	Excess oil/grease; food residue.	Ensure the crumb tray is clean. Remove any excess oil or grease from food before cooking. Clean the interior of the oven regularly.
Digital display not responding.	Temporary electronic glitch.	Unplug the appliance from the power outlet for 1 minute, then plug it back in.

Specifications

Feature	Detail
Model Name	Toaster Oven
Model Number	GTF1188SSA
Brand	Gourmia
Capacity	10 Quarts (Fits 9" pizza, 4 slices of bread)
Product Dimensions (D x W x H)	10.5"D x 15"W x 8.5"H
Item Weight	6.8 Pounds

Feature	Detail
Material	Aluminum, Stainless Steel
Color	Silver
Output Wattage	1000 Watts
Voltage	120 Volts
Control Method	Touch
Max Temperature Setting	400 Degrees Fahrenheit
Air Frying Technology	Rapid Air Circulation (FryForce 360°)
Dishwasher Safe Parts	Yes
Included Components	Air Fryer Basket, Oven Rack, Baking Pan, Crumb Tray
UPC	810190210420

Official Product Videos

Watch these official product videos for visual guides on setup, features, and cooking demonstrations.

Gourmia Digital Air Fryer Oven Overview

▶ **Watch video online**
Honest Review Of Gourmia Toaster Oven Digital Air Fryer - Convection Mode

Video: An honest review of the Gourmia Toaster Oven Digital Air Fryer, highlighting its convection mode and various features. This video provides a comprehensive look at the appliance's capabilities.

Replacing Multiple Appliances with Gourmia

▶ **Watch video online**
This little oven just replaced my toaster, air fryer, +more

Video: This video demonstrates how the Gourmia oven can replace multiple kitchen appliances, showcasing its versatility and space-saving benefits.

Gourmia Air Fryer with 12 Cooking Functions

▶ **Watch video online**
Gourmia Air Fryer with 12 cooking functions

Video: A demonstration of the Gourmia Air Fryer's 12 cooking functions, providing a quick look at its various capabilities for different types of food preparation.

Warranty and Support

For warranty information or customer support, please refer to the contact details provided in your product packaging or visit the official Gourmia website. Keep your purchase receipt as proof of purchase for any warranty claims.
Manufacturer: Gourmia

© 2026 Gourmia. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G6NWBZ36

More documents and user manuals: **https://manuals.plus/**