Makerbase MKS Monster8 V2

Makerbase MKS Monster8 V2 32Bit Control Board Instruction Manual

Model: MKS Monster8 V2 | Brand: Makerbase

1. Introduction

The Makerbase MKS Monster8 V2 is a high-performance 32-bit control board designed for advanced 3D printing applications, particularly compatible with Voron systems. It features TMC2209 stepper motor drivers, ensuring precise motor control and stable power output for enhanced printing accuracy. This board offers fast data transmission and smooth firmware operation, supporting complex tasks without lag. Its durable construction is built to withstand regular use and voltage fluctuations, providing long-term stability for extended printing sessions. This manual provides essential information for the proper setup, operation, and maintenance of your MKS Monster8 V2 control board.

2. Product Overview



Figure 2.1: Top view of the MKS Monster8 V2 control board, showing various connectors and the included USB cable.

The MKS Monster8 V2 board integrates key components for 3D printer control, including multiple stepper motor driver slots, power input terminals, and various peripheral connectors. Its compact design allows for efficient integration into 3D printer enclosures.



Figure 2.2: Angled perspective of the MKS Monster8 V2 board, highlighting the driver sockets and power input.



Figure 2.3: A different angled view, showing the USB and Ethernet ports on the side.



Figure 2.4: Bottom view of the MKS Monster8 V2 board, displaying solder points and component layout.

3. Setup and Installation

Proper installation is crucial for the stable operation of your MKS Monster8 V2 board. Always ensure the power is disconnected before making any connections.

3.1 Mounting the Board

Secure the MKS Monster8 V2 board within your 3D printer's control enclosure using appropriate standoffs and screws. Ensure there is adequate airflow around the board to prevent overheating, especially for the stepper motor drivers.

3.2 Wiring Connections

Carefully connect all components to the board. Refer to your 3D printer's wiring diagram and the MKS Monster8 V2 pinout documentation for precise connections. Common connections include:

- **Power Input:** Connect your 24V or 12V power supply to the designated power terminals. Observe correct

polarity.

- **Stepper Motors:** Connect X, Y, Z, and E (extruder) stepper motors to their respective driver slots. Ensure the motor wires are correctly matched to the driver pins.
- **Endstops:** Connect mechanical or optical endstops to the X, Y, and Z endstop pins.
- **Heaters:** Connect the hotend heater and heated bed to the designated heater outputs.
- **Thermistors:** Connect thermistors for the hotend and heated bed to the temperature sensor inputs.
- **Fans:** Connect cooling fans for the hotend, part cooling, and board cooling to the fan outputs.
- **USB/Ethernet:** Connect the board to your computer via USB for initial setup and firmware flashing, or use Ethernet for network connectivity if supported by your firmware.

3.3 Firmware Flashing

The MKS Monster8 V2 requires compatible firmware (e.g., Marlin, Klipper) to operate. Follow the specific instructions provided by your chosen firmware project for compiling and flashing the firmware to the board. Typically, this involves:

1. Downloading the firmware source code.
2. Configuring the firmware for your specific printer setup (e.g., motor types, endstop logic, thermistor values, board type).
3. Compiling the firmware using a suitable IDE (e.g., PlatformIO in VS Code).
4. Flashing the compiled firmware to the MKS Monster8 V2 board, usually via USB or an SD card.

Refer to the official Makerbase documentation or community resources for detailed firmware setup guides specific to the MKS Monster8 V2.

4. Operating Instructions

Once the board is installed and firmware is flashed, you can begin operating your 3D printer.

4.1 Powering On

Connect the power supply to the board and turn on the main power switch for your 3D printer. The board's indicator LEDs should illuminate, indicating successful power-up.

4.2 Connecting to a Host

You can control your 3D printer via a computer connected through USB, or a network connection (e.g., OctoPrint via Raspberry Pi connected to USB or Ethernet). Ensure the correct drivers are installed on your computer if connecting via USB.

4.3 Basic Operation

Use your chosen host software (e.g., Pronterface, OctoPrint, Repetier-Host) to send G-code commands, monitor printer status, and initiate prints. Always perform a homing sequence (G28) before starting a print to establish the printer's origin.

5. Maintenance

Regular maintenance helps ensure the longevity and reliable performance of your MKS Monster8 V2 control board.

- **Cleaning:** Periodically disconnect power and gently clean the board with compressed air or a soft brush to remove dust and debris. Avoid using liquids.
- **Connection Inspection:** Regularly check all wiring connections to ensure they are secure and free from corrosion or damage. Loose connections can lead to intermittent issues or component failure.
- **Firmware Updates:** Keep your firmware updated to benefit from bug fixes, performance improvements, and new features. Always back up your configuration before updating.
- **Environmental Control:** Operate the board in a clean, dry environment with stable temperatures. Avoid extreme humidity or direct exposure to heat sources.

6. Troubleshooting

This section addresses common issues you might encounter.

6.1 Board Not Powering On

- **Check Power Supply:** Ensure the power supply is connected correctly and providing the correct voltage (12V or 24V).
- **Verify Polarity:** Double-check that the power input polarity is correct. Incorrect polarity can damage the board.
- **Inspect Fuses:** Check if any fuses on the board are blown. Replace them with fuses of the correct rating if necessary.

6.2 Stepper Motors Not Moving or Moving Incorrectly

- **Driver Installation:** Ensure TMC2209 drivers are correctly inserted into their sockets and oriented properly.
- **Motor Wiring:** Verify that motor wires are connected to the drivers in the correct sequence.
- **Firmware Configuration:** Check your firmware settings for correct motor direction, steps per millimeter, and driver configuration (e.g., UART/SPI mode).
- **Driver Voltage:** Ensure the stepper motor driver's Vref (voltage reference) is set correctly, or that the current is configured properly in firmware.

6.3 Heating Issues (Hotend/Bed Not Heating)

- **Wiring:** Confirm that heater and thermistor wires are securely connected to the correct terminals on the board.
- **Firmware Settings:** Verify that thermistor types and heater pin assignments are correctly configured in the firmware.
- **Component Check:** Test the heater cartridges and thermistors for continuity and correct resistance values.

6.4 Communication Problems (USB/Ethernet)

- **USB Cable:** Try a different USB cable.
- **Drivers:** Ensure the correct USB serial drivers are installed on your computer.
- **Baud Rate:** Verify that the baud rate in your host software matches the baud rate configured in the firmware.
- **Ethernet Configuration:** If using Ethernet, check network settings and ensure the board has a valid IP address.

7. Specifications

Feature	Detail
Model	MKS Monster8 V2
Processor	32-bit ARM Cortex-M (Specific chip may vary, refer to official documentation)
Stepper Drivers	TMC2209 (integrated or socketed, depending on variant)
Compatibility	Voron 3D Printers, Marlin, Klipper firmware
Power Input	12V-24V DC
Connectivity	USB, Ethernet (if supported by firmware/hardware variant), SD Card
Package Dimensions	0.39 x 0.39 x 0.39 inches
Item Weight	1.76 ounces
ASIN	B0GG63S3YG
Manufacturer	Makerbase (Generic listed, but product is Makerbase)

8. Warranty and Support

Specific warranty terms for the Makerbase MKS Monster8 V2 control board may vary depending on your region and point of purchase. Please refer to the retailer's or manufacturer's official website for detailed warranty information.
For technical support, firmware updates, and additional resources, visit the official Makerbase website or consult relevant 3D printing community forums. These resources often provide comprehensive guides, troubleshooting tips, and community assistance for MKS products.
Note: Always ensure you are using official and verified resources for firmware and technical information to prevent potential damage to your board or printer.

© 2026 Makerbase. All rights reserved. This manual is for informational purposes only.