Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Magic Mill MTO-870SN

Magic Mill MTO-870SN Ultra-Premium Air Fryer Toaster Oven Combo

User Manual

Safety Instructions | Product Overview | Setup | Operating Instructions | Maintenance & Cleaning | Troubleshooting | Specifications

1. Safety Instructions

Please read all instructions carefully before using the Magic Mill Air Fryer Toaster Oven Combo to ensure safe operation and prevent damage to the appliance or injury to yourself. Keep this manual for future reference.

General Safety

- Do not touch hot surfaces. Use handles or knobs. Always use oven mitts or protective gloves when handling hot materials.
- To protect against electrical shock, do not immerse the cord, plugs, or the appliance body in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for other than intended use.
- Oversized foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.

- A fire may occur if the oven is covered or touching flammable material, including curtains, drapes, walls, and the like, when in operation. Do not store any item on top of the appliance when in operation.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, or similar materials.
- Do not store any materials, other than manufacturer's recommended accessories, in this oven when not in use.
- Always wear protective, insulated oven gloves when inserting or removing items from the hot oven.

Electrical Safety

- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting the appliance.
- The appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.
- A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.

2. Product Overview

The Magic Mill MTO-870SN is an Ultra-Premium Air Fryer Toaster Oven Combo designed for versatile cooking. It features independent dual-zone technology, a large 32-quart capacity, and 10 smart presets to simplify meal preparation.

Key Features

- **SyncCore Dual-Zone Cooking with Sync Finish:** Cook two different dishes simultaneously with separate temperatures and timers. The Sync Finish feature ensures both zones complete cooking at the same time. A removable divider allows for full 32QT capacity when needed.
- **10-in-1 Smart Presets:** Offers optimized functions for Air Fry, Bake, Toast, Rotisserie, Pizza, Roast, Broil, Dehydrate, Reheat, and Ferment.
- **LED Display, Interior Lighting & Touch Controls:** Dual LED displays for easy programming, interior lighting to monitor cooking progress, and responsive touch controls for precise adjustments.
- **Family-Size 32-Quart Capacity:** Accommodates a full rotisserie chicken, a 12-inch pizza, or multiple trays, suitable for family meals and entertaining.
- **Durable Construction:** Crafted with stainless steel for everyday use.

Included Accessories

The appliance comes with a 13-piece premium accessory kit, all designed to be top-rack dishwasher-safe for easy cleaning.

- Roasting Pan
- Baking Pans (multiple)
- Grill Racks (multiple)
- Air Fry Baskets (multiple)
- Rotisserie Spit
- Rotisserie Removal Tool
- Crumb Tray
- Cavity Divider



Figure 2.1: The image displays the Magic Mill Air Fryer Toaster Oven alongside a visual breakdown of its 13 included accessories. These include a rotisserie spit, removal tool, divider panel, grill racks, air fry baskets, baking trays, and a crumb tray, illustrating the comprehensive kit provided.

3. Setup

Unpacking

1. Carefully remove the appliance and all accessories from the packaging.
2. Remove any packaging materials, stickers, or labels from the appliance and accessories.
3. Retain the packaging for future storage or shipping if needed.

Initial Cleaning

1. Before first use, wipe the exterior of the appliance with a damp cloth.
2. Wash all removable accessories (roasting pan, baking pans, grill racks, air fry baskets, rotisserie tools, crumb

tray, cavity divider) in warm, soapy water or in the dishwasher. Rinse thoroughly and dry completely.
3. Ensure all parts are dry before placing them back into the oven.

Placement

- Place the appliance on a stable, level, heat-resistant surface.
- Ensure there is adequate space (at least 4-6 inches) on all sides and above the oven for proper ventilation. Do not place it directly against a wall or under cabinets.
- Do not place the appliance near flammable materials such as curtains or drapes.
- Plug the power cord into a grounded electrical outlet.

4. Operating Instructions

Control Panel Overview

The Magic Mill Air Fryer Toaster Oven features an intuitive LED touchscreen control panel. It consists of dual displays for independent zone control, function icons, temperature/time adjustments, and start/pause buttons.



Figure 4.1: This image provides a detailed view of the appliance's LED touchscreen control panel. It highlights the 10 smart presets for functions like Air Fry, Toast, Pizza, Roast, Broil, Bake, Reheat, Ferment, and Rotisserie, along with temperature and time controls.

Basic Operation

1. **Power On:** Plug the appliance into a grounded outlet. The display will illuminate.
2. **Select Zone:** If using dual zones, select the Left or Right zone on the control panel. If using the full cavity, ensure the divider is removed.
3. **Choose Function:** Select one of the 10 smart presets (e.g., Air Fry, Bake, Toast) or manually set the desired cooking mode.
4. **Adjust Settings:** Use the temperature and time controls to set your desired cooking parameters.
5. **Start Cooking:** Press the 'Start/Pause' button to begin the cooking cycle.
6. **Monitor Progress:** Use the interior light to check food without opening the doors.
7. **End Cycle:** The oven will beep when the cooking cycle is complete. Carefully remove food using oven mitts.

Dual-Zone Cooking with Sync Finish

This feature allows you to cook two different foods at different temperatures and times, ensuring they finish

simultaneously.



Figure 4.2: This image shows the Magic Mill Air Fryer Toaster Oven with its French doors open, revealing two independent cooking zones. The left zone contains vegetables air frying at 375°F, and the right zone contains a roast chicken at 425°F, demonstrating its dual-zone cooking capability.

1. Place the cavity divider in the center of the oven.
2. Load food into both the left and right zones with appropriate accessories.
3. Select the Left zone on the control panel, choose a cooking function, temperature, and time.
4. Select the Right zone on the control panel, choose a different cooking function, temperature, and time.
5. Press the 'Sync' button (if available) to activate the Sync Finish feature. The oven will automatically adjust the start times of each zone so they complete cooking together.
6. Press 'Start/Pause' to begin.



Figure 4.3: The image shows the Magic Mill Air Fryer Toaster Oven's Sync Finish mode in action, with two different dishes (fries and pizza) cooking in separate zones. The control panel indicates different timers but a synchronized finish, ensuring both meals are ready at the same time.

Using the Rotisserie Function

The rotisserie function is ideal for roasting whole chickens or other large cuts of meat, ensuring even cooking and a crispy exterior.



Figure 4.4: This image features the Magic Mill Air Fryer Toaster Oven with a whole chicken rotating on the built-in rotisserie spit, emphasizing its capability for even roasting and golden, juicy results.

1. Prepare your food for rotisserie cooking (e.g., truss a whole chicken).
2. Insert the rotisserie spit through the food and secure it with the forks.
3. Place the rotisserie assembly into the oven's rotisserie slots. Ensure the drip tray is placed at the bottom.
4. Select the 'Rotisserie' preset on the control panel.
5. Adjust temperature and time as needed.
6. Press 'Start/Pause'. The rotisserie will begin to rotate.
7. Use the rotisserie removal tool to safely extract the hot food after cooking.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your appliance. Always unplug the oven and allow it to cool completely before cleaning.

Cleaning the Interior and Exterior

- Wipe the exterior surfaces with a damp cloth and mild detergent. Do not use abrasive cleaners or scouring pads, as they may damage the finish.
- For the interior, wipe down with a damp cloth and mild, non-abrasive cleaner. For stubborn stains, a paste of baking soda and water can be used, then wiped clean.
- Do not immerse the main unit in water or any other liquid.

Cleaning Accessories

All included accessories are top-rack dishwasher-safe for convenient cleaning.



Figure 5.1: This image demonstrates the ease of cleaning the Magic Mill Air Fryer Toaster Oven's accessories. It shows a baking pan being rinsed under water and other accessories placed in a dishwasher, indicating that removable parts are dishwasher-safe for convenient cleanup.

- Remove the crumb tray from the bottom of the oven and discard any crumbs. Wash the crumb tray with warm, soapy water or place it in the dishwasher.

- Wash roasting pans, baking pans, grill racks, air fry baskets, rotisserie spit, and removal tool with warm, soapy water or place them in the top rack of your dishwasher.
- Rinse all accessories thoroughly and dry completely before storing or re-inserting into the oven.

6. Troubleshooting

If you encounter any issues with your Magic Mill Air Fryer Toaster Oven Combo, please refer to the following table for common problems and solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; circuit breaker tripped.	Ensure the power cord is securely plugged into a working outlet. Check your household circuit breaker.
Food is not cooking evenly.	Overcrowding; incorrect temperature/time; food placement.	Avoid overcrowding the oven. Ensure food is arranged in a single layer for air frying. Adjust temperature and time as needed. Rotate food halfway through cooking if necessary.
Smoke is coming from the oven.	Excess oil/grease; food residue; crumb tray full.	Ensure the crumb tray is clean. Clean any food residue from the interior. Use less oil or pat food dry before cooking.
Rotisserie function not working.	Rotisserie spit not properly installed; food too heavy.	Ensure the rotisserie spit is correctly seated in the drive socket and support bracket. Do not exceed the maximum weight capacity for rotisserie (refer to specifications).
Sync Finish not synchronizing.	Sync button not activated; significant time difference between zones.	Ensure the 'Sync' button is pressed after setting both zones. The system works best with reasonable time differences.

7. Specifications

Feature	Detail
Brand	Magic Mill
Model Name	MTO-870SN
Color	Stainless Steel
Product Dimensions (D x W x H)	14.6"D x 16.65"W x 17.87"H
Capacity	32 Quarts
Special Features	Automatic Shut-Off, Independent Dual Zone, LED Display, Large Capacity, Rotisserie Feature

Feature	Detail
Material	Stainless Steel
Wattage	1800 watts
Control Type	Touch Control
Power Source	Electric
Temperature Range	80-450 Degrees Fahrenheit
Number of Shelves	1 (adjustable positions)
Door Style	French Door
UPC	810183041727

8. Warranty and Support

Magic Mill products are built for daily use and engineered for performance, reliability, and quality. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Magic Mill customer support. Contact information can typically be found on the manufacturer's website or on the product packaging.

- **Online Support:** Visit the official Magic Mill website for FAQs, product registration, and support contact forms.
- **Email/Phone:** Refer to your product packaging or the Magic Mill website for direct contact methods.

© 2026 Magic Mill. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GK625QKV

More documents and user manuals: **https://manuals.plus/**