Manuals+
Q & A | Deep Search | Upload

Princess 182494

Princess Air Fryer Oven Vision Instruction Manual

Model: 182494

Introduction

Thank you for purchasing the Princess Air Fryer Oven Vision. This versatile appliance offers multiple functions for preparing a wide variety of dishes with hot air, including air frying, baking, roasting, and toasting. With its generous 12.6-liter capacity and 1800W power, it is ideal for cooking large portions or complete meals for the family. The durable plastic construction is designed for frequent and prolonged use, and its smooth interior surfaces ensure quick and convenient cleaning.

This manual provides important information regarding the safe operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

Important Safety Instructions

- Always place the appliance on a stable, heat-resistant surface, away from walls and other appliances to allow for proper ventilation.
- Do not immerse the appliance, cord, or plug in water or any other liquid.
- Ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Keep children and pets away from the appliance during operation.
- Do not touch hot surfaces. Use oven mitts or handles.
- Unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool completely before handling.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

Product Overview

The Princess Air Fryer Oven Vision is designed for efficient and versatile cooking. Familiarize yourself with its components and accessories.

Main Unit and Control Panel

Image: Front-side view of the Princess Air Fryer Oven Vision, showing the main unit with a transparent door and digital control panel on top.

Image: Top-down view of the Princess Air Fryer Oven Vision, displaying the digital control panel and a whole roasted chicken inside.

Accessories

- **Mesh Baskets:** For air frying smaller items like fries, vegetables, or chicken wings.
- **Rotisserie Spit:** For roasting whole chickens or larger cuts of meat.
- **Rotisserie Handle:** For safely inserting and removing the hot rotisserie spit.
- **Drip Tray:** Collects excess oil and food drippings for easier cleaning.
- **Rotisserie Basket:** A cylindrical mesh basket for tumbling items like nuts or coffee beans.

Image: Various accessories for the Princess Air Fryer Oven Vision, including mesh baskets, a rotisserie spit, a rotisserie handle, and a drip tray.

Setup

Unpacking and Initial Cleaning

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Wipe the exterior of the appliance with a damp cloth.
3. Wash all removable accessories (mesh baskets, rotisserie spit, drip tray) in warm, soapy water. Rinse thoroughly and dry completely.
4. Wipe the interior of the appliance with a damp cloth.

Placement

- Place the air fryer oven on a stable, level, and heat-resistant surface.
- Ensure there is at least 10 cm (4 inches) of clear space around the back and sides of the appliance, and 30 cm (12 inches) above, for adequate air circulation.
- Do not place the appliance near flammable materials or heat sources.

Power Connection

- Plug the power cord into a grounded electrical outlet.
- The appliance is now ready for use.

Operating Instructions

Control Panel Overview

Image: Close-up of the digital control panel with various cooking icons and temperature/time display.

The digital control panel features intuitive touch controls and a clear display for temperature and time. It includes:

- **Power Button:** To turn the appliance on/off.
- **Temperature Control:** Adjusts cooking temperature.
- **Time Control:** Adjusts cooking time.
- **Preset Icons:** Various pre-programmed settings for common dishes (e.g., fries, chicken, fish, pizza).
- **Start/Pause Button:** To begin or temporarily stop the cooking process.
- **Light Button:** To turn the interior light on/off.
- **Rotisserie Button:** To activate the rotisserie rotation function.

Basic Operation

1. **Power On:** Plug in the appliance. Press the Power button to turn it on. The display will light up.

2. **Select Function/Preset:** Choose a preset icon for common dishes, or manually set the temperature and time.
3. **Adjust Temperature and Time:** Use the temperature and time control buttons to set your desired cooking parameters.
4. **Preheat (Optional):** For best results, preheat the appliance for 3-5 minutes at the desired temperature before adding food.
5. **Start Cooking:** Press the Start/Pause button to begin cooking.
6. **Monitor Cooking:** The transparent door allows you to monitor food without opening the appliance. Use the interior light button if needed.
7. **Finish Cooking:** The appliance will beep when the cooking time is complete and automatically shut off. Carefully remove food using oven mitts.

Using Accessories

- **Mesh Baskets:** Place food evenly in the mesh baskets. Slide the baskets into the designated slots inside the oven. Ensure they are securely seated.
- **Rotisserie Spit:** Skewer a whole chicken or roast onto the rotisserie spit. Secure it with the forks. Insert the rotisserie spit into the appliance's rotisserie drive and support. Press the Rotisserie button on the control panel to activate rotation.
- **Drip Tray:** Always place the drip tray at the bottom of the appliance to catch any drippings and facilitate cleaning.

Image: French fries cooking inside the Princess Air Fryer Oven Vision, visible through the transparent door.

Image: View of the interior heating element of the Princess Air Fryer Oven Vision, showing the coiled heating element at the top.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your appliance. Always ensure the appliance is unplugged and completely cooled before cleaning.

Cleaning the Interior and Exterior

- Wipe the exterior with a damp cloth and mild detergent. Do not use abrasive cleaners.
- For the interior, wipe with a damp cloth and mild, non-abrasive cleaning solution. For stubborn food residue, a soft brush or sponge can be used.
- Ensure the heating element is free from food debris.

Cleaning Accessories

- All removable accessories (mesh baskets, rotisserie spit, drip tray) can be washed in warm, soapy water.
- Some accessories may be dishwasher safe; refer to the specific accessory instructions if provided.

- Dry all parts thoroughly before reassembling or storing.

Storage

- Store the appliance in a cool, dry place.
- Ensure all parts are clean and dry before storage.

Troubleshooting

If you encounter any issues with your Princess Air Fryer Oven Vision, consult the following common problems and solutions:

- **Appliance does not turn on:** Check if the power cord is securely plugged into a working outlet. Ensure the power button has been pressed.
- **Food not cooking evenly:** Ensure food is not overcrowded in the baskets. Shake or turn food halfway through cooking. Verify correct temperature and time settings.
- **White smoke coming from the appliance:** This may indicate excessive oil or fat dripping onto the heating element. Clean the drip tray and interior thoroughly. Ensure food is not excessively greasy.
- **Appliance emits a burning smell:** This can be normal during first use due to manufacturing residues. If it persists, unplug the appliance and check for any foreign objects or food debris inside.

If the problem persists after checking these points, please contact customer support.

Specifications

Brand	Princess
Model Number	01.182494.01.001
Color	Black
Product Dimensions	44.6 x 33.7 x 35.5 cm
Capacity	12.6 Liters
Power	1800 Watts
Voltage	230 Volts
Automatic Shut-off	Yes
Special Features	Automatic Shut-off, Temperature Control, Programmable, Timer
Product Weight	7.7 kg
Non-stick Coating	Yes

Warranty and Support

This Princess Air Fryer Oven Vision comes with a standard manufacturer's warranty. For detailed information regarding warranty terms and conditions, please refer to the warranty card included with your product or visit the official Princess website.

For technical support, spare parts, or service inquiries, please contact Princess customer service. Contact details

can typically be found on the manufacturer's website or in the product packaging.