Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jocoevol JOC-C-1615

Jocoevol 58" Farmhouse Electric Fireplace TV Stand User Manual

Model: JOC-C-1615

1. Introduction

Thank you for purchasing the Jocoevol 58" Farmhouse Electric Fireplace TV Stand. This product combines a stylish entertainment center with a functional electric fireplace, offering both storage and warmth. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your unit.



Image 1.1: The Jocoevol 58" Farmhouse Electric Fireplace TV Stand in a living room.

Your browser does not support the video tag.

Video 1.1: Overview of the Jocoevol 59" Farmhouse Fireplace TV Stand, showcasing its design and features.

2. Safety Information

Please read all safety warnings and instructions carefully before assembly and use. Failure to follow these instructions may result in electric shock, fire, property damage, or personal injury.

- **Electrical Safety:** Ensure the fireplace is connected to a properly grounded outlet. Do not overload electrical circuits. Do not run the power cord under carpeting or in high-traffic areas.
- **Placement:** Place the TV stand on a flat, level, and stable surface. Maintain a minimum distance of 3 feet (0.9 meters) from combustible materials such as curtains, bedding, furniture, and other flammables.
- **Ventilation:** Do not block the air vents of the electric fireplace. Ensure proper airflow around the unit.
- **Children and Pets:** Keep children and pets away from the fireplace when it is operating. The glass front can become hot.
- **Overheat Protection:** The fireplace is equipped with an overheat protection system that will automatically shut

off the unit if it becomes too hot. If this occurs, unplug the unit, wait 15 minutes, and then plug it back in.

- **Maintenance:** Always unplug the fireplace before cleaning or performing any maintenance.
- **Anti-Tip Hardware:** Secure the TV stand to the wall using the provided anti-tip hardware to prevent accidental tipping, especially in households with children.

3. Setup and Assembly

Assembly requires two adults and approximately 90 minutes. Ensure all parts are present before beginning assembly. A Phillips head screwdriver is required (not included).

3.1 Unpacking

1. Carefully open the packaging and remove all components.
2. Check the parts list against the included hardware and panels to ensure nothing is missing or damaged. If any parts are missing or damaged, contact customer support.
3. Lay out all parts on a soft, clean surface (e.g., a blanket or carpet) to prevent scratching.

3.2 Assembly Instructions

Follow the step-by-step instructions provided in the included assembly manual. The general process involves:

- Assembling the base and side panels.
- Attaching the back panel.
- Installing the drawers and drawer slides.
- Mounting the sliding barn door hardware and doors.
- Inserting the adjustable shelves.
- Installing the electric fireplace insert.
- Attaching the LED lighting strip to the floating base.
- Securing the unit to the wall using anti-tip hardware.

Your browser does not support the video tag.

Video 3.1: Detailed installation guide for the 59" Farmhouse Fireplace TV Stand.



Image 3.1: Product dimensions for the TV stand, fireplace, and drawers.

4. Operation

4.1 Electric Fireplace

The electric fireplace provides realistic 3D flame effects and supplemental heating for spaces up to 400 sq. ft. It can be operated via the control panel on the unit or the included remote control.



Image 4.1: The 24" electric fireplace unit and its remote control.

Controls and Functions:

- **Power On/Off:** Press the power button to turn the fireplace on or off.
- **Temperature Adjustment:** Use the temperature buttons (up/down arrows) to set the desired room temperature from 62°F to 82°F.
- **Timer:** Set the programmable timer for automatic shut-off from 0.5 to 6 hours.
- **Flame Levels:** Adjust the brightness of the 3D flame effects to your preference (multiple levels available).
- **Heat Function:** The heater can be turned on or off independently of the flame effect.
- **Sleep Mode:** Operates quietly (less than 50 dB) for undisturbed rest.

Your browser does not support the video tag.

Video 4.1: Demonstration of the 3D flame electric fireplace features.

4.2 LED Floating Light

The integrated LED lighting system offers over 60,000 color options and adjustable brightness, controllable via the included remote or a mobile app.



Image 4.2: The TV stand showcasing its RGB LED floating light feature.

LED Light Functions:

- **Color Selection:** Choose from a wide spectrum of colors to match your mood or decor.
- **Brightness Adjustment:** Dim or brighten the lights as desired.
- **Music Sync:** The lights can sync with music for dynamic effects (via app control).
- **Preset Modes:** Various preset lighting effects for different occasions.
- **App Control:** Download the specified mobile app for advanced control features.

4.3 Storage Features

The TV stand offers ample storage solutions to keep your living space organized.

- **Sliding Barn Doors:** Two smooth-gliding barn doors provide flexible access to the side cabinets, concealing or revealing items as needed.
- **Adjustable Shelves:** The interior shelves in the side cabinets are adjustable to three different levels, accommodating items of various sizes such as gaming consoles, books, or decor.
- **Storage Drawers:** Two oversized drawers offer convenient storage for remotes, controllers, magazines, and

other small essentials.



Image 4.3: Detail of the smooth sliding barn doors.



Image 4.4: Overview of the adjustable shelves and storage capacity.



Image 4.5: The two spacious storage drawers for everyday essentials.

5. Maintenance and Care

Proper care will help maintain the appearance and functionality of your TV stand and electric fireplace.

- **Cleaning the Wood Surfaces:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or furniture polish that may damage the finish.
- **Cleaning the Fireplace:** Ensure the fireplace is unplugged and cool before cleaning. Use a soft, dry cloth to wipe the exterior. For the glass front, use a glass cleaner applied to a cloth (not directly to the glass) and then wipe. Do not use abrasive cleaners on the glass.
- **Dusting:** Regularly dust all surfaces with a soft, dry cloth.
- **Power Cord:** Periodically inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.
- **Ventilation:** Keep the fireplace vents clear of dust and debris to ensure proper operation and prevent overheating.

6. Troubleshooting

If you encounter any issues, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power switch off, or overheat protection activated.	Check power outlet and circuit breaker. Ensure the main power switch is on. If overheat protection activated, unplug for 15 minutes and retry.
No heat, but flames are visible.	Heater function is off.	Activate the heater function using the control panel or remote. Ensure temperature setting is higher than room temperature.
Remote control not working.	Dead batteries, remote out of range, or sensor blocked.	Replace batteries. Ensure remote is pointed at the fireplace sensor and within range. Remove any obstructions.
LED lights not working.	Power connection loose, remote/app issue.	Check the power connection to the LED strip. Ensure remote batteries are good or app is properly connected.
Unusual noises from fireplace.	Dust in fan, or minor expansion/contraction.	Ensure vents are clear. If noise persists or is loud, discontinue use and contact support.

7. Specifications

Feature	Specification
Brand	Jocoevol
Model Number	JOC-C-1615
Product Dimensions (D x W x H)	12"D x 58.6"W x 33.7"H
Material	Engineered Wood, Metal
Power Source	Corded Electric
Heat Output	1400 watts
Heating Coverage	Up to 400 sq ft
Temperature Range	62°F to 82°F
Timer	0.5 - 6 hours
Weight	122.7 pounds
Max TV Size Supported	Up to 65 inches
Tabletop Weight Capacity	Up to 260 lbs
Shelf Weight Capacity	Up to 35 lbs per shelf

8. Warranty Information

This Jocoevol product comes with a**1-Year Manufacturer's Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear. Please retain your proof of purchase for warranty claims.

9. Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact the retailer where you purchased this product or visit the official Jocoevol website for support. Please have your model number (JOC-C-1615) and proof of purchase ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GP7PRP41

More documents and user manuals: **https://manuals.plus/**