Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

QIDO EH-AF01-NEW

QIDO 8-in-1 Air Fryer Instruction Manual

Model: EH-AF01-NEW | Brand: QIDO

1. Important Safety Instructions

Please read all instructions carefully before using your QIDO Air Fryer. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the air fryer on a stable, heat-resistant surface.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Do not block any ventilation openings.
- Unplug the air fryer when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug.
- The outer surfaces may become hot during use. Use oven mitts when handling hot components.
- Do not overfill the basket.
- Never leave the appliance unattended while in operation.

2. Product Overview

The QIDO 8-in-1 Air Fryer is designed for versatile cooking, offering multiple functions in a compact design. It features a 5.5-quart capacity and a digital touch display for easy operation.

Key Components

- **Main Unit:** Houses the heating element and control panel.
- **Removable Basket:** 5.5 QT capacity for cooking various foods.
- **Crisper Tray:** Non-stick, designed to allow 360° air circulation for even cooking.
- **Digital Touch Display:** For setting time, temperature, and selecting presets.

- **Easy-View Window & Internal Light:** Allows monitoring of food without opening the basket.
- **Cool-Touch Handle:** Ensures safe handling of the hot basket.

Features

- **8-in-1 Functionality:** Air fry, broil, roast, dehydrate, bake, and reheat.
- **Precision Heating:** 360° hot air circulation with temperatures from 180°F to 400°F.
- **Smart Programs:** Large touch display with 11 intuitive auto-presets for common dishes.
- **Shake Reminder:** Alerts you to shake or flip food for even crisping.
- **Auto-Pause:** Pauses operation when the basket is removed and resumes when reinserted.
- **Dishwasher Safe:** Removable crisper basket and tray are non-stick and dishwasher safe for easy cleaning.



Image: The QIDO 8-in-1 Air Fryer, showcasing its sleek black design and digital display.

3. Setup

1. **Unpack:** Carefully remove all packaging materials from the air fryer and its accessories.
2. **Clean:** Wash the removable basket and crisper tray with warm, soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth.
3. **Assemble:** Insert the crisper tray into the basket, ensuring it sits securely at the bottom. Slide the assembled basket into the main unit until it clicks into place.
4. **Placement:** Place the air fryer on a stable, level, heat-resistant surface, ensuring adequate clearance (at least 5 inches) from walls and other appliances for proper ventilation.
5. **Power:** Plug the power cord into a grounded electrical outlet (120V). The display will illuminate.



Image: The compact design of the QIDO Air Fryer, illustrating its dimensions and suitability for various kitchen spaces.

4. Operating Instructions

Basic Operation

1. **Power On:** Press the power button (**U**) to turn on the air fryer.
2. **Preheat (Optional):** For best results, preheat the air fryer. Set the desired temperature and time (e.g., 5 minutes) and press the play/pause button (**▶/II**).
3. **Load Food:** Once preheated, carefully pull out the basket using the cool-touch handle. Place your food onto the crisper tray. Do not exceed the MAX fill line.
4. **Set Time & Temperature:** Use the 'TEMP/TIME' button to toggle between temperature and time settings. Use the '+' and '-' buttons to adjust values. Temperature range: 180°F-400°F. Time range: 1-60 minutes (up to 24 hours for dehydrate).
5. **Start Cooking:** Press the play/pause button (**▶/II**) to begin cooking.
6. **Monitor Food:** Use the Easy-View Window and internal light (press the light bulb icon) to check on your food without interrupting the cooking cycle.
7. **Shake Reminder:** The air fryer will beep and display a 'SHAKE' icon at the halfway point of certain cooking programs. Carefully remove the basket, shake or flip the food, and reinsert the basket to resume.
8. **End of Cooking:** The air fryer will beep several times when the cooking cycle is complete and automatically shut off. Carefully remove the basket and transfer food to a serving plate.

Using Auto-Presets

The QIDO Air Fryer features 11 pre-programmed settings for common foods. Simply touch the icon corresponding to your desired food, and the air fryer will automatically set the optimal time and temperature.



Image: The digital touch display showing various preset icons for different food types like fries, shrimp, pork, chicken, fish, cheese, steak, bacon, dehydrate, vegetables, and toast.

Your browser does not support the video tag.

Video: A demonstration of the QIDO Air Fryer's functional features, including the touch display and basket operation.

5. Cooking Guide

The following table provides general guidelines for cooking various foods. Adjust time and temperature as needed based on food quantity, thickness, and desired crispness.

Food Item	Temperature	Time	Notes
French Fries (frozen)	380°F (193°C)	15-20 min	Shake halfway through.

Food Item	Temperature	Time	Notes
Chicken Wings	380°F (193°C)	20-25 min	Flip halfway through.
Steak	400°F (204°C)	10-15 min	Flip halfway through for even cooking.
Fish Fillets	350°F (177°C)	10-12 min	Cook until flaky.
Vegetables (fresh)	375°F (190°C)	10-18 min	Toss halfway through.
Dehydrating Fruits	160°F (71°C)	4-8 hours	Check periodically for desired dryness.



Image: Illustration of the air fryer's large capacity, showing it can accommodate 20 chicken wings, 6 pieces of pizza, or a 3 lb steak.



Image: The air fryer in operation, demonstrating the 360° hot air circulation technology cooking a whole chicken.

6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your QIDO Air Fryer.

1. **Unplug:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Clean Basket & Tray:** The removable basket and crisper tray are non-stick and dishwasher safe. For manual cleaning, wash with warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely.
3. **Clean Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scourers. Never immerse the main unit in water or any other liquid.
4. **Clean Heating Element:** Use a cleaning brush to remove any food residue from the heating element inside the air fryer.

5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.



Image: The removable crisper basket and tray are shown being cleaned, highlighting their non-stick and dishwasher-safe properties.

7. Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in.	Ensure the power cord is securely plugged into a grounded outlet.
Food is not cooked evenly.	Basket is overfilled; food not shaken/flipped.	Do not overfill the basket. Shake or flip food halfway through cooking.

Problem	Possible Cause	Solution
White smoke coming from appliance.	Grease residue from previous use; fatty foods.	Clean the basket and crisper tray thoroughly. For fatty foods, drain excess oil during cooking.
Food not crispy.	Insufficient cooking time/temperature; too much moisture.	Increase cooking time or temperature. Pat food dry before cooking.

8. Specifications

- **Model Name:** EH-AF01-NEW
- **Capacity:** 5.5 Quarts
- **Power:** 1500 Watts
- **Voltage:** 120 Volts
- **Temperature Range:** 180°F - 400°F
- **Control Method:** Touch
- **Material:** PP Plastic
- **Product Dimensions:** 15.5"D x 15.15"W x 13.77"H
- **Item Weight:** 7.7 Pounds
- **Special Features:** 360° Hot Air Circulation, Easy-View Window, Large Touch Display with Auto Menus, Shake Reminder, Temperature Control, Non-stick Coating, Dishwasher Safe Components.

9. Warranty and Support

The QIDO Air Fryer (Model EH-AF01-NEW) comes with a **1-year warranty** from the date of purchase.
For warranty claims, technical support, or any questions regarding your product, please contact QIDO Customer Service:

- **Email:** webservice4you@outlook.com

Please have your model number (EH-AF01-NEW) and proof of purchase ready when contacting support.

© 2026 QIDO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GQZ5HKC5

More documents and user manuals: **https://manuals.plus/**