Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jocoevol JOC-C-1615

Jocoevol 70" Fireplace TV Stand User Manual

Model: JOC-C-1615

1. Introduction

1.1 Safety Information

Please read and understand all instructions before assembling and using this product. Failure to follow these instructions may result in electric shock, fire, property damage, or personal injury.

- Ensure all electrical connections comply with local codes and ordinances.
- Do not overload electrical outlets.
- Keep flammable materials at least 3 feet (0.9 meters) away from the fireplace heater.
- Do not block the air vents of the electric fireplace.
- This TV stand is designed to support TVs up to 75 inches and a maximum weight of 300 lbs on the tabletop. Do not exceed this weight limit.
- Install the anti-tip hardware provided to prevent accidental tipping, especially in households with children or pets.
- Always unplug the electric fireplace from the power outlet before cleaning or performing maintenance.

1.2 Package Contents

Your Jocoevol Fireplace TV Stand will be delivered in two separate packages, which may arrive at different times. Please ensure all parts are present before beginning assembly. Refer to the included assembly manual for a detailed list of parts and hardware.

Typical contents include:

- TV Stand Panels (top, bottom, sides, shelves, drawer fronts, door panels)
- Electric Fireplace Insert
- Hardware Pack (screws, dowels, cam locks, drawer slides, door tracks, handles, anti-tip kit)
- LED Light Strip and Controller
- Remote Control for Fireplace
- Assembly Instructions

2. Setup and Assembly

Assembly of this TV stand requires two people and approximately 90 minutes. Follow the step-by-step instructions

provided in the separate assembly manual. An installation video is also available for visual guidance.

2.1 Assembly Video Guide

For a detailed visual guide on assembling your TV stand, please refer to the official installation video:

▶ **Watch video online**
How to Install This Entertainment Center with Fireplace

Video: How to Install This Entertainment Center with Fireplace. This video demonstrates the step-by-step assembly process for the Jocoevol Fireplace TV Stand.

2.2 General Assembly Steps

1. **Unpack and Identify Parts:** Lay out all components and hardware. Verify against the parts list in the assembly manual.
2. **Assemble the Main Frame:** Follow the instructions to connect the base, side panels, and internal dividers.
3. **Install Drawer Slides and Door Tracks:** Attach the necessary hardware for drawers and sliding doors.
4. **Insert Electric Fireplace:** Carefully place the electric fireplace unit into its designated opening. Secure it according to the instructions.
5. **Assemble and Attach Drawers and Doors:** Construct the drawers and sliding barn doors, then install them onto the main frame.
6. **Install LED Light Strip:** Adhere the LED strip to the designated area on the floating base and connect the controller.
7. **Attach Anti-Tip Hardware:** Secure the TV stand to the wall using the provided anti-tip kit.

3. Operating Instructions

3.1 Electric Fireplace Operation

The 36-inch electric fireplace can be controlled via the included remote control or the control panel on the unit.



Image: Close-up of the 36-inch electric fireplace unit, showing the flame effect, control panel, and remote control.

- **Power On/Off:** Press the power button on the remote or control panel.
- **Flame Settings:** Adjust flame brightness (4 levels) and color options (14 colors) using the dedicated buttons. The flame effect can operate independently of the heat.
- **Heat Settings:** The 1500W heater provides adjustable temperature control from 65°F to 95°F (18°C to 35°C). It can warm rooms up to 400 sq ft.
- **Timer Function:** Set an automatic shut-off timer from 0 to 8 hours.
- **Sleep Mode:** Activates a quiet operation mode (less than 50dB).
- **Memory Function:** The fireplace remembers your last settings when powered off and on.
- **Overheat Protection:** The unit will automatically shut off if it detects overheating, ensuring safe operation.

3.2 LED Floating Light Operation

The integrated LED light strip on the floating base enhances the ambiance of your living space.



Image: The Jocoevol TV stand with its base illuminated by various LED colors, demonstrating the multiple lighting options.

- **Control:** Use the included remote control or a compatible mobile app to manage the LED lights.
- **Color Options:** Choose from over 60,000 colors and various preset lighting effects.
- **Brightness:** Adjust the intensity of the LED glow to suit your preference.
- **Music Sync:** The lights can synchronize with music beats for dynamic effects (check app features for availability).

3.3 Storage Features

The TV stand offers various storage solutions to keep your living area organized.



Image: A close-up view of one of the open storage drawers, showing space for remotes, glasses, and other small items.

- **Drawers:** Two smooth-gliding drawers provide concealed storage for remotes, chargers, and other small items.
- **Sliding Barn Doors:** Two sliding doors offer flexible access to the side cabinets, concealing or revealing items as needed.
- **Adjustable Shelves:** The side cabinets feature dual-layer adjustable shelves, allowing you to customize storage space for various media devices or decor.

4. Maintenance

- **Cleaning the TV Stand:** Dust regularly with a soft, dry cloth. For deeper cleaning, use a slightly damp cloth with a mild, non-abrasive cleaner. Avoid harsh chemicals that may damage the finish.
- **Cleaning the Electric Fireplace:** Ensure the fireplace is unplugged and cool before cleaning. Wipe the exterior with a soft, damp cloth. Do not spray water directly onto the unit. Keep the air intake and exhaust vents clear of dust and debris.
- **Drawer and Door Maintenance:** Periodically check drawer slides and door tracks for smooth operation. Clean any accumulated dust or debris.

- **Electrical Safety:** Regularly inspect the power cord for any damage. Do not use the fireplace if the cord is damaged.

5. Troubleshooting

Problem	Possible Cause	Solution
Electric fireplace does not turn on.	No power, power switch off, remote battery dead.	Ensure unit is plugged in and outlet is functional. Check the main power switch on the unit. Replace remote batteries.
No heat output.	Heat function not activated, temperature set too low, overheat protection triggered.	Activate heat function via remote/panel. Increase target temperature. Unplug unit for 5 minutes to reset overheat protection, then ensure vents are clear.
LED lights not working.	Power connection loose, remote battery dead, controller issue.	Check LED strip and controller connections. Replace remote batteries.
Drawers or doors stick/do not slide smoothly.	Misalignment, debris in tracks, damaged hardware.	Check assembly for proper alignment. Clean tracks. Inspect hardware for damage.

6. Specifications



Image: Detailed diagram showing the overall dimensions of the Jocoevol 70-inch Fireplace TV Stand and its components.

Model Number	JOC-C-1615
Overall Dimensions (W x D x H)	70.1" x 13.8" x 30.9"
Weight	Approximately 104.2 lbs
Material	Engineered Wood
Electric Fireplace Size	36 inches
Heat Output	1500W (4777 BTU)
Heating Coverage	Up to 400 sq ft
Temperature Range	65°F - 95°F

Power Source	Corded Electric
Maximum TV Size Supported	Up to 75 inches
Tabletop Weight Capacity	300 lbs

7. Warranty and Support

7.1 Manufacturer's Warranty

This Jocoevol Fireplace TV Stand comes with a**1-Year Manufacturer's Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

7.2 Customer Support

If you have any questions about assembly, operation, missing parts, or warranty claims, please contact Jocoevol customer support. Refer to your purchase documentation or the brand's official website for contact information.

When contacting support, please have your model number (JOC-C-1615) and purchase details ready.

© 2023 Jocoevol. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GRVJM3DW

More documents and user manuals: **https://manuals.plus/**