Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dragon Touch Frameo 10.1 Inch

Dragon Touch Frameo 10.1 Inch Smart Wi-Fi Digital Picture Frame User Manual

Model: Frameo 10.1 Inch

Introduction

Welcome to the user manual for your Dragon Touch Frameo 10.1 Inch Smart Wi-Fi Digital Picture Frame. This device allows you to instantly share photos and videos with loved ones from anywhere in the world using the Frameo app. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your digital picture frame to ensure a seamless experience.

Setup

1. Unboxing and Physical Setup

Carefully remove all components from the packaging. The frame comes with a detachable stand. Insert the stand into the designated groove on the back of the frame to position it securely on a flat surface.



Image: The digital picture frame with its stand, ready for placement.

2. Powering On

Connect the power adapter to the frame and plug it into an electrical outlet. The frame will automatically power on.

3. Initial Configuration and Wi-Fi Connection

Follow the on-screen prompts to select your language, time zone, and connect the frame to your Wi-Fi network. A stable Wi-Fi connection is crucial for photo sharing.

4. Downloading the Frameo App

Download the free Frameo app on your smartphone or tablet. It is available on both the Apple App Store and Google Play Store. Search for "Frameo" to find the official application.



Image: Instructions for downloading the Frameo app from the App Store and Google Play.

5. Connecting the App to Your Frame

Open the Frameo app and create an account. On your digital frame, navigate to the 'Add Friend' section to get a unique code. Enter this code into the Frameo app on your device to link them. You can then invite family and friends to connect to your frame using the same method, allowing them to share photos and videos remotely.

Operating Instructions

1. Viewing Photos and Videos

The frame features a responsive touchscreen. Swipe left or right to manually navigate through photos and videos. The frame will automatically cycle through uploaded content in a slideshow format.



Image: A hand interacting with the touchscreen to view images.

2. Sending Photos and Videos via App

Using the Frameo app, you can select photos and short videos from your device and send them directly to your connected digital frame. You can also add captions to your memories before sending.



Image: A visual guide on how to customize and send photos using the Frameo app.

3. Customizing Slideshow Settings

Access the frame's settings menu to personalize your slideshow experience. Options include:

- **Slideshow Speed:** Adjust how long each photo is displayed.
- **Display Modes:** Choose how photos are presented (e.g., fit to frame, fill frame).
- **Background Music:** Enable or disable background music during slideshows.
- **Shuffle:** Randomize the order of photos.

4. Managing Photos and Frame Features

The frame's interface allows for various management functions:

- **Organize Photos:** Create albums to categorize your memories.
- **React to Pictures:** Use the reaction feature to send feedback on photos.
- **Hide/Delete Photos:** Remove unwanted photos from the display.
- **Calendar and Weather:** The frame can display calendar information and local weather forecasts.
- **Alarms:** Set alarms directly from the frame's settings.



Image: Overview of the Frameo app's features for photo management and interaction.

5. Expanding Storage

The frame has 16GB of internal storage, expandable up to 32GB via a microSD card. Insert a microSD card into the designated slot to increase storage capacity for more photos and videos. Note that the microSD card slot may require tweezers for easy removal.

Maintenance

1. Cleaning the Frame

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid using harsh chemicals or abrasive materials. Clean the frame's exterior with a dry, soft cloth.

2. Software Updates

Ensure your frame is connected to Wi-Fi to receive automatic software updates. These updates provide new features, performance improvements, and bug fixes. You can check for updates manually in the frame's settings menu.

Troubleshooting

Common Issues and Solutions:

- **Frame Not Powering On:** Ensure the power adapter is securely connected to both the frame and a working electrical outlet.
- **Wi-Fi Connection Issues:** Check your router and ensure the Wi-Fi password is entered correctly. Try restarting both the frame and your router.
- **Photos Not Appearing:** Verify that photos have been successfully sent from the Frameo app. Ensure the frame is connected to Wi-Fi.
- **Screen Flickering/Oscillating:** If the display appears unstable, try restarting the frame. If the issue persists, ensure the power supply is stable and consider contacting support.
- **MicroSD Card Ejection:** The microSD card slot may not have an eject button. Use a pair of tweezers to carefully remove the card if needed.
- **App Connection Problems:** Ensure both your phone and the frame have a stable internet connection. Re-enter the frame code if necessary.

Specifications

Feature	Detail
Brand	Dragon Touch
Model	Frameo 10.1 Inch
Screen Size	10.1 inches
Resolution	WXGA+ (1280x800 HD)
Aspect Ratio	16:9
Connectivity Technology	Wi-Fi
Memory Storage Capacity	16GB internal (expandable up to 32GB via microSD)
Control Method	App, Touchscreen
Power Source	Corded Electric
Item Dimensions (L x W)	10.53"L x 7.33"W
UPC	850080617465
ASIN	B0GTLPX5LC

Warranty Information

This Dragon Touch Frameo Digital Picture Frame is covered by a**2-Year Manufacturer Warranty**. Please retain your

proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty documentation included with your product or visit the official Dragon Touch website.

Support

For further assistance, technical support, or inquiries, please utilize the following resources:

- **Frameo App:** The Frameo application often includes a help section or FAQs.
- **Dragon Touch Website:** Visit the official Dragon Touch website for product support, FAQs, and contact information.
- **Customer Service:** Refer to the contact details provided in your product packaging for direct customer service.

© 2024 Dragon Touch. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GTLPX5LC

More documents and user manuals: **https://manuals.plus/**