Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy AH-KZG27BS-4GY-RC

Sweetcrispy Air Fryer 4 Quart with Window

Model: AH-KZG27BS-4GY-RC

User Manual

Introduction

Thank you for choosing the Sweetcrispy Air Fryer. This appliance uses rapid air circulation technology to cook your favorite foods with little to no oil, resulting in delicious, crispy results. Please read this manual thoroughly before use to ensure safe and optimal operation.

Important Safeguards

- Always place the appliance on a stable, heat-resistant surface.
- Do not immerse the cord, plug, or appliance in water or other liquids.
- Keep the appliance and its cord out of reach of children.
- Do not block any air vents. Ensure adequate space around the appliance during operation.
- Unplug the air fryer when not in use and before cleaning.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions.
- Exercise extreme caution when removing the basket during cooking, as hot steam may escape.
- This appliance is for household use only.

Product Overview

Familiarize yourself with the components of your Sweetcrispy Air Fryer.



Image: The Sweetcrispy Air Fryer features a clear viewing window to monitor cooking progress without opening the basket. The digital control panel is located on top.

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Digital display with touch controls for temperature, time, and presets.
- **Viewing Window:** Allows you to observe food during cooking.
- **Air Fryer Basket:** Removable, non-stick basket for holding food.
- **Crisper Plate:** Sits inside the basket to allow air circulation around food.
- **Handle:** For safely pulling out and inserting the air fryer basket.

Setup and First Use

Unpacking

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Check that all components are present and undamaged.

Cleaning Before First Use

1. Wash the air fryer basket and crisper plate with hot water, dish soap, and a non-abrasive sponge.
2. Wipe the inside and outside of the main unit with a damp cloth.
3. Ensure all parts are completely dry before use.

Initial Operation (Burn-in)

It is recommended to run the air fryer empty for about 10 minutes on its first use to eliminate any manufacturing odors.

1. Place the crisper plate into the basket, then insert the basket into the air fryer.
2. Plug the air fryer into a grounded electrical outlet.
3. Set the temperature to 400°F (200°C) and the timer to 10 minutes.
4. Allow the appliance to run. A slight odor may be present, which is normal.
5. After 10 minutes, unplug the air fryer and let it cool completely.

Operating Instructions

General Use

1. Place the crisper plate into the air fryer basket.
2. Place ingredients into the air fryer basket. Do not overfill.
3. Slide the basket back into the air fryer.
4. Plug in the appliance. The power button will illuminate.
5. Press the power button to turn on the display.



Image: The digital control panel features 8 preset options for common foods like chips, wings, steak, and fish, simplifying cooking.

Using Presets

- Press the 'MENU' button repeatedly to cycle through the 8 preset cooking functions (Chips, Wings, Steak, Fish, Shrimp, Pizza, Bake, DIY).
- Once a preset is selected, the corresponding icon will flash, and the default time and temperature will display.
- You can adjust the time and temperature using the '+' and '-' buttons if desired.
- Press the power button to start cooking.

Manual Cooking

- After pressing the power button, use the 'TEMP/TIME' button to switch between temperature and time settings.
- Use the '+' and '-' buttons to adjust the desired temperature (up to 400°F) and cooking time (up to 60 minutes).
- Press the power button to start cooking.

Shake Reminder

For certain foods, the air fryer will emit a 'SHAKE' reminder halfway through the cooking cycle. This prompts you to shake or flip the food for even cooking and crispiness.

- When the 'SHAKE' icon appears and the buzzer sounds, carefully pull out the basket.
- Shake the basket or use tongs to flip the food.
- Slide the basket back into the air fryer. Cooking will resume automatically.

Viewing Window and Internal Light

The integrated viewing window and internal light allow you to monitor your food without interrupting the cooking process. Press the 'LIGHT' button on the control panel to turn the internal light on or off.

Preheating

For best results, preheating is recommended for most recipes.

- Press the 'PREHEAT' button.
- Adjust the desired temperature using the '+' and '-' buttons.
- Press the power button to start preheating. The air fryer will beep when preheating is complete.
- Add your food to the basket and resume cooking with your desired settings.

Cooking Completion

When the timer reaches zero, the air fryer will beep, and the display will show "END".

- Carefully pull out the basket using the handle.
- Empty the food onto a plate. Use tongs or a spatula to remove food, avoiding direct contact with the hot basket.
- Unplug the appliance and allow it to cool before cleaning.

▶ **Watch video online**
Sweetcrispy Air Fryer

Video: An overview of the Sweetcrispy Air Fryer's features and how it can be used to prepare various meals.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your air fryer.

Cleaning the Basket and Crisper Plate



Image: The non-stick air fryer basket and crisper plate are dishwasher safe for easy cleaning.

- Always unplug the air fryer and allow it to cool completely before cleaning.
- The non-stick basket and crisper plate are dishwasher safe. You can also wash them by hand with hot water, dish soap, and a non-abrasive sponge.
- For stubborn food residue, soak the basket and plate in warm, soapy water for about 10 minutes.
- Do not use metal utensils or abrasive cleaning materials, as this can damage the non-stick coating.

Cleaning the Main Unit

- Wipe the exterior of the air fryer with a damp cloth.
- Clean the interior with a damp cloth and mild detergent if necessary. Avoid getting water into the electrical components.
- Clean the heating element with a cleaning brush to remove any food residue.
- Ensure all parts are dry before storing or using again.

Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; power outlet malfunction; basket not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Push the basket firmly into the unit until it clicks.
Food is not cooked evenly.	Basket is overcrowded; food not shaken/flipped.	Cook in smaller batches. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; high-fat ingredients.	Clean the basket and crisper plate thoroughly. For high-fat foods, drain excess oil from the bottom of the basket.
Food is not crispy.	Insufficient cooking time/temperature; too much moisture.	Increase cooking time or temperature. Pat food dry before air frying.

Specifications

- **Model:** AH-KZG27BS-4GY-RC
- **Capacity:** 4.23 Quarts (4 Liters)
- **Power:** 1500 Watts
- **Voltage:** 120V, 60Hz (Standard US)
- **Temperature Range:** Max 400°F (200°C)
- **Timer:** Up to 60 minutes
- **Dimensions (D x W x H):** 10.24" x 13.31" x 12.99"
- **Weight:** 6.77 Pounds
- **Material:** Polypropylene (PP)
- **Special Features:** Viewing Window, Digital Touch Control, 8 Presets, Shake Reminder, Auto Shut-Off, Overheat Protection, Non-stick Coating, Dishwasher Safe Basket.



Image: The compact design of the air fryer, with dimensions 10.24"D x 13.31"W x 12.99"H, allows for easy storage.

Warranty and Support

Sweetcrispy products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Sweetcrispy website.

Please retain your proof of purchase for any warranty claims.

For additional support, you may visit the Sweetcrispy Store on Amazon.

© 2026 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why does the preheat button on my Sweetcrispy AH-KZG27BS-4GY-RC air fryer not respond, and how can I stop the automatic preheating?

Based on the manual for the Sweetcrispy AH-KZG27BS-4GY-RC, the preheat function requires a specific sequence to activate. If the button seems unresponsive or the unit is behaving unexpectedly, please follow these steps: Correct Activation...

Read full answer

Open the live page

https://manuals.plus/asin/B0GV4GGP51

More documents and user manuals: **https://manuals.plus/**