**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Garvee TVECB**

# Garvee 55-inch Outdoor TV Enclosure Instruction Manual

Model: TVECB

## 1. Introduction

This manual provides essential instructions for the safe and effective installation, operation, and maintenance of your Garvee 55-inch Outdoor TV Enclosure. This enclosure is designed to protect televisions ranging from 44 to 55 inches from outdoor elements, featuring a solid wood construction, a fold-up door, and a 4D adjustable TV mount.

## 2. What's in the Box

Carefully unpack all components and verify that you have received the following items:

- TV Enclosure
- Telescopic Bracket (4D Adjustable TV Mount)
- Dust-Resistant Cover
- Installation Hardware Kit



Image: All components included with the Garvee Outdoor TV Enclosure.

## 3. Safety Information

Please read and understand all safety instructions before installation and use. Failure to follow these instructions may result in property damage or injury.

- **Weight Capacity:** Ensure your television's weight does not exceed the mount's specified capacity.
- **Secure Mounting:** Always install the enclosure on a solid, structurally sound surface capable of supporting the combined weight of the enclosure and your television.
- **Electrical Safety:** Ensure all electrical connections for your TV are weatherproof and comply with local electrical codes.
- **Ventilation:** Do not obstruct ventilation openings on the enclosure or your television.
- **Children and Pets:** Keep children and pets away from the installation area during setup and ensure the enclosure is securely closed when not in use.

## 4. Setup and Installation

The Garvee Outdoor TV Enclosure is designed for installation on solid surfaces such as brick, stone, wood, or concrete. Do not mount on hollow or unstable walls. All necessary hardware and clear instructions are provided for a straightforward setup.

### 4.1 Wall Mount Installation

1. **Select Location:** Choose a suitable outdoor location on a solid wall, ensuring adequate clearance for the fold-up door.
2. **Mark Drilling Points:** Use the provided template or the mount itself to mark the drilling points on the wall.
3. **Drill Holes:** Drill pilot holes according to the marked points and insert wall anchors if required for your wall type.
4. **Attach Mount:** Securely attach the telescopic bracket (4D adjustable TV mount) to the wall using the provided screws. Ensure it is level and firmly fixed.




Image: Professional TV Wall Mount with 4D adjustable angle and telescopic bracket.

### 4.2 TV and Enclosure Installation

1. **Attach TV Brackets:** Attach the TV mounting brackets to the back of your television.
2. **Mount TV:** Carefully lift and hook your TV onto the wall mount. Secure it with the safety screws.
3. **Install Enclosure:** Position the Garvee TV Enclosure around the mounted TV and secure it to the wall according to the detailed instructions in the hardware kit. Ensure the enclosure is level and the fold-up door operates smoothly.




Image: Weatherproof Outdoor TV Enclosure protecting a television from rain.

## 5. Operating Instructions

### 5.1 Opening and Closing the Fold-Up Door

The enclosure features a convenient fold-up door with gas struts for smooth operation. To open, gently pull the reinforced handle downwards. The gas struts will assist in lifting the door to its open position. To close, gently pull the door downwards until it latches securely. Avoid forcing the door.




Image: Detail of the fold-up door and handle for the Garvee Outdoor TV Enclosure.

## 5.2 Adjusting the TV Viewing Angle

The integrated 4D adjustable mount allows for flexible positioning of your TV. You can extend the TV forward, backward, left, and right, as well as tilt and swivel it to achieve optimal viewing angles. Adjust the TV carefully by hand to your desired position.




Image: Wide available view range up to 178 degrees with the Garvee Outdoor TV Enclosure.

### 5.3 Using the Dust Cover

For additional protection against debris and moisture when the TV is not in use, place the included dust-resistant cover over the entire enclosure. This is especially recommended during prolonged periods of inactivity or severe weather conditions.

## 6. Maintenance

Regular maintenance will ensure the longevity and performance of your Garvee Outdoor TV Enclosure.

- **Cleaning:** Wipe the exterior of the enclosure with a soft, damp cloth. Avoid abrasive cleaners or solvents that may damage the weatherproof finish.
- **Inspect Seals:** Periodically check the seals around the door and edges for any signs of wear or damage to ensure continued weather resistance.
- **Hardware Check:** Annually inspect all mounting hardware and screws for tightness. Tighten if necessary.

- **Gas Struts:** Ensure the gas struts operate smoothly. If they become stiff or lose their lifting power, they may require replacement.

## 7. Troubleshooting

If you encounter issues with your Garvee Outdoor TV Enclosure, refer to the following common solutions:

- **Door Does Not Latch Securely:** Check for any obstructions preventing the door from closing fully. Ensure the enclosure is mounted level. Inspect the latch mechanism for damage or misalignment.
- **Handle Feels Loose:** Tighten the screws securing the handle. If the handle is damaged, contact customer support for a replacement.
- **Water Inside Enclosure:** Verify that all seals are intact and properly seated. Ensure the enclosure is correctly installed and no gaps exist between the enclosure and the wall. Check for any damage to the enclosure's weatherproof finish.
- **TV Mount Movement Issues:** Ensure all mount screws are tightened. If the mount feels unstable, re-check the wall installation for proper anchoring.

## 8. Specifications

| Feature | Detail |
|---|---|
| Brand | Garvee |
| Model Number | TVECB |
| Compatible TV Size | 44-55 Inches |
| Exterior Dimensions (L x W) | 54.76"L x 31.77"W |
| Interior Dimensions (W x H x D) | 54.78"W x 31.77"H x 7.48"D |
| Material | Solid Wood |
| Color | Classic Black |
| Finish Type | Matte |
| Special Features | Full Coverage, Weatherproof, Fold-Up Door, 4D Adjustable Mount |
| Item Weight | 57.8 Pounds |
| UPC | 824126300048 |



Image: Garvee Outdoor TV Enclosure showing compatibility with 44-55 inch TVs and key dimensions.

## 9. Warranty Information

The Garvee Outdoor TV Enclosure comes with a**30-day warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for any warranty claims.

## 10. Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official Garvee Store on Amazon:

**Visit the Garvee Store**

© 2026 Garvee. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0GXV7X95Q**

More documents and user manuals: **https://manuals.plus/**