Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lehwey CD8-US

Lehwey Retro Vertical Portable CD Player

Model: CD8-US User Manual

1. Important Safety Instructions

Please read all instructions carefully before using this product and retain them for future reference. Follow all warnings and instructions marked on the product.

- Do not expose this appliance to rain or moisture.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the appliance.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this appliance during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.

2. Package Contents

Please check that all items are present and in good condition upon unpacking.



Image: All items included in the package, neatly arranged.

- Lehwey Portable CD Player
- Remote Control (2 AAA batteries not included)
- Type-C Charging Cable
- 5V-2A USB Adapter
- 3.5mm AUX Cable
- User Manual

3. Product Overview

Familiarize yourself with the components and controls of your Lehwey CD Player.



Image: Detailed diagram showing the front, top, and side controls and ports of the CD player.

1. **Mode (Press Button)/Volume (Rotate)**: Press to cycle through modes (CD, Bluetooth, FM, USB, AUX, SPDIF). Rotate to adjust volume.
2. **Play/Pause Button**: Press to play or pause playback.
3. **Next Track Button**: Press to skip to the next track/station.
4. **Previous Track Button**: Press to go to the previous track/station.
5. **Bluetooth Connection Button**: Press and hold to enter Bluetooth pairing mode.
6. **Built-in Dual Speakers**: Provides stereo audio output.
7. **Dustproof Cover**: Protects the CD tray from dust.
8. **Music Fiber Optics (SPDIF) Port**: For digital audio output.
9. **Headphone Jack**: For connecting wired headphones (3.5mm).
10. **AUX Socket**: For connecting external audio devices via 3.5mm AUX cable.
11. **USB Port**: For playing audio files from a USB flash drive.
12. **DC IN 5V (Type-C)**: Power input port.

13. **Power Switch**: Slide to turn the unit ON or OFF.
14. **Turntable Arm Switch**: Used to activate CD playback when a CD is inserted.

Your browser does not support the video tag.

Video: A brief demonstration of the Lehwey Retro CD Player, showcasing its design and basic operation.

4. Setup

4.1 Power Connection

1. Connect the Type-C end of the charging cable to the **DC IN 5V** port (12) on the back of the CD player.
2. Connect the USB-A end of the charging cable to the provided 5V-2A USB Adapter.
3. Plug the USB Adapter into a standard wall outlet.

Image: A white Type-C cable plugged into the power input port of the CD player.

4.2 Powering On/Off

Slide the **Power Switch** (13) located on the back of the unit to the 'ON' position to power on the device. Slide it to 'OFF' to power off.

5. Operating Modes

Press the **Mode/Volume** button (1) to cycle through the available modes.

5.1 CD Mode

1. Open the **Dustproof Cover** (7).
2. Place a CD (compatible formats: CD, CD-R, CD-RM, CD-G, MP3, WMA, WAV) onto the spindle with the label side facing up.
3. Close the **Dustproof Cover** (7).
4. Gently move the **Turntable Arm Switch** (14) over the CD. The player will automatically detect the CD and begin playback.
5. Use the **Play/Pause** (2), **Next** (3), and **Previous** (4) buttons to control playback.

5.2 Bluetooth Receiver Mode

In this mode, the CD player acts as a Bluetooth speaker, receiving audio from your smartphone or other Bluetooth devices.

1. Switch the CD player to Bluetooth mode. The LED indicator will flash blue.
2. On your smartphone or Bluetooth device, search for Bluetooth devices and select "Lehwey CD Player" to pair.
3. Once connected, the LED indicator will be solid blue. You can now stream audio from your device.

5.3 Bluetooth Transmitter Mode

In this mode, the CD player transmits audio to Bluetooth headphones or speakers.

1. Ensure your Bluetooth headphones/speaker are in pairing mode.
2. While in CD, USB, or AUX mode, press and hold the **Bluetooth Connection Button** (5) on the CD player. The LED indicator will flash blue rapidly.
3. The CD player will automatically search for and connect to nearby Bluetooth audio devices. Once connected, the LED indicator will be solid blue.



Image: A woman enjoying music through Bluetooth headphones, connected wirelessly to the CD player.

5.4 FM Radio Mode

1. Switch the CD player to FM Radio mode.
2. Press the **Play**/**Pause** button (2) once to auto-scan and save available FM stations (frequency range: 76MHz-108MHz).
3. Use the **Next** (3) and **Previous** (4) buttons to navigate through saved stations.

5.5 USB Mode

1. Insert a USB flash drive into the **USB Port** (11).
2. Switch the CD player to USB mode. The player will automatically detect and begin playing compatible audio files (MP3, WMA, WAV).
3. Use the **Play**/**Pause** (2), **Next** (3), and **Previous** (4) buttons to control playback.

Image: A USB flash drive plugged into the USB port on the side of the CD player.

5.6 AUX Mode

1. Connect one end of the 3.5mm AUX cable to the **AUX Socket** (10) on the CD player.
2. Connect the other end to the audio output of an external device (e.g., smartphone, MP3 player).
3. Switch the CD player to AUX mode. Audio from the external device will now play through the CD player's speakers.

Image: A white 3.5mm AUX cable plugged into the AUX input port of the CD player.

5.7 SPDIF Mode

Connect a fiber optic cable (not included) from the **Music Fiber Optics (SPDIF) Port** (8) on the CD player to a compatible audio receiver or sound system for digital audio output.

6. Playback Options

The CD player offers various playback options, accessible via the remote control.

- **A-B Repeat**: Repeats a specific section of a track. Press the A-B button at the start point (A) and again at the end point (B).
- **Single Loop**: Repeats the current track.
- **Full Disc Loop**: Repeats all tracks on the current disc/USB.
- **Random Play**: Plays tracks in a random order.

7. Remote Control

The included remote control allows for convenient operation from a distance (up to 5 meters).



Image: A family relaxing on a couch, using the remote control to operate the CD player placed on a shelf.

Note: The remote control requires 2 x AAA batteries (not included). Please insert them according to the polarity markings inside the battery compartment.

Functions include: Power On/Off, Mode Selection, Play/Pause, Skip Tracks, Volume Up/Down, Mute, Repeat Modes (A-B, Single, All), Random Play, FM Scan.

8. Sleep Mode

The sleep mode is designed for relaxing bedtime moments, suitable for playing audiobooks or soothing lullabies. To activate sleep mode, press the 'Sleep' button on the remote control. The player will automatically turn off after a set period (refer to remote control markings or product specifications for default timing, usually 30, 60, 90 minutes).

9. Maintenance

9.1 Cleaning

- Wipe the exterior of the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- To clean the CD lens, use a commercially available CD lens cleaner disc.

9.2 CD Handling

- Always hold CDs by their edges.
- Keep CDs clean and free from scratches. Store them in their cases when not in use.

10. Troubleshooting

Problem	Possible Cause	Solution
No power	Power cable not connected; Power switch off	Ensure power cable is securely connected; Turn power switch ON
CD not playing	CD inserted incorrectly; CD dirty/scratched; Turntable arm not engaged	Reinsert CD correctly; Clean or replace CD; Ensure turntable arm is over the CD
No sound	Volume too low; Mute activated; Incorrect mode selected	Increase volume; Deactivate mute; Select correct input mode
Bluetooth pairing fails	Device too far; CD player not in pairing mode; Other device already connected	Move devices closer; Ensure CD player is in Bluetooth pairing mode; Disconnect from other devices
Remote control not working	Batteries low/incorrectly inserted; Obstruction between remote and player	Replace batteries, check polarity; Remove obstructions; Ensure line of sight

11. Specifications

Feature	Description
Brand	Lehwey
Model Number	CD8-US
Color	Brown
Connectivity Technology	Bluetooth, USB, AUX, SPDIF
Special Features	Built-In FM Radio, Portable, Wireless, Dual Speakers
Supported Audio Formats	CD, CD-R, CD-RM, CD-G, MP3, WMA, WAV
FM Frequency Range	76MHz-108MHz
Connector Type	3.5mm Jack (AUX, Headphone), USB, Type-C (Power), SPDIF
Number of Channels	2 (Stereo)
Item Dimensions (L x W x H)	7.8" x 6.3" x 3.3" (19.8cm x 16cm x 8.4cm)
Item Weight	850 g (1.87 lbs)
Power Input	DC 5V

12. Warranty and Support

This Lehwey CD Player comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For warranty claims, technical support, or any questions regarding your product, please contact the seller through your purchase platform or refer to the contact information provided with your product packaging.

© 2023 Lehwey. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GYDHC7CG

More documents and user manuals: **https://manuals.plus/**