Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KRUPS EA879NE0

KRUPS Intuition Experience EA879NE0 Automatic Coffee Machine User Manual

Model: EA879NE0

1. Introduction

Welcome to the KRUPS Intuition Experience EA879NE0. This automatic coffee machine is designed to provide a wide range of hot and cold coffee beverages, from classic espressos to innovative cold brews and iced lattes. This manual will guide you through the setup, operation, and maintenance of your new appliance to ensure optimal performance and enjoyment.



Image 1.1: The KRUPS Intuition Experience EA879NE0 coffee machine, showcasing its ability to prepare both hot and cold beverages.

2. Important Safety Instructions

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- Ensure the voltage indicated on the appliance corresponds to your mains voltage.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Close supervision is necessary when any appliance is used by or near children.
- Use only accessories recommended by the manufacturer.
- The appliance is for household use only.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control

to "off", then remove the plug from the wall outlet.

3. Package Contents

Verify that all components are present and in good condition upon unpacking.

- KRUPS Intuition Experience EA879NE0 Automatic Coffee Machine
- Milk Container
- Water Filter Cartridge (Claris Aqua)
- Cleaning Tablets
- Descaling Powder
- Cleaning Brush
- User Manual (this document)



Image 3.1: The coffee machine alongside its essential accessories for setup and maintenance.

4. Initial Setup

Follow these steps to prepare your coffee machine for first use.

1. **Unpacking:** Carefully remove the machine and all accessories from the packaging. Place the machine on a stable, flat surface.
2. **Water Tank:** Remove the 3-liter water tank from the back of the machine. Rinse it thoroughly with fresh water.
3. **Install Water Filter:** Insert the Claris Aqua filter cartridge into the water tank as per the filter instructions. Fill the tank with fresh water up to the MAX level and reinsert it into the machine.
4. **Bean Hopper:** Open the lid of the bean hopper located on top of the machine. Pour fresh coffee beans into the hopper. Do not use ground coffee in the bean hopper.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.
6. **First Start-up:** Turn on the machine using the power button. The display will guide you through the initial setup process, including language selection and a rinsing cycle. Follow the on-screen instructions.

5. Operating Instructions

Your KRUPS Intuition Experience offers a wide array of hot and cold beverages. The TFT touchscreen display provides intuitive control.

5.1 Navigating the Touchscreen Display

The machine features a TFT touchscreen for easy selection and customization of beverages.



Image 5.1: The intuitive touchscreen interface for selecting and customizing drinks.

- **Home Screen:** Displays various beverage categories (Coffee, Latte, Iced, To Go).
- **Selection:** Tap on a beverage icon to select it.
- **Customization:** After selection, you can adjust parameters like coffee strength, volume, and milk quantity.
- **User Profiles:** Create and save personalized beverage settings for different users.

5.2 Preparing Hot Coffee Beverages

The machine can prepare 36 hot and cold beverages, including Ristretto, Espresso, Lungo, and more.

1. Ensure the water tank is filled and the bean hopper contains coffee beans.
2. Place your cup(s) under the coffee spout. The spout is height-adjustable (up to 13.8 cm) to accommodate various cup sizes.
3. Select your desired hot coffee beverage from the touchscreen.
4. Customize settings if desired (e.g., strength, volume).
5. Press the "Start" button to begin brewing.



Image 5.2: Coffee being brewed directly into a cup, demonstrating the adjustable spout.

5.3 Using the One-Touch Milk System

The One Touch Milk Advanced technology automatically prepares silky milk-based drinks like Cappuccino and Latte Macchiato.

1. Fill the milk container with fresh milk.
2. Connect the milk tube from the container to the milk frother on the machine.

3. Place your cup(s) under the coffee and milk spouts.
4. Select a milk-based beverage (e.g., Cappuccino, Latte Macchiato) from the touchscreen.
5. Customize settings if desired. The machine can prepare two cappuccinos simultaneously.
6. Press "Start". The machine will automatically froth and dispense milk, then brew coffee.
7. After use, the machine will prompt for a milk system rinse. Follow the on-screen instructions.



Image 5.3: The machine with the milk container attached, illustrating the milk frothing system.



Image 5.4: Two milk-based coffees being prepared simultaneously.

5.4 Preparing Cold Brew and Iced Beverages

The patented Cold Brew Aroma technology allows for the preparation of perfect cold beverages with rich flavor and aroma.

1. Ensure the water tank is filled and the bean hopper contains coffee beans.
2. Place a glass filled with ice under the coffee spout.
3. Select an "Iced" beverage option (e.g., Iced Latte, Cold Brew, Nitro Coffee) from the touchscreen.
4. Customize settings if desired.
5. Press "Start". The machine will perform a multi-stage process, including pre-infusion and cold extraction, to create your iced drink.



Image 5.5: Cold brew coffee being dispensed, ready to be enjoyed.

6. Maintenance and Cleaning

Regular maintenance ensures the longevity and optimal performance of your coffee machine. The machine features automatic cleaning, rinsing, and descaling programs.

6.1 Daily Cleaning

- **Drip Tray and Coffee Grounds Container:** Empty and rinse the drip tray and coffee grounds container daily.
- **Milk System:** Always perform the automatic milk system rinse after preparing milk-based beverages. Regularly disassemble and clean the milk tube and frother components with warm soapy water.
- **Water Tank:** Rinse the water tank regularly with fresh water.
- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth.

6.2 Cleaning Program

The machine will prompt you when a cleaning cycle is required. Use the provided cleaning tablets.

1. Follow the on-screen instructions when the cleaning alert appears.
2. Place a container under the coffee spout.
3. Insert a KRUPS cleaning tablet into the designated slot (usually in the coffee grounds container or a bypass doser).
4. Start the cleaning program. The machine will perform several rinsing cycles.

6.3 Descaling Program

The descaling program removes mineral deposits that can affect machine performance. The frequency depends on water hardness and usage. Use the provided descaling powder.

1. When the descaling alert appears, follow the on-screen instructions.
2. Empty the water tank and dissolve the descaling powder in fresh water as instructed.
3. Pour the descaling solution into the water tank and reinsert it.
4. Place a large container under the coffee spout and steam nozzle.
5. Start the descaling program. The process will take some time and involve several rinsing cycles.
6. After the program, rinse the water tank thoroughly and fill it with fresh water for a final rinse cycle.

6.4 Water Filter Replacement

The Claris Aqua filter should be replaced regularly (approximately every 2-3 months or as indicated by the machine) to ensure optimal water quality and reduce descaling frequency.

1. Remove the old filter from the water tank.
2. Insert a new Claris Aqua filter cartridge according to the instructions provided with the filter.
3. Activate the new filter in the machine's settings menu.

7. Troubleshooting

If you encounter issues with your coffee machine, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No coffee is dispensed.	Water tank empty, coffee beans empty, brewing unit blocked.	Fill water tank, fill bean hopper, perform a cleaning cycle.
Coffee is too weak or watery.	Grind setting too coarse, insufficient coffee dose, old coffee beans.	Adjust grind setting finer, increase coffee strength, use fresh beans.
Milk does not froth properly.	Milk system dirty, milk too warm, wrong type of milk.	Clean the milk system thoroughly, use cold milk (preferably semi-skimmed), ensure milk tube is correctly connected.
Machine displays "Descale" message.	Mineral buildup in the system.	Perform the descaling program as described in section 6.3.
Machine is noisy.	Air in the water system, normal grinding noise.	Run a hot water cycle to prime the pump. Grinding noise is normal.

If the problem persists after attempting these solutions, please contact KRUPS customer support.

8. Technical Specifications

Feature	Detail
Model Number	EA879NE0
Brand	KRUPS
Capacity	3 Liters (Water Tank)
Color	Black
Dimensions (D x W x H)	24 cm x 40 cm x 36.3 cm
Special Features	Automatic shut-off, Height-adjustable spout, Removable tank, Milk frother, Integrated coffee grinder
Coffee Maker Type	Bean-to-cup
Material	Stainless Steel, Acrylonitrile Butadiene Styrene (ABS)
Operation	Fully Automatic
Power	1550 Watts
Voltage	220-240 Volts
Input Interface	Buttons, Touchscreen
Pump Pressure	15 Bar
Display Type	TFT
Coffee Input Type	Coffee Beans
Bean Hopper Capacity	250 g
Grounds Container Capacity	9 doses
Dishwasher Safe Parts	No

9. Warranty and Customer Support

Your KRUPS Intuition Experience EA879NE0 is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.
For technical assistance, spare parts, or further inquiries, please visit the official KRUPS website or contact their customer service department. Contact information can typically be found on the KRUPS website or in your product documentation.
Visit the KRUPS Brand Store for more information and support.

© 2023 KRUPS. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H3QBJ1MP

More documents and user manuals: **https://manuals.plus/**