Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aroepurt AG11

Aroepurt RebotAi AG11 11-inch Tablet Case User Manual

Model: AG11

1. Introduction

Thank you for choosing the Aroepurt RebotAi AG11 11-inch Tablet Case. This case is designed to provide comprehensive protection and enhanced functionality for your RebotAi AG11 tablet. It features a durable synthetic leather construction, a 360-degree rotating mechanism, and a multi-angle stand for versatile viewing.

The case is crafted with a non-slip soft lining to protect your device from scratches, impacts, fingerprints, and dust. Its unique design also adds an artistic touch to your tablet.



Image 1.1: The tablet case features curated artistic designs, adding a unique aesthetic to your device.



Image 1.2: The case provides all-over protection, covering every side and corner of the tablet, while maintaining a slim and lightweight profile.

2. Setup: Installing Your Tablet

Follow these steps to correctly install your RebotAi AG11 tablet into the case:

1. Open the tablet case completely, laying it flat on a clean surface.
2. Align your RebotAi AG11 11-inch tablet with the protective frame inside the case.
3. Gently press the tablet into the frame, ensuring all corners and edges are securely seated. The flexible holders will grip the tablet firmly.
4. Verify that all ports, speakers, and buttons are accessible through the case's cutouts.

COMPATIBLE WITH A LOT OF TABLET

Please kindly check your tablet size before purchase as shown



Image 2.1: Ensure your tablet size is compatible before insertion. The case is designed to fit the RebotAi AG11 11-inch tablet securely.

Note on Camera Cutouts: This protective case features pre-cut openings for the rear camera, designed to accommodate 99% of camera usage scenarios. However, due to variations in tablet models, some specific camera placements might not align perfectly with all three cutouts simultaneously. Ensure your tablet's camera aligns with one of the available cutouts for proper functionality.



Image 2.2: The case provides three pre-cut camera openings to suit various tablet camera positions.

3. Operating Instructions

3.1 Using the Multi-Angle Stand

The case features a non-slip stripe design that allows you to prop up your tablet at multiple viewing angles for stability. This is ideal for watching videos, typing, or making video calls.

1. Fold the front cover of the case backward to form a triangular stand.
2. Place the edge of your tablet into one of the non-slip grooves on the inside of the front cover to achieve your desired viewing angle.



Image 3.1: The anti-slip stripe ensures stability when the tablet is used in stand mode, providing multiple viewing angles.

3.2 Utilizing the 360-Degree Rotation Function

The case is equipped with a 360-degree rotating mechanism, allowing you to switch between portrait and landscape orientations without removing the tablet from the case.

1. With the tablet securely in the case, gently rotate the tablet and its inner frame to your preferred orientation.
2. Once rotated, you can then use the multi-angle stand feature in either portrait or landscape mode.



Image 3.2: The 360-degree rotation feature allows for seamless switching between portrait and landscape viewing, complemented by adjustable angles.

4. Maintenance

To ensure the longevity and appearance of your tablet case, follow these maintenance guidelines:

- **Cleaning:** Wipe the synthetic leather exterior with a soft, damp cloth. For stubborn dirt, use a mild soap solution and then wipe clean with a dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Protection:** Keep the case away from direct sunlight and extreme temperatures to prevent material degradation.
- **Handling:** Avoid sharp objects that could scratch the surface of the case.

5. Troubleshooting

- **Automatic Sleep/Wake Function:** This case does not support the tablet's automatic sleep/wake function. You will need to manually turn your tablet's screen on and off.

- **Keyboard Storage:** There is no dedicated space within this case to store a keyboard.
- **Camera Alignment:** If your tablet's camera does not align perfectly with one of the cutouts, ensure your tablet is correctly seated within the case. The case provides multiple cutouts to accommodate various camera positions, but 100% alignment for all tablet models is not guaranteed.

6. Specifications

Feature	Detail
Brand	Aroepurt
Compatible Device	RebotAi AG11
Form Factor	Flip Case
Shell Type	Hybrid
Product Exterior Material	Polyurethane (Synthetic Leather)
Color	LHD
Pattern	Personality fashion
Theme	Colorful
Included Components	1*Tablet Case
Country of Origin	China
Manufacturer Model Number	DYPB-2607-164 LHD
Product Body Size	10 x 10 x 10 mm (Packaging dimensions, actual product size may vary slightly)

7. Warranty and Support

For any questions, concerns, or support regarding your Aroepurt RebotAi AG11 11-inch Tablet Case, please contact the seller directly through your purchase platform. Please refer to your purchase documentation for specific warranty details, as warranty terms may vary.

© 2023 Aroepurt. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0H8Q9MJ7B

More documents and user manuals: **https://manuals.plus/**