DYNAVIN Dynaway Navigation System User Manual

Contents

1 DYNAVIN Dynaway Navigation System
2 Navigation
3 Warnings and safety information
4 Getting Started
4.1 Update Map
4.2 Navigation Voice
4.3 Navigation Style
4.4 Map Label
4.5 Selecting Distance Unit
5 General Settings
5.1 Adjusting Navigation Volume and Warning Volume
5.2 2D and 3D Map Settings
5.3 Smart Zoom Features
5.4 Route Settings
6 Product Usage Instructions
7 Warnings and safety information
8 Getting Started
9 General Settings
10 Start Navigation
11 Documents / Resources
11.1 References
12 Related Posts

Dynaway

DYNAVIN Dynaway Navigation System

Navigation

Table of contents

1. Warnings and safety information
2. Getting Started

Warnings and safety information

The navigation system is equipped with a built-in GPS receiver to help you find your way to your destination. It is important to note that the navigation system does not transmit your GPS position, so others cannot track you. We strongly advise that you only look at the display when it is safe to do so. If you are the driver of the vehicle, we recommend that you plan and review your route before you start your journey. Plan the route before your departure and stop if you need to change the route.

Getting Started

The Dynaway navigation software is optimized for in-car use and can be easily used by tapping the screen buttons and the map with your fingertips.

Update Map

You can download countries or regions maps to your Dynavin radio so you can plan your route and navigate offline. To update your maps, login to flex.dynavin.com website with your Dynavin radio’s serial number, download the latest map file, and follow the instructions on the website to import it into your Dynavin radio. You will have access to the same quarter maps as you first used Dynaway, and for more information about upgrades, please visit
flex.dynavin.com.

Navigation Voice

You can select the desired navigation voice by following the steps provided in the user manual.

Navigation Style

You can select navigation style by following the steps provided in the user manual, and you can choose the desired display mode for Day style and Night style. Also, Dynaway navigation software supports switching between Day style and Night style automatically.

Map Label

If the map data contains the local name of that country or region, area names, place names, and street names will be displayed in the local language. You can set up this feature by following the steps provided in the user manual.

Selecting Distance Unit

You can select the desired distance unit by following the steps provided in the user manual. The default value is in Kilometers and permanent if you do not change it manually.

General Settings

Adjusting Navigation Volume and Warning Volume

You can adjust the navigation volume and warning volume by following the steps provided in the user manual.

2D and 3D Map Settings

The map switches from 3D to 2D when you are approaching an intersection or making a turn; The map switches from 2D to 3D when you are going straight ahead at a higher speed and there are no turns. You can adjust these settings by following the steps provided in the user manual.

Smart Zoom Features

- While following a route: When approaching a turn, it zooms in and raises the view angle to let you easily recognize your next maneuver. If the next turn is at a distance, it zooms out and lowers the view angle to be flat so you can see the road in front of you.
- While driving without a planned route: Smart Zoom zooms in if you drive slowly and zooms out when you drive at a high speed.

Route Settings

You can select different route types by following the steps provided in the user manual. This setting is permanent and will be used in your next trip if you do not change it manually.

Product Usage Instructions

1. Plan and review your route before starting your journey.
2. Update your maps by logging in to flex.dynavin.com website with your Dynavin radio’s serial number, downloading the latest map file, and following the instructions on the website to import it into your Dynavin radio.
3. Select the desired navigation voice, navigation style, map label, and distance unit by following the steps provided in the user manual.
4. Adjust the navigation volume and warning volume by following the steps provided in the user manual.
5. Adjust the 2D and 3D map settings by following the steps provided in the user manual.
6. Use Smart Zoom feature while following a route or driving without a planned route.
7. Select different route types by following the steps provided in the user manual.

Warnings and safety information

The navigation system helps you find your way to your destination with the built-in GPS receiver. The navigation system does not transmit your GPS position; others cannot track you. It is important to look at the display only when it is safe to do so. If you are the driver of the vehicle, we recommend that you plan and review your route before you start your journey. Plan the route before your departure and stop if you need to change the route.

Getting Started

Dynaway navigation software is optimized for in-car use. You can use it easily by tapping the screen buttons and the map with your fingertips.

Update Map

You can download countries or regions maps to your Dynavin radio so you can plan your route and navigate offline. Simply login flex.dynavin.com website with your Dynavin radio's serial number, download the latest map file and follow the instructions on the website to import it into your Dynavin radio. We guarantee that you will have access to the same quarter maps as you first used Dynaway. For more information about upgrades, please visit flex.dynavin.com.

Navigation Voice

You can select the desired navigation voice by the following steps











Navigation Style
You can select navigation style by the following steps







and you can select the desired display mode for Day style and Night style.



Also Dynaway navigation software supports to switch Day style and Night style automatically



- **Off:** Night style off
- **On:** Night style on
- **Automatic:** Day style and night style switch automatically

Map Label
With Dynaway navigation software, if the map data contains the local name of that country or region, area names, place names, and street names will be displayed in local language; you can set up by the following steps


Search
Malsch
Buhnweg
Federbach
Birkhofer-Straße
Amtfeldstraße
Bachstraße
Glasbacher Weg
Saumweg
Mittelbachle
Muggensturmer Straße
Hauptstraße
Am Pfad
Hebelstraße
Friedhof Malsch
Rosenstraße
Malsch


Settings
Mobile Data
On
Warnings
Advanced Settings
General
Navigation
About


General
Sound
Night Colors
Automatic
Night Style
Basic 3 Nocturnal
Map Labels
Automatic
Distances
In Kilometres
Day Style
Basic 3
Map Layers



Selecting Distance Unit

You can select the desired distance unit by the following steps, the default value is “In Kilometers” and permanent if you do not change it by manually.









General Settings

Adjusting Navigation Volume and Warning Volume

You can adjust the navigation volume and warning volume by the following steps









2D and 3D Map Settings


Search
Malsch
Buhnweg
Federbach
Bachstraße
Amfeldstraße
Muggensturmer Straße
Hauptstraße
Am Pfad
Friedhof Malsch
Hebelstraße
Rosenstraße
Glasbacher Weg
Saumweg
Mittelbachle
Malsch


Settings
Mobile Data
On
General
Warnings
Navigation
Advanced Settings
About


Navigation
Common Settings
2D/3D Map
Automatic
North Up
Demo Speed
1
1
10
Specific Settings
Car
Truck



Automatic: The map switches from 3D to 2D when you are approaching an intersection or making a turn; The map switches from 2D to 3D when you are going straight ahead at a higher speed and there are no turns

- 2D: 2D map display
- 3D: 3D map display

Smart Zoom Features

- While following a route: When approaching a turn, it zooms in and raises the view angle to let you easily recognize your next maneuver. If the next turn is at a distance, it zooms out and lowers the view angle to be flat so you can see the road in front of you.
- While driving without a planned route: Smart Zoom zooms in if you drive slowly and zooms out when you drive at a high speed.

Route Settings
You can select different route types by the following steps; This setting is permanent and will be used in your next trip if you do not change it by manually.




Settings
Mobile Data
On
Warnings
Advanced Settings
General
Navigation
About


Navigation
Common Settings
2D/3D Map
Automatic
Demo Speed
1
1
10
North Up
Specific Settings
Car
Truck


Car
Travel Mode
Fastest
Avoid Motorways
Avoid Ferries
Show Traffic Delays Longer Than
0 min
2 min
30 min
Avoid Traffic
Prefer Current Route
Avoid Toll Roads
Avoid Unpaved Roads



Also you can set the scenes you want to avoid on your trip from this menu.



Truck Map Settings

You can set the truck data to avoid the no-passing areas by the following steps.




Settings
Mobile Data
On
Warnings
Advanced Settings
General
Navigation
About


Navigation
Common Settings
2D/3D Map
Automatic
Demo Speed
1
1
10
North Up
Specific Settings
Car
Truck


Truck
Travel Mode
Fastest
Avoid Motorways
Avoid Ferries
Show Traffic Delays Longer Than
0 min
2 min
30 min
Avoid Traffic
Prefer Current Route
Avoid Toll Roads
Avoid Unpaved Roads
Truck Profile
Width
Height



Speed Limit Warning

Dynaway navigation map contains information about the speed limits of the road segments. it is able to warn you if you exceed the current limit. This function may not be available for your region, you can delete the function by clicking “Uninstall Speed Cameras”.









- **Off:** Close warning speed limit camera alerts
- **Early** / **Normal** / **Late** : Tap When to show warning speed limit camera alerts

Speed Warning Tolerance
You can use the slider bar to select the desired tolerance value.



Warning Type



- **Voice Message**: Warning alerts by voice
- **Beep:** Warning alerts by beep sound

This function may not be available for your region, you can delete the function by the following steps.





Speed cameras will be uninstalled. You can always reinstall them by using the “Reset to Defaults” option. Continue?
NO YES

Online-TMC Function
Dynaway navigation software has Online-TMC function, you can use it when Dynavin radio is connected internet via Wi-Fi.



Start Navigation

Type the address in the search bar, it shows the result as below picture shown;





Dynavin GmbH
Siemensstr. 7
76316 Malesich
Germany
© 2022 Dynavin GmbH
All rights reserved.
Reprinting and reproduction, even in part, is prohibited.
The features of the products are correct at the time of creation of the print product. All display representations are simulated. The color of the products may vary. We accept no liability for any typesetting errors. We reserve the right
to make changes.
REV 2022 / 11 / 30
www.dynavin.de

Documents / Resources

Dynaway Navigation User Manual	DYNAVIN Dynaway Navigation System [pdf] User Manual Dynaway, Dynaway Navigation System, Navigation System

References

- Dynavin
- Dynavin: Das smarte Multimediasystem (Autoradio mit Navi)

Manuals+,