Manuals+ — User Manuals Simplified.

FLAIR 2AK78BRIDGE Bridge Plug and Play Networking Gateway

FLAIR 2AK78BRIDGE Bridge Plug and Play Networking Gateway Installation Guide

Contents

FLAIR 2AK78BRIDGE Bridge Plug and Play Networking Gateway

Specifications

- **Colour:** Pulsing Blue, Pulsing White, Solid Blue, Pulsing Red, Solid Red, Flashing Green, Solid Green, Pulsing Orange
- **Status:** Ready for Wi-Fi setup, Ready for Ethernet setup, Connected to Wi-Fi/Ethernet setup complete, No internet access, Failed to connect to Wi-Fi/Ethernet, Over-the-Air (OTA) in progress, Over-the-Air (OTA) successful, Setup mode enabled
- **Antenna Type:** Glue Stick Antenna
- **Antenna Gain:** 1.93dBi

For full instructions visit **flair.co/welcome**
View our installation guides, user guides, and support dashboard at **support.flair.co**

INSTALL THE FLAIR APP

- Flair has mobile and web apps.
- Available for iOS, Android and Chrome.

flair.co/ios
flair.co/android
my.flair.co

RUN THE SETUP
The Flair App will guide you through step-by-step instructions to connect your devices and complete setup.

WHAT'S IN THE BOX

- **A.** Bridge
- **B.** Power Adapter
- **C.** USB Cable
- **D.** Ethernet Cable

OPTIONAL MOUNTING HOLES

PORTS

Ethernet Port   Reset Button

915 MHz Antenna   USB-C Port

LED INDICATORS

- COLOR
- Pulsing Blue
- Pulsing White
- Solid Blue
- Pulsing Red
- Solid Red
- Flashing Green
- Solid Green
- Pulsing Orange

STATUS

- Ready for Wi-Fi setup
- Ready for Ethernet setup
- Connected to Wi-Fi/ Ethernet setup complete
- No internet access
- Failed to connect to Wi-Fi/Ethernet
- Over-the-Air (OTA) in progress

- Over-the-Air (OTA) successful

- Setup mode enabled

NEED ASSISTANCE? WE'RE HERE TO HELP.
If you have any questions as you set up your Flair home, please contact us at support@flair.co

FCC COMPLIANCE STATEMENT

- **FCC ID:** 2AK78BRIDGE

- **Contains FCC ID:** 2AC7Z-ESPS3WROOM1

- **IC:** 22464-BRIDGE

- **Contains IC:** 21098-ESPS3WROOM1

- **Model:** BRIDGE-1.0

This device complies with Part 15 of the FCC Rules . Operation is subject to the following two conditions:

1. this device may not cause harmful interference,

2. this device must accept any interference received, including interference that may cause undesired operation.

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and the receiver.

- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Canada Statement
This device complies with Innovation, Science and Economic Development Canada's license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. this device may not cause interference,

2. this device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body.

This radio transmitter ||C:22464-BRIDGE] has been approved by Innovation, Science and Economic Development Canada to operate with the antenna types listed below, with the maximum permissible gain indicated. Antenna types not included in this list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited for use with this device.

- **Antenna Type:** Glue Stick Antenna
- **Antenna Gain:** 1.93dBi

Frequently Asked Questions

- **Q: What should I do if the device shows a flashing green LED?**
  - A: The flashing green LED indicates that an Over-the-Air (OTA) update is in progress. Please wait for the update to complete before using the device.
- **Q: How can I enable setup mode on the device?**
  - A: To enable setup mode, ensure the device is powered on and press the designated setup button as indicated in the user manual.

Documents / Resources

FLAIR Bridge Installation Guide For full instructions visit flair.co/welcome View our installation guides, user guides, and support dashboard at support.flair.co	**[FLAIR 2AK78BRIDGE Bridge Plug and Play Networking Gateway](#)** [pdf] Installation Guide 2AK78BRIDGE, 2AK78BRIDGE Bridge Plug and Play Networking Gateway, Bridge Plug and Play Networking Gateway, Plug and Play Networking Gateway, Play Networking Gateway, Networking Gateway, Gateway

References

- **[User Manual](#)**