Manuals+ — User Manuals Simplified.

HARVEST TECHNOLOGY Nodestream RiS Quad Media Decoder User Guide

**MEDIA
DECODER NQDR**

Contents

Overview

**Welcome to the Nodestream RiS Quad Decoder (NQDR)** Please read these instructions carefully before using this product and save this quick start guide for future reference. See the User Manual for full details via the QR code on the back page.

Video and data streaming solution

Video Source (up to 4 sources)   RiS Encoder Device (remote location)   Nodestream RiS Decoder (viewing location)   Monitor(s)

In the Box

Nodestream RiS Quad Decoder   4 x Mini Display Port to HDMI adaptor   Power cable (region specific)

Rear Connections

Power Switch   Power Socket

USB-A

Ethernet

DO NOT USE

Line In
Line Out
Mic In

PS/2   HDMI   DisplayPort   USB-A   USB-A

Serial Port

Mini Display Port   (output to monitors)

⚠ **IMPORTANT: 100-240VAC 47/63HZ only (UPS recommended).**
Do not use the Display Port or HDMI for output to monitors. (Use the Mini-Display port only).
Front Connections

ON / OFF   POWER   USB-A
RESET   HDD

Installation

The NQDR is designed to be mounted in a standard 19" Rack and occupies 3U of space

⚠ Ensure there is adequate spacing around the NQDR device for cooling. Cooling air travels in the direction as shown by the arrows.
No vertical loading on the NQDR device.

1. Install at 4 mount points

mount points

2. Connect

Power

Monitor output(s)

Serial

Ethernet

Configuration

Access via Web Browser

1. Connect the RIS Quad Decoder to your LAN via the Ethernet port and power the device
2. Input the IP address into the address bar of a web browser

The device is set to DHCP by default. The IP address can be identified by use of a suitable IP scanning tool. Serial number and/or MAC address should be displayed

Access via the Device

1. Connect LAN, monitor, keyboard/mouse and power the device
2. Once the device has booted, double click the "RiS configuration" icon on the desktop or hold CTRL and press ~

Complete Configuration

1. Login with – User: admin , Password: admin
2. When prompted, enter a new password

3. Configure device network settings as provided by your Network Administrator

4. Once connected and configured on your local network, the device will show online in the Harvest RiS Deliverer application

⚠️ RiS networks require specific port settings, see user manual for details

• Devices need to be manually added to the Deliverer application. See Deliverer User Manual for more information

ℹ️ User Manual

Refer to the RIS Quad Decoder User Manual for additional information.

User Resources

https://qrco.de/bcpbWY

Contact and Support **support@harvest-tech.com.au**

Troubleshooting

Issue	Cause	Resolution
Device not powering	PSU switch set to off position AC not connected	Confirm AC connected and switch is in the on position
No display output	Video output device not connected or powered on	Confirm video output device connected and powered on
Network issue (Device showing "offline" in Deliverer application)	Network not connected Network settings incorrect Device IP address incorrect in Deliverer application	Check Ethernet cable is connected and enabled Check network settings, contact your network administrator to diagnose network Confirm IP address of device matches that set in Deliverer
Forgot login or network details	N/A	Factory reset to defaults (see User Manual)

EU REP TerrainQ Market Access Ltd (**service@market-access.online**) 33 Nikolaou I. Nikolaidi Ave. , KS Tower, 8010 Paphos Cyprus

Documents / Resources

MEDIA DECODER | NQDR RiS Quick Start Guide	**HARVEST TECHNOLOGY Nodestream RiS Quad Media Decoder** [pdf] User Guide Nodestream RiS Quad, Media Decoder, Nodestream RiS, Quad Media Decoder, Nodestream RiS Quad Media Decoder, NQDR

References

- 🌐 **Turner Rooms for Rent**