132x192mm

Frigidaire

REFRIGERATOR
FREEZER

75 cm
212 L

USER MANUAL

EFR751

FRIGIDAIRE is a pending or registered trademark used under license from Electrolux Home Products, Inc.
Made in China

TABLE OF CONTENTS

NAMES OF THE PARTS 2
IMPORTANT SAFETY INSTRUCTIONS 3
INSTALLATION INSTRUCTION
BEFORE USING YOUR REFRIGERATOR 4
INSTALLING YOUR REFRIGERATOR 4
ELECTRICAL CONNECTION 5
OPERATING YOUR REFRIGERATOR
TEMPERATURE CONTROL 6
ICE TRAY 6
THE FREEZER COMPARTMENT 6
WHEN TO DEFROST 6
HOW TO DEFROST 7
HOW TO CHANGE THE INTERIOR LIGHT 7
HOW TO INSTALL THE HANDLES 8
CHANGING THE REVERSIBLE DOOR 9
CARE AND MAINTENANCE
CLEANING YOUR REFRIGERATOR 10
VACATION TIME 10
MOVING YOUR REFRIGERATOR 10
ENERGY SAVING TIPS 10
TROUBLESHOOTING GUIDE 11

NAMES OF THE PARTS

MODEL NO. EFR751

(1) Cabinet Tabletop
(2) Door Rack
(3) Temperature Control Box
(4) Interior Light Switch
(5) Shelf: Refrigerator Section
(6) Ice Cube
(7) Crisper
(8) Leveling Leg
(9) Egg Tray
(10) Ice Tray

⚠ WARNING ⚠ Never touch the interior of the Freezer Chamber or frozen foods in the compartment with wet hands as this could result in frost bite.

IMPORTANT SAFETY INSTRUCTIONS

WARNING To reduce the risk of fire, electrical shock, or injury follow these basic precautions when using your refrigerator.

1. **WARNING**—Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
2. **WARNING**—Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
3. **WARNING**—Do not damage the refrigerant tubing to increase the risk of a leak when handle, move and use of refrigerator.
4. **WARNING**—Do not use electrical appliances inside the food storage compartments of the appliances, unless they are of the type recommended by the manufacturer.
5. **WARNING**—Do not store explosive substances such as aerosol cans with a flame inside the refrigerator. Risk of child entrapment. Before you throw away your old refrigerator or freezer:
   - Take off the doors
   - Leave the shelves in place so that children may not easily climb inside.
6. The appliance has to be unplugged before carrying out user maintenance on the appliance.
7. This appliance can be used by children age 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children should not play with the appliance. Cleaning and maintenance should not be made by children without supervision.
8. If the component part is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
9. Please abandon the refrigerator according to local regulations as the unit contains flam mable blowing gas and refrigerant.
10. Do not damage the refrigerant circuit. Dispose of the appliance due to flammable refrigerant and blowing gas. All refrigerator products contain refrigerants, which under the guidelines of federal law must be removed before disposal. It is the consumer's responsibility to comply with federal and local regulations when disposing of this product.
11. This appliance is intended to be used in household and similar environments; such as:
   - staff areas in shops, offices and other working environments;
   - farm houses and by clients in hotels, motels and other residential type environments;
   - bed and breakfast type environments.
12. Do not store or use gasoline or any other flammable vapors and liquids inside or in the vicinity of refrigerator.
13. Do not use an extension cord with this appliance. If the power cord is too short, have a qualified electrician install an outlet near the appliance. Use of an extension cord can negatively affect the performance of the unit.

R600a
Contains refrigerant

IMPORTANT SAFETY INSTRUCTIONS

⚠ WARNING ⚠ To reduce the risk of fire, electrical shock, or injury follow these basic precautions when using your refrigerator.

- Read all instructions before using the refrigerator.
- **DANGER or WARNING**: Risk of child entrapment.
- Before throwing away your old refrigerator or freezer, please take the following precautions before throwing out the refrigerator:
  - Remove all doors from the unit.
  - Leave the shelves in place so that children may not easily climb inside.
- Never allow children to operate, play on, or crawl inside the refrigerator.
- Refrigerants: All refrigeration products contain refrigerants, which under the guidelines of federal law must be removed before disposal of product. It is the consumer's responsibility to comply with federal and local regulations when disposing of this product.
- Never clean refrigerator parts with flammable fluids. The fumes can create a fire hazard or explosion.
- Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other refrigerator. The fumes can create a fire hazard or an explosion.

Store these instructions

INSTALLATION INSTRUCTIONS

Before Using Your Refrigerator

- Remove the exterior and interior packing.
- Before connecting the refrigerator to the power source, let it stand upright for approximately 4 hours. This will reduce the possibility of a malfunction in the cooling system from improper handling during transportation.
- Clean the interior surface with lukewarm water using a soft cloth. (Cleaning instruction on page 9)

Installing Your Refrigerator

- Place your refrigerator on a floor that is strong enough to support the refrigerator when it is fully loaded.
- Leave 2 inches of space between the back and sides of the refrigerator, which allows the proper air ventilation. Adjust the feet to keep the refrigerator level.
- Locate the refrigerator away from direct sunlight and sources of heat (stove, heater, radiator, etc.). Direct sunlight may affect the acrylic coating and heat sources may increase electrical consumption. Ambient temperature below 50°F (10°C) or above 90°F (29.4°C) will hinder the refrigeration performance. **This unit is not designed for use in a garage or any other outside installation.**
- Avoid locating the refrigerator in moist areas.
- Plug the refrigerator into dedicated, properly installed-grounded wall outlet. Do not under any circumstances cut or remove the third (ground) prong from the power cord. Any questions concerning the electrical or shock hazard, please call a qualified electrician or call the authorized service center. **This unit is not designed to be installed in an RV or used with an inverter.**
- After plugging the appliance into a wall outlet, turn the unit on and allow the unit to cool down for 2-3 hours under before placing food in the refrigerator or freezer compartment.

Electrical Connection

⚠ WARNING ⚠
Improper use of the grounded plug can lead to the risk of electrical shock. If the power cord is damaged, have it replaced by an authorized service center.

This refrigerator should be properly grounded for your safety. The power cord of this refrigerator is equipped with a three-prong plug which mates with standard three-hole wall outlets to minimize the possibility of electrical shock.

Do not, under any circumstances, cut or remove the third ground prong from the power cord supplied.

This refrigerator requires a standard 115/120 Volt AC ~60Hz electrical outlet with three-prong ground.

This refrigerator is not designed to be used with an inverter.

The cord should be secured behind the refrigerator and not left exposed or dangling to prevent accidental injury.

Never unplug the refrigerator by pulling the power cord. Always grip the plug firmly and pull straight out from the receptacle.

Do not use an extension cord with this appliance. If the power cord is too short, have a qualified electrician or service technician install an outlet near the appliance. Use of an extension cord can negatively affect the performance of the unit.

OPERATING YOUR REFRIGERATOR

Temperature Control

- Your refrigerator has one control for regulating the temperature. The temperature control is located on the top center of the refrigerator compartment.
- The first time you turn the unit on, adjust the temperature control knob to " " hand run for at least 2 hours before putting food in the unit. This will ensure the cabinet is thoroughly chilled before food is put in.
- The range of the refrigerator temperature control is from position "1" the warmest to "7" the coldest. Adjust the temperature control to the setting that best suits your needs.
- Turn the "7" knob to the opposite for home or office refrigerator unit.
- Turning the temperature control knob to "0" position stops the cooling cycle but does not shut off the power to the unit.

- **NOTE;**
  - If the unit is unplugged, leave power; you must wait 3 to 5 minutes before restarting the unit. This will prevent damage to the unit. Food may be spoiled if not.
  - Large amounts of food will slowly lower the cooling efficiency of the appliance.
  - Do not place the foods on the air outlet, and leave spaces for airflow.
  - If it is necessary to change the thermostat setting, adjust thermostat control by one increment at a time. Allow several hours for temperature to stabilize between adjustments.

Ice Tray

- Remove the ice tray from the freezer compartment.
- Fill the tray (23 cubes capacity) with cold water and place the tray on the bottom of the chiller compartment. Place tray evenly.
- To eject the ice cubes from the tray, place over the ice bucket and twist slightly.
- Reset the temperature control to setting " 3.

The Freezer Compartment

- This compartment is designed for the long-term storage of frozen food.
- The ice cube life of frozen foods varies and the recommended storage time should not be exceeded.
- Place frozen food into the freezer as quickly as possible after purchase. If there are instructions on the packet, carefully follow those instructions regarding storage times.

When To Defrost

This unit is not designed to defrost automatically. In order to prevent damage to the interior liner of the unit from excessive frost build-up, please manually defrost the unit every 3 month or when ice / frost is approximately 1/4 " thick inside the freezer compartment.

How To Defrost

Defrost the freezer compartment when the ice / frost are approximately ¼" thick or every 3 months, whichever comes first. Do not allow ice build-up to exceed ¼". Remove all contents from the freezer compartment. Leave the freezer door open to allow accelerated ice / frost to melt. Remove large pieces of ice / frost by hand. Do not use any sharp objects to remove ice / frost. Remove accumulated ice. After defrosting, remove accumulated ice / water and wipe the freezer compartment dry with a soft cloth. In the event that the ice is not visibly present in the freezer compartment, please wait approximately 30 minutes before restarting the unit. Allow approximately 2 hours before restarting the unit. Reset the temperature control after starting instructions.

How To Change the Interior light

NOTE: All parts removed must be saved to do the reinstallation of the light bulb. Before removing the light bulb, unplug the appliance from the power supply. Failure to do so could result in electrical shock or personal injury.

1. Remove the lamp cover by unscrewing.
2. Unscrew old bulb from the socket and install a new one at the thermostat control box.
3. Replace the new bulb of the same voltage and screw size.
4. Reinstall the lamp cover by screwing it in place.

- **How To Install the handles**
  - Take out the handle from the unit and remove the package. (two handle part and 4 screws)
  - Use a screwdriver to secure the handle to the bottom of the door by four pcs screw.
  - Push the handle horizontally until the handle secure.
  - Push and pull the handle to make sure the handle is installed well.



CHANGING THE REVERSIBLE DOOR

CAUTION: To avoid personal injury to yourself and/or property, we recommend someone assist you during the door reversal process.

Your refrigerator is built with a reversible door. You have the choice of either opening it from the left or the right side. In order to reserve the opening direction of your door, please follow these simple instructions.

1) Disassemble all the reversible components in the sequence as shown below (also refer to left diagram above). Be sure to keep them well for later use in the process of reassembling.

(1) leveling leg II
(2) bottom hinge
(3) leveling leg I
(4) bottom door baffle block
(5) 2 screws to hold bottom hinge
(6) door lower freezer section
(7) mid hinge
(8) 2 screws to hold mid hinge
(9) upper door right stopper
(10) door freezer section
(11) top hinge
(12) 2 screws to hold top hinge
(13) door hinge cover
(14) door cap
(15) upper door left stopper
(16)
(17)
(18)

2) To access the bottom hinge assembly, you may tilt back the refrigerator cabinet or lay the refrigerator on its back.
3) Remove the upper door right stopper (9), install the upper door left stopper (15) on the opposite side, remove the door cap (14) and place it on the hole left by the upper door stopper.
4) Reassemble the unit with the door hinges on the opposite side (see the right diagram above). The sequence for reassembling is just in reverse order of disassembling.
5) Adjust the door alignment: loosen the bottom hinge (2) and the mid hinge (7) on the cabinet and then fasten the mid hinge 7 temporary, loosen the bottom hinge and the top hinge when aligning and then fasten them tight.

CARE AND MAINTENANCE

Cleaning Your Refrigerator

Upon installation of your new appliance, it is recommended that it be cleaned thoroughly.

- Turn off the refrigerator first and then unplug the unit from the wall outlet.
- Remove all food.
- Wash the inside with a damp warm cloth soaked in lukewarm water and baking soda solution. The solution should be about 2 tablespoons of baking soda to a quart of water.
- Be sure to keep the door gasket (seal) clean to keep the unit running efficiently.
- The outside of the refrigerator should be cleaned with mild detergent and warm water.
- Dry the interior and exterior with a soft cloth.

Vacation Time

- Turn off the refrigerator first and then unplug the unit from the wall outlet.
- Remove all the food.
- Clean the refrigerator.
- Leave the door open slightly to avoid possible formation of condensation, mold, or odor.
- Use extreme caution in the case of children. The unit should not be accessible to child's play.
- **Power failure:** Unplug the refrigerator and remove the food in the freezer if the power is out for long **vacations**: If the appliance will not be used for several months, remove all food and unplug the power cord. Clean and dry the interior thoroughly. To prevent odor and mold growth, leave the door open slightly blocking it open if necessary or have the door removed.

Moving Your Refrigerator

- Turn off the refrigerator first and then unplug the unit from the wall outlet.
- Remove all the food.
- Securely tape down all loose items inside your refrigerator.
- Tape the doors shut.
- Tape the refrigerator stays in the upright position during transportation.

Energy Saving Tips

- Your refrigerator should be located in the coolest area of the room, away from heat producing appliances or heating ducts, and out of the direct sunlight.
- Let hot foods cool to room temperature before placing in the refrigerator. Overloading the refrigerator forces the compressor to run longer. Foods that freeze too slowly may lose quality or spoil.
- Be sure to wrap foods properly, and wipe containers dry before placing them in the refrigerator. This will prevent frost build-up and food from drying out.
- Organize and label food to reduce door opening and extended searches. Remove as many items as needed at one time, and close the door as soon as possible.

TROUBLESHOOTING GUIDE

You can solve many common refrigerator problems easily, saving you the cost of a possible service call. Try the suggestions below to see if you can solve the problem before calling for service.

PROBLEM	POSSIBLE CAUSE
Refrigerator does not operate.	Not plugged in.
	Circuit breaker tripped or a blown fuse.
Compressor turns on and off frequently.	The room temperature is hotter than normal. A large amount of food has been added to the refrigerator.
	The door has been opened too often.
	The door is not closed completely.
	The temperature control is not set correctly.
	The door gasket does not seal properly.
	The door gasket does not have the correct clearance.
	The refrigerator has recently been disconnected for a period of time. It heats up as required for the first hour of operation. This is normal.
Temperature inside the refrigerator is too warm.	Temperature control is set too warm. Turn the control to a colder setting and allow several hours for the temperature to stabilize.
	Door is kept open too long or is opened too frequently. Warm air enters the refrigerator every time the door is opened. Open the door less often.
	The door is not closed completely.
	Warm food has been put in the refrigerator. A large amount of warm or hot food might have been stored recently. Wait until the refrigerator has had a chance to reach its selected temperature.
	The refrigerator has recently been disconnected or has been off for a period of time. Allow the refrigerator to cool down completely.
Temperature inside the refrigerator is too cold.	Temperature control is set too cold. Turn the control to a warmer setting and allow several hours for the temperature to stabilize.
Temperature of external refrigerator surface is warm.	Some warmth is felt on the surface as much as 30°F warmer than room temperature. This is normal while the compressor works to transfer heat from inside the refrigerator to outside.
Popping or cracking sound when compressor comes on.	Metal parts undergo expansion and contraction, as in hot water pipes. This is normal. Sound will stop if or disappear as refrigerator continues to run.
Bubbling or gurgling sound, like water boiling.	Refrigerant (used to cool refrigerator) is circulating through the refrigerator. This is normal.
Vibrations.	Check to ensure that the refrigerator is on a level surface.
	Check to ensure unseen or weak. Refrigerator rocks on the floor when it is moved slightly. Be sure floor can adequately support refrigerator. Level the

---

To make a warranty claim, do not return this product to the store. Please email support@curtisint.com or call 1-800-968-9853.

1 Year Warranty

This product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of original purchase. During this period, your exclusive remedy is repair or replacement of the product or component found to be defective, at our option; however, you are responsible for all costs associated with returning the product to us. If the product or component is no longer available, we will replace with a similar one of equal or greater value. Prior to a replacement being sent, the product must be tendered inoperable or returned to us.

This warranty does not cover glass, filters, wear from normal use, use not in conformity with the printed directions, or damage to the product resulting from accident, alteration, abuse, or misuse. This warranty extends only to the original consumer purchaser or gift recipient. It does not extend to any product that is resold or transferred in violation of the warranty claim. This warranty is void if the product is used for other than single-family household use or subjected to any voltage and waveform other than as on the specified rating on the label (e.g., 120V~60Hz).

We exclude all claims for special, incidental, and consequential damages caused by breach of express or implied warranty. All liability is limited to the amount of the purchase price. **Every implied warranty, including any statutory warranty or condition of merchantability or fitness for a particular purpose, is disclaimed except to the extent prohibited by law, in which case such warranty or condition is limited in duration to the period of this warranty.** Some states do not allow limitations on rights. You may have other legal rights that vary depending on where you live. Some states or provinces do not allow limitations on implied warranties or special, incidental, or consequential damages, so the foregoing limitations may not apply to you.

For faster service, locate the model, type, and serial numbers on your appliance.

For service assistance and product information, please call: 1-800-968-9853.
Curtis International Ltd.
7045 BECKETT DRIVE, UNIT 15, MISSISSAUGA, ON, L5S 2A3 www.curtisint.com

---

Frigidaire

RÉFRIGÉRATOR
CONGÉLATEUR

75 cm
212 L

MANUEL D'INSTRUCTIONS

EFR751

FRIGIDAIRE est une marque commerciale en attente ou enregistrée utilisée sous licence par Electrolux Home Products, Inc.
Fabriqué En Chine

TABLE DES MATIÈRES

NOM DES PIÈCES 2
DIRECTIVES DE SÉCURITÉ IMPORTANTES 3
INSTRUCTIONS POUR L'INSTALLATION
AVANT D'UTILISER VOTRE RÉFRIGÉRATEUR 4
INSTALLATION DE VOTRE RÉFRIGÉRATEUR 4
BRANCHEMENT ÉLECTRIQUE 5
UTILISATION DE VOTRE RÉFRIGÉRATEUR
COMMANDE DE TEMPÉRATURE 6
MOULE À GLAÇON 6
LE CONGELATEUR 6
QUAND DÉGIVRER 6
COMMENT DÉGIVRER 7
MODIFICATION DE LA LUMIÈRE 7
POIGNÉE INSTALLATION 7
CHANGEMENT DE LA PORTE RÉVERSIBLE 8
ENTRETIEN ET MAINTENANCE
NETTOYAGE DE VOTRE RÉFRIGÉRATEUR 9
PÉRIODE D'INUTILISATION 9
DÉPLACEMENT DE VOTRE RÉFRIGÉRATEUR 9
ÉCONOMIES D'ENERGIE CONSEILS 9
GUIDE DE DÉPANNAGE 10

NOM DES PIÈCES

NUMÉRO DU MODÈLE : EFR751

(1) Couvercle de la charnière
(2) Porte
(3) Boîtier de contrôle de la température
(4) Interrupteur de l'éclairage intérieur
(5) Grilles, section du réfrigérateur
(6) Glaçon
(7) Bac à légumes
(8) Pieds de nivellement
(9) Plateau en œufs
(10)Moule à glaçon

⚠ MISE EN GARDE ⚠ Ne touchez jamais l'intérieur du Congélateur ou les aliments congelés situés à l'intérieur si vous avez les mains humides car cela pourrait entraîner une gelure.

DIRECTIVES DE SÉCURITÉ IMPORTANTES

AVERTISSEMENT Afin de minimiser les risques d'incendie, de choca électrique ou de blessures, suivez des précautions élémentaires lorsque vous utilisez votre réfrigérateur.

1) **AVERTISSEMENT**—Ne pas obstruer l'ouverture de ventilation, dans l'enceinte de l'appareil ou dans la structure intégrée.
2) **AVERTISSEMENT**—Ne pas utiliser de dispositifs mécaniques ou autres moyens pour accélérer le processus de dégivrage, autre ceux recommandés par le fabricant.
3) **AVERTISSEMENT**— Ne pas endommager la tuyauterie du réfrigérant ce qui augmentera les risques de fuite lorsque de la manipulation, du déplacement et de l'utilisation réfrigérateur.
4) **AVERTISSEMENT** —Ne pas utiliser d'appareils électriques à l'intérieur des compartiments de rangement des aliments de l'appareil, à moins qu'ils ne soient du type recommandé par le fabricant.
5) **AVERTISSEMENT — DANGER:** Ne jamais laisser les enfants jouer, utiliser ou ramper sur ou à l'intérieur du réfrigérateur. Risque d'enfermer les enfants. Avant de jeter votre vieux réfrigérateur ou congélateur:
   - Enlever les portes.
   - Laisser les étagères en place afin que les enfants ne puissent pas grimper facilement à l'intérieur.
6) Le produit doit être débranché avant de procéder à la maintenance de l'appareil.
7) Cet appareil peut être utilisé par des enfants âgés de 8 ans et au-delà, par des personnes aux capacités sensorielles ou physiques et mentales réduites, ou manquant d'expérience et de connaissance à condition qu'elles aient reçu une supervision d'instructions préalables concernant l'utilisation de l'appareil en toute sécurité, et comprennent les risques encourus. Les enfants ne devraient pas jouer avec l'appareil. Le nettoyage et entretien ne doivent pas être assurés par des enfants sans surveillance.
8) Si la pièce est endommagée, elle doit être remplacée par le fabricant, son agent de SAV ou des personnes qualifiées afin d'éviter tout danger.
9) Veuillez vous débarrasser du réfrigérateur conformément à la réglementation locale, car l'appareil contient un gaz inflammable pouvant s'en dégager, et du réfrigérant.
10) Suivre la réglementation locale relative à l'élimination de l'appareil. Ne pas endommager le circuit réfrigérant. Les produits réfrigérants contiennent des réfrigérants inflammables et du gaz. Tous les appareils réfrigérants contiennent des réfrigérants qui, conformément aux directives de la loi fédérale, doivent être purgés avant d'être éliminés. Il est du ressort du consommateur de se conformer à la réglementation fédérale et locale lors de l'élimination du produit.
11) Cet appareil est prévu pour un usage domestique et dans des lieux similaires, notamment :
   - Les cuisines du personnel dans les magasins, bureaux et autres lieux de travail ;
   - Les maisons de ferme et par les clients dans les hôtels, motels et autres lieux de type résidentiel ;
   - Les chambres d'hôtes.
   - Restauration et service en gros de même type.
12) Ne pas stocker ni utiliser de l'essence, des alcools inflammables ni des liquides à proximité de ce réfrigérateur ou d'un autre.
13) Ne pas utiliser de rallonge avec l'appareil. Si le cordon d'alimentation est trop court, demander à un électricien qualifié d'installer une prise près de l'appareil. L'utilisation d'une rallonge peut affecter négativement le bon fonctionnement de l'appareil.

R600a
Contient du réfrigérant

DIRECTIVES DE SÉCURITÉ IMPORTANTES

⚠ MISE EN GARDE ⚠ Afin de réduire le risque d'incendie, de choca électrique ou de blessures, suivez des précautions élémentaires lorsque vous utilisez votre réfrigérateur.

- Lisez la totalité des instructions avant d'utiliser le réfrigérateur.
- **DANGER ou MISE EN GARDE:** Risque d'enfermement d'enfant.
- Pour éviter toute possibilité qu'un enfant se retrouve piégé à l'intérieur du réfrigérateur, veuillez prendre les précautions suivantes avant de le mettre au rebut.
  - Retirez la totalité des portes de l'appareil.
  - Laissez les étagères en place de sorte que des enfants ne puissent pas facilement grimper à l'intérieur.
- N'autorisez jamais aucun enfant à utiliser, jouer avec ou ramper à l'intérieur du réfrigérateur.
- Fluides réfrigérants: Tous les produits de réfrigération contiennent des fluides frigorigènes qui, selon les directives de la loi fédérale doit être enlevé avant l'élimination du produit. Il incombe au consommateur de se conformer aux réglementa fédérales et locaux lors de l'élimination de ce produit.
- Ne nettoyez jamais les pièces du congélateur avec des fluides inflammables. Les vapeurs peuvent créer un risque d'incendie ou d'explosion.
- Ne conservez pas ou n'utilisez pas d'essence ni aucune autre émanations ni aucun liquide inflammable à proximité de ce réfrigérateur ou de tout autre réfrigérateur. Les émanations pourraient créer incendie ou une explosion.

Conservez ces instructions

INSTRUCTIONS POUR L'INSTALLATION

Avant d'utiliser votre réfrigérateur

- Retirez l'emballage extérieur et intérieur.
- Avant de brancher le réfrigérateur sur la prise de courant, laissez-le debout pendant environ 4 heures. Cela permettra de réduire les risques de panne du circuit de refroidissement dues à une manipulation incorrecte lors du transport.
- Nettoyez la surface interne à l'eau tiède à l'aide d'un chiffon doux. (Voyez la nettoyage sur le réfrigérateur page 9)

Installation de votre réfrigérateur

- Ce appareil est conçu pour fonctionner seul. Il ne devrait pas être encastré.
- Placez votre réfrigérateur sur un sol suffisamment résistant pour supporter son poids lorsqu'il est plein.
- Laissez un espace de 5 pouces entre l'arrière de votre cellule du réfrigérateur afin de permettre la ventilation adéquate. Ajustez les pieds pour maintenir le réfrigérateur à niveau.
- Positionnez le réfrigérateur de sorte que celui-ci ne soit pas exposé à la lumière directe du soleil ou à proximité de sources de chaleur (poêle, chaudière, radiateur, etc.). L'exposition à la lumière directe du soleil peut détériorer le revêtement acrylique et les sources de chaleur peuvent augmenter la consommation électrique du réfrigérateur. Une température ambiante inférieure à

50°F (10°C) ou supérieure à 90°F (29.4°C) aura une influence négative sur la performance de l'appareil. **Cet appareil n'est pas conçu pour une utilisation dans un garage ou dans toute autre installation en extérieur.**

- Ne pas entreposer ou utiliser dans des lieux humides.
- Branchez le réfrigérateur sur une prise de courant raccordée à la terre dédiée et correctement installée. Ne coupez ou ne retirez sous aucun prétexte la troisième ergot (terre) de la fiche du cordon d'alimentation. Toute question concernant l'alimentation en électricité ainsi le raccordement à la terre devrait être posée à un électricien certifié ou à un centre de réparations agréé. **Cet appareil n'est pas conçu pour être installé dans un véhicule de camping ni pour être utilisé avec un onduleur.**
- Après avoir branché l'appareil sur une prise de courant, attendez l'appareil et laissez-le refroidir pendant 2-3 heures avant de placer des aliments dans le congélateur ou dans le réfrigérateur.

Branchement électrique

⚠ MISE EN GARDE ⚠
Une utilisation incorrecte de la prise de raccordement à la terre peut entraîner un risque d'électrocution. Si le cordon d'alimentation est endommagé, faites-le remplacer par un réparateur agréé.

Pour votre sécurité, ce réfrigérateur devrait être correctement raccordé à la terre. Le cordon d'alimentation de ce réfrigérateur est équipé d'une fiche à trois ergots qui s'emboîte dans des prises sechez à trois ergots standard afin de réduire la possibilité d'une électrocution.

Ne coupez ou ne retirez sous aucun prétexte la troisième ergot (terre) de la fiche du cordon d'alimentation fourni.

Le cordon d'alimentation devrait être sécurisé derrière le réfrigérateur et ne devrait pas être exposé ou suspendu pour éviter toute blessure accidentelle.

Ne débranchez jamais le réfrigérateur en tirant sur le cordon d'alimentation. Tenez toujours fermement la fiche et tirez-la droite vers l'extérieur de la prise de courant.

N'utilisez pas de cordon de rallonge avec cet appareil. Si le cordon d'alimentation est trop court, demandez à un électricien qualifié ou à un technicien d'entretien d'installer une prise de courant près de l'appareil. L'utilisation d'un cordon de rallonge peut avoir un effet négatif sur le fonctionnement de l'appareil.

UTILISATION DE VOTRE RÉFRIGÉRATEUR

Commande de température

- Votre réfrigérateur est équipé d'un thermostat. Le contrôle de la température est situé en haut et au centre du compartiment du réfrigérateur.
- Lorsque vous allumez votre machine, réglez la température sur "5" et faites fonctionner l'appareil pendant au moins 2 heures avant d'y placer des aliments. Ceci vous permettra d'être sûr que l'appareil est complètement refroidi avant de mettre des aliments à l'intérieur.
- Le contrôle de la température va de « 1 » à « 5 », c'est-à-dire du moins froid au froid maximum. Réglez la température selon vos besoins. Le réglage sur « 3 » convient à la plupart des conditions d'utilisations au domicile ou au bureau.
- Lorsque vous mettez le bouton de contrôle sur « 0 », le cycle de refroidissement est arrêté mais l'appareil reste allumé.

- **REMARQUE;**
  - Si l'appareil est débranché ou en cas de coupure de courant, il faut attendre 3 à 5 minutes avant de le remettre en marche. Si vous essayez de le redémarrer avant ce délai, vous risquez de l'endommager.
  - Les grandes quantités de nourriture réduisent l'efficacité de l'appareil.
  - Ne placez pas les aliments sur la sortie d'air et disposez les aliments de manière à permettre une bonne circulation de l'air.
  - Si vous souhaitez modifier le réglage du thermostat, ajustez le bouton de contrôle du thermostat d'un cran à la fois. Attendez quelques heures pour que la température se stabilise qu'après plusieurs heures suivant le changement de réglage.

Moule à glaçons

- Il est recommandé de régler la commande de température à la position « 5 » pendant le fonctionnement du congélateur.
- Remplissez le moule à glaçons (à 23 de la capacité) avec de l'eau froide et posez-le dans la partie inférieure du compartiment de congélation pour une congélation uniforme.
- Afin d'éjecter les glaçons du moule, positionnez-se-ellesce dun bac à glaçons et tordez légèrement.
- Réinitialisez la commande de température en la réglant à la position « 3».

Le congélateur

- Ce compartiment est conçu pour le stockage à long terme des surgelés.
- La durée de conservation des aliments surgelés varie, et il ne faut pas dépasser le temps de stockage recommandé.
- Mettez les surgelés au congélateur le plus tôt possible après l'achat. Respectez les instructions inscrites sur les produits congelés, surtout en ce qui concerne la durée de stockage.

Quand dégivrer

Ce produit n'est pas conçu pour un dégivrage automatique. Afin d'éviter d'endommager l'intérieur de l'appareil par une accumulation excessive de glace, veuillez faire un dégivrage manuel tous les 3 mois ou lorsque vous voyez que l'intérieur du compartiment du congélateur est recouvert d'une couche de glace d'environ ¼" d'épaisseur.

Comment dégivrer

Il convient de dégivrer le compartiment du congélateur dès que la couche de glace atteint environ ¼" d'épaisseur ou au moins tous les trois mois, selon le premier terme survenu. Réglez le bouton du thermostat sur « 0 » pour le dégivrage. Retirez toutes les denrées du compartiment du congélateur. Laissez la porte du congélateur ouverte pour accélérer la fonte de la glace. Retirez les plus importantes de glace à la « main ». Ne pas utiliser d'objets pointus pour éliminer la glace. Après le dégivrage, retirez l'accumulation de glace/eau et essuyez le compartiment du congélateur avec un chiffon doux. Attendez 30 minutes si vous ne voyez pas de glace dans le compartiment du congélateur. Il faut complétement dégivrer l'évaporateur situé derrière la paroi du congélateur pendant environ 2 heures avant de remettre l'appareil en marche. Réinitialisez l'appareil en suivant les instructions de mise en marche.

Modification de la lumière

NOTE: Toutes les pièces retirées doivent être enregistrées à la réinstallation de l'ampoule. Avant de retirer l'ampoule, débranchez l'appareil de l'alimentation électrique. Sinon, cela pourrait entraîner un choc électrique ou des blessures.

1. Remove le couvercle de la lampe en dévissant.
2. Dévissez l'ancienne ampoule de nous référrer à la boîte de commande du thermostat.
3. Replacez la nouvelle ampoule de la même tension et visser taille.
4. Réinstaller le couvercle de la lampe par vissage.

- **Poignée installation**
  - Retirez la poignée de l'appareil et retirez le sachet (deux poignées de part et 4 vis) utiliser le tournevis pour fixer le bas de la poignée sur la porte par quatre vis de pcs.
  - Poussez la poignée en horizontal et jusqu'à ce que le Mouvrée cuble sur le fond.
  - Poussez et tirez le levier pour s'assurer que la poignée est bien installée.

CHANGEMENT DE LA PORTE RÉVERSIBLE

ATTENTION : Pour éviter de vous blesser ou d'endommager du matériel, il est recommandé d'utiliser de l'aide pendant le processus de changement de sens d'ouverture de la porte.

Votre réfrigérateur est équipé d'une porte réversible. Vous pouvez choisir une ouverture à gauche ou à droite. Pour inverser le sens d'ouverture de la porte, suivez les instructions très simples ci-dessous.

1) Démontez toutes les pièces réversibles dans l'ordre indiqué ci-dessous (consultez également le diagramme ci-dessus à gauche). Veillez à bien les conserver pour le remontage.

(1) patte réversible II
(2) charnière inférieure
(3) patte réversible I
(4) 2 vis pour fixer la charnière de la porte
(5) 2 vis pour fixer la charnière inférieure
(6) porte du réfrigérateur
(7) charnière intermédiaire
(8) 2 vis pour fixer la charnière intermédiaire
(9) bouchon porte supérieure droite
(10) porte du congélateur
(11) charnière supérieure
(12) 2 vis pour fixer la charnière supérieure
(13) Couvercle de la charnière
(14) Pipe
(15) porte supérieure gauche bouchon

2) Pour accéder à la charnière inférieure, vous pouvez incliner le réfrigérateur vers l'arrière ou le placer à plat sur son dos.
3) Retirez le bouchon porte supérieure droite (9), installez la porte supérieure gauche bouchon (15) sur le côté opposé, prendre ainsi le bas la tête (réflecteur inférieur de la porte (4), et installez-la sur le côté opposé.
4) Remontez l'appareil avec les charnières de l'autre côté (consultez le diagramme ci-dessus). Remontez en suivant les étapes du démontage en ordre inverse.
5) Avec la charnière intermédiaire en place mais pas trop serrée, alignez bien les de