Sulle Warmer & Sterilizer
Manual de usuario
Calentador de toallas y esterilizador
Instrucciones de uso del calentador de toallas

HEARTFELT THANK YOU

Thank you for purchasing our product. We are a small family business and we are very grateful for your support. We are GROWISH. If there's ever anything we can do to improve your experience with our product or if you simply wish to share your thoughts, we'd be delighted to hear from you. Your satisfaction is our ultimate goal, and your feedback is invaluable in helping us refine and improve our offerings. Your satisfaction is our top priority, and we hope this is the moment GROWISH's engaged upon your journey with our exceptional product.

For any questions or inquiries, please contact us at:

www.growishhome.com

OR SEND **GROWISH** TO **JESSICAN-0456** 1

We wish you warm and cozy moments with your new product.

Warmly,
Founder
Founder of GROWISH 2

1.5L

Product Name: Sulle Warmer & Sterilizer
Material: Stainless Steel
Power Input: 8W
Power Output: 12V/0.67A
Size/Type: 220V
Recommended Humidity 60-80%
Recommended Temperature: 55-65°C
Product Capacity: 1.5L
Recommended Environment: Indoor
Product Capacity: 36PCS

1 2

Warning

Safety Warnings for Sulle Warmer:
Please read these safety instructions before using the Sulle Warmer:
- Ensure the Sulle Warmer is placed on a stable surface.
- Do not exceed the maximum capacity of towels.
- Keep the Sulle Warmer away from water and other liquids.
- Do not use the Sulle Warmer if the power cord or plug is damaged.
- Unplug the Sulle Warmer when not in use.
- Do not touch the heating elements while the Sulle Warmer is in operation.
- Keep the Sulle Warmer out of reach of children.
- Do not use the Sulle Warmer for any purpose other than warming towels.
- Do not modify the Sulle Warmer in any way.
- Ensure proper ventilation when using the Sulle Warmer.
- Do not cover the Sulle Warmer while it is in operation.
- Do not place the Sulle Warmer near flammable materials.
- Do not exceed the recommended humidity and temperature levels.

Note:
Keep the Sulle Warmer out of reach of children.

Caution

Sulle Warmer Cautions:
- Do not place the towels directly on the heating plate.
- Do not use the Sulle Warmer for more than 24 hours continuously.
- Do not use the Sulle Warmer in a humid environment.
- Do not place the Sulle Warmer in direct sunlight.
- Do not use the Sulle Warmer near a heat source.
- Do not use the Sulle Warmer if the water level is below the minimum line.
- Do not use the Sulle Warmer if the water tank is damaged.
- Do not use the Sulle Warmer if the heating plate is damaged.
- Do not use the Sulle Warmer if the temperature exceeds 65°C.
- Do not use the Sulle Warmer if the humidity exceeds 80%.
- Do not use the Sulle Warmer if the power cord is damaged.
- Do not use the Sulle Warmer if the plug is damaged.
- Do not use the Sulle Warmer if the Sulle Warmer is damaged.
- Do not use the Sulle Warmer if the Sulle Warmer is not functioning properly.
- Do not use the Sulle Warmer if the Sulle Warmer is not functioning properly.

Note:
Keep the Sulle Warmer out of reach of children.

3 4

Before figures are for Test, verified warming, 24H* poly for Standard, please refer to below detail description.

5 6

This Sulle warmer has smart sensors function. It will remember last time it ending it and your towels is set time again for next warming.

Fast & Sterilize

SRAMS 2: Fast Warming
Ideal for quickly warming a damp or clothed sulle and ensuring the sulle is sterilized for use.

Fast & Sterilize

Fast & Sterilize

Fast & Sterilize

Note:
The speed of warming sulle depends on the amount of water in the water tank, the ambient temperature, and the room temperature of the sulle. Huge temperature of 10 degrees difference will cause 10 minutes difference.

When you find the sulle is not warm enough, you can add more water in the water tank to increase the temperature of it. It takes about 5 minutes warming. This will make a slightly warmer result and without overheating.

7 8

Fast & Sterilize

Sulle Warmer Specifications					
Model	Capacity	Dimensions (L x W x H)	Power Input	Power Output	Weight
SRAMS 2	36 sulle	17.5 x 17.5 x 17.5 cm	220V	12V, 0.67A	1.5 kg
SRAMS 3	36 sulle	17.5 x 17.5 x 17.5 cm	220V	12V, 0.67A	1.5 kg
SRAMS 4	36 sulle	17.5 x 17.5 x 17.5 cm	220V	12V, 0.67A	1.5 kg
SRAMS 5	36 sulle	17.5 x 17.5 x 17.5 cm	220V	12V, 0.67A	1.5 kg
SRAMS 6	36 sulle	17.5 x 17.5 x 17.5 cm	220V	12V, 0.67A	1.5 kg

Note:
Function "Fast & Sterilize" is designed for both fast warming and sterilization. It is not suitable for only needs to a set different time to suit your purpose.

Sulle Warming&Sterilizing

SRAMS 2 - STERILIZE
Ideal for sterilizing sulle, ensuring they are clean and safe for use.

Sulle Warming&Sterilizing

Sulle Warming&Sterilizing

Sulle Warming&Sterilizing