BUTTONS FUNCTION

power
(turn on/off the TV)

source
(selects the available video inputs)

To the saved channel list

PRE-CH
(returns to the previous channel)

mute

volume up/down

channel up/down

channel lists

home

accesses to "netflix"

accesses to "prime video"

accesses to "hulu"

program guide

select button

return
(return to the previous menu)

exit the menu

info
(displays information on the TV screen)

settings