www.1more.com

1MORE

NAYIN Dual Drive Bluetooth® 5.0 In-Ear Headphones
User Guide

Power

Turn on/off: Take out the headphone (earbud) to remove, then hold earbud for 1 second to turn on/off.
Pairing: Take out the headphone (earbud) to remove, then hold earbud for 3 seconds to enter pairing mode.

Bluetooth Pairing

Pairing mode:
Take out both earbuds to automatically find the Bluetooth connection, then select "1More NAYIN" on your device's Bluetooth pairing list.

To Pair:
Take out the headphone (earbud) you want to pair and hold the power button for 3 seconds to enter pairing mode.

Placement

Fit

Charging

Put it back to the charging bin of charging. Charging time: 1.5 hours. Charging time for earbuds: 1.5hour charging, 15min charge half an hour, etc.

Controller Functions

Take out the headphone (earbud) to remove, then hold the controller for 2 seconds. Now listen the instructions to create basic functions.

* Only iOS compatible with extra Siri/AI assistant calls/Voice.

Open the charging case to wake headphones.

* Above functions may vary with different devices.

Extra Functions

Multi-point Connection: Connecting two Bluetooth sets to two devices at the same time.

Listening Time and Call time: Half the Ear Functions. The headphone (earbud) will automatically switch off.

Voice Prompt Control: Turning voice on/off, low, mid, high.

Voice Prompt Language: Chinese, English.

Voice Prompt Volume: Adjusting the Voice Prompt volume by 3 levels. Voice Prompt Language: Chinese, English.

Voice Prompt Content: Battery Status, Pairing Status, Volume Level, Incoming Call Notification, Hang Up Call, Reject Call, Pick Up Call, Siri/Google Assistant.

Safety Information

Water Resistance: IPX4 Sweat Resistance. There are no sets accessible for swimming.

1. Do not expose the headphones to temperatures below 0°C or 70°C. Do not use in rain or water.
2. Do not use the headphones in a dangerous area, for example, when driving or walking in busy traffic. Do not use the headphones when listening at high volume.
3. Do not use the headphones if they are damaged or if you feel a tingling sensation on your skin. Do not disassemble, modify or attempt to repair the headphones. Do not insert foreign objects into the headphones as this may damage them or cause injury to your ears.
4. Do not use the headphones in a dangerous area, where explosion may occur. Do not use the headphones in areas where electronic devices are prohibited, such as airplanes or in a car. Keep headphones away from children.

FAQ

1. My headphones don't turn on.
Charge the headphones and try again. If it still does not turn on, please contact the 1More Support Team.

2. My headphones and my device do not connect, or take a long time to connect.
Make sure your headphones are in Bluetooth pairing mode and your device has Bluetooth enabled.

3. My headphones are connected but there is no sound.
Check the volume on your device and headphones. Also check if your headphones are connected to the right device.

4. My headphones are connected but only one ear has sound.
Check if the other headphone is connected to your device. Make sure the volume is set to the same level for both headphones.

5. My Sound Quality is poor or sound keeps cutting out.
Move closer to your device. Remove any obstacles between your headphones and your device. Avoid using your headphones in areas with heavy wireless interference.

6. My Bluetooth connection is not stable, causing some disruptions.
Turn Bluetooth off and back on, then reconnect your headphones. Ensure your device's software is up to date.

7. My headphones and my device do not connect, or take a long time to connect.
Make sure your headphones are in Bluetooth pairing mode and your device has Bluetooth enabled.

8. My Sound Quality is poor or sound keeps cutting out.
Move closer to your device. Remove any obstacles between your headphones and your device. Avoid using your headphones in areas with heavy wireless interference.

9. My Bluetooth connection is not stable, causing some disruptions.
Turn Bluetooth off and back on, then reconnect your headphones. Ensure your device's software is up to date.

10. Unpaired the first device and connected the second device, but the second device's GM connection.
Please first unpair the second device, then pair the first device and the second device.

11. Unpaired the first device and connected the second device, but the second device's GM connection.
Please first unpair the second device, then pair the first device and the second device.

Warranty Product Warranty

1More provides a 1-year limited warranty for its products. Warranty coverage does not include damage caused by improper use, accidents, or unauthorized repairs. Warranty coverage does not include the cost of shipping the product to 1More for warranty repairs. Consumers are responsible for shipping costs. Warranty coverage does not include damage to the product caused by improper use, accidents, or unauthorized repair