XIAOMI Front Pocket Carry-on Luggage 20" User Manual - 01
Руководство пользователя чемодана Xiaomi Front Pocket Carry-on Luggage 20" - 02
Manual de usuario del Xiaomi Front Pocket Carry-on Luggage 20" - 03
Manuel d'utilisation du Xiaomi Front Pocket Carry-on Luggage 20" - 04
Xiaomi 20-inch handbagagerifle met vak voorzien
Bedienungsanleitung - 05
Xiaomi 40厘米横版登机箱 20 寸 使用说明书 - 06
Instrukcja obsługi Walizki podręcznej z przednią kieszenią 20" Xiaomi - 07
Manual do utilizador da Mala de Viagem de Cabina com Compartimento Frontal Xiaomi de 20" - 08
Xiaomi Önden Gözlü Kabin Bavulu 20 inç Kullanım Kılavuzu - 09
Xiaomi 20 Inch Front Pocket Carry On Luggage User Manual - 10
Xiaomi 20ليوتا بأمامية بجيب 20" دليل مستخدم حقيبة - 11
Xiaomi 20 inch Ön Cepli Kabin Bagajı User Manual - 12
Xiaomi Handgepäckkoffer mit Frontfaltasche 20" Bedienungsanleitung - 13
Manuale utente di Xiaomi Front Pocket Carry-on Luggage 20" - 14
Manual de usuario del equipaje de mano con bolsillo frontal de 20 pulgadas Xiaomi Front Pocket Carry-on Luggage 20" - 15
Xiaomi 20 Inch Ön Cepli Kabin Bagajı Kullanım Kılavuzu - 16
Xiaomi 20 pulldaja ees-taskuga käsipagasi kasutusjuhend - 17
Xiaomi 20 pulldaja avatavate suhtlemiseks mõeldud käsipagasi käsiraamat - 18

Read this manual carefully before use, and retain it for future reference.

Safety Instructions

- Do not put cash or valuable items in the luggage.
- Do not place the luggage, otherwise it may be over and cause personal injury.
- Do not place the luggage on uneven surface, otherwise it may be unpredictable.
- Do not move the luggage through its wheels or stem or bumo roads, to avoid personal injury or luggage turned over or damage.

Product Features

- PC Composite Material
- Foreseeable TSA Lock
- Front Pocket Design Allows for Easy Self-Pickup

Specifications

Xiaomi Front Pocket Carry-on Luggage 20"
Model: XMLGGH00
Shell Dimensions: 565 × 350 × 235 mm
Item Dimensions: 565 × 350 × 345 mm
Note:
The dimensions refers to the dimensions of the luggage with its handle completely retracted, including its wheels, handle, and side crack. Shell Dimensions refers to the dimensions of the shell excluding its accessories.

Product Overview

Exterior
Tag Handle · Front Cover · Side Table · Side Handle · Zipper · Wheels
Interior
Dry Pocket · Wet Pocket · Main Pocket · Outlet
Caution: The internal layer of the bottom of the luggage is used for maintenance only, please do not use it for storage, to avoid affecting the normal use of the luggage.

TSA Lock Instructions

Locking Mode · Push Button ID · Locking Hook · Open Button ID · Reset Button ID
The initial code of the lock is set to 0-0-0-0. It is recommended to set a personal code, please follow the steps to reset the code:
1. Set the new 3位 to 0-0-0-0 to unlock the lock.
2. Turn the dial 3位 to set your personal code (such as 8-8-8-8), then press the button ID on your personal code (such as 8-8-8-8).
3. Push the button ID to the left or right along the direction indicated by the arrows to lock the lock. Please remember your code.
4. Turn the dial 3位 to the initial code (0-0-0-0) to unlock the lock. If you need to reset the code, again repeat steps 1-3.

Caution

If you forget your code, you need to open the lock, or open the luggage. Therefore, be sure to remember your code.

Cautions

- Do not lift the luggage by pulling its telescopic handle.
- Do not press the push button on the telescopic handle when moving the luggage.
- Do not release the luggage to rest flat on ground personal. The luggage is resistant to accidental splashes of water during normal use, but it is not completely waterproof. When the luggage gets wet, promptly wipe it dry so as to prevent any water from getting inside.
- Do not use the luggage near high-temperature objects, such as stoves or heaters, so as to prevent the deformation of the shell or accessories.
- Do not scrub the luggage with corrosive solvents such as benzene or petroleum, or alcohol, otherwise the shell or accessories may deform.
- Do not place the luggage in high sun or high humidity environments, as this may damage the lock or other metal components and prevent the normal use of the luggage.
- When storing the luggage in high humidity, make sure it does not fall down, so as to avoid mildew or damage to the luggage or its contents.
- It is recommended to use a protective cover (sold separately) to prevent damage to the luggage during transit.

EU REP:
Xiaomi Technology Netherlands B.V.
Prinses Beatrixlaan 582, 2595BM The Hague, The Netherlands
contact@support.mi.com

UK REP:
Xiaomi Technology UK Limited
Devonshire House, Finsbury Square, Reading, Berkshire RG1 1EU
contact@support.mi.com

Manufacturer: Xiaomi Communications Co. Ltd.
Manufacturer's Address: Shanghai Xiaomi Technology Co., Ltd.
Lot 96 Ecosystem Industrial
Address: Room 1601-1 Building No.16, No.108 of Xinshun Rd, Songjiang District, Caohejing Hi-tech Park, Shanghai, China
For further information, please go to www.mi.com
User Manual Version: V1.0
Made in China

Перед использованием внимательно прочтите это руководство. Сохраните его на случай последующего использования.

Инструкции по безопасности

- Не перевозите в чемодане денег и ценные вещи.
- Не ударяйте чемоданом по ногам! Чемодан может травмировать вас.
- Не ставьте чемодан на неровную поверхность, в противном случае он может упасть.
- Не перемещайте чемодан на колесиках по застежкам или неровным дорогам, во избежание травм, случайного опрокидывания или повреждения.

Характеристики изделия

- Композиционный поликарбонат материал
- Гарантированный замок TSA
- Конструкция передней карманной для удобного извлечения вещей

Технические характеристики

Название: Xiaomi Front Pocket Carry-on Luggage 20"
Модель: XMLGGH00
Размеры корпуса: 565 × 350 × 235 мм
Размеры изделия: 565 × 350 × 345 мм
Примечание:
Размеры относятся к размерам багажа с полностью выдвинутой ручкой, включая колеса, ручку и боковую трещину. Размеры корпуса относятся к размерам корпуса, исключая аксессуары.

Описание изделия

Внешний вид
Передняя фронтальная крышка · Боковая ручка · Боковая ручка · Колесики · Ручка · Молния
Внутренняя часть
Сухая зона для вещей · Мокрая зона для вещей · Основная зона · Отверстие
Предупреждение: Внутренний слой внутренней части багажа предназначен только для обслуживания. Не используйте его для хранения и повреждения обычного использования багажа.

Инструкция для замка TSA

Фиксирующий замок · Кнопка открытия · Кнопка сброса · Фиксирующий крючок
Начальный код замка 0-0-0-0. Рекомендуем сменить начальный код, чтобы сбросить код, выполняйте следующие шаги:
1. Поверните кодовые колеса 3位 на 0-0-0-0, чтобы открыть замок.
2. Поверните 3位 колесо, чтобы установить свой код (например, 8-8-8-8), затем нажмите кнопку сброса.
3. Нажмите кнопку сброса 3位, установленную на свой личный код (например, 8-8-8-8). Сдвиньте кнопку в направлении, указанном стрелками, чтобы закрыть замок. Запомните свой код.
4. Чтобы открыть замок, поверните 3位 колесо на начальный код (0-0-0-0). Если вам нужно сбросить код, повторите шаги 1-3 заново.

Предостережение

- Не подвешивайте чемодан за телескопическую ручку.
- Не нажимайте чемодан на телескопическую ручку.
- Не перемещайте чемодан на колесиках по застежкам или неровным дорогам, во избежание травм, случайного опрокидывания или повреждения.
- Не ставьте чемодан на ровную поверхность, в противном случае он может упасть.
- Не ставьте чемодан на колесиках или ручку, во избежание травм.
- Не ставьте чемодан на колесиках или ручку на ровную поверхность, в противном случае чемодан может упасть