FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.The device has been evaluated to meet general RF exposure requirement. The devic can be used in portable exposure condition without restriction.
The device must not be co-located or operating in conjunction with any other antena or transmitter.

Guangzhou DK Electronic Technology Co. , Ltd.
Manufacturer: Zhuhai DK Electronic Technology Development Co. , Ltd.
Address: Room1601A, Building A, Dazhou Science Park, No.1 Gangle Road, Hi-Tech Zone, Zhuhai, Guangdong, China
Tel: +86-756-3666689
Website:www.dk-music.cn
Made in China

广州大咖电子科技有限公司
GuangZhou DK Electronic Technology Co., Ltd.
制造商：珠海大咖电子科技开发有限公司
地址:珠海市高新区港乐路1号大洲科技园A座1601A
电话:0756-3666689
公司网址:www.dk-music.cn

萨克斯无线系统

直播/内录/混响

MP-10Pro

产品介绍

欢迎使用 DK MP-10Pro萨克斯无线系统

针对萨克斯音频曲线进行优化设计，运用DSP音频数字信号处理技术，高保真还原萨克斯原声音色

① UHF通讯频段，可多套同时使用

② 无障碍传输可达40米，延迟低

③ 内置混响，可调节混响的空间和干湿比例

④ 三种动态频率调节，适合高音、降E、降B三种萨克斯

⑤ 支持蓝牙连接、耳机监听、麦克风输入、声卡内录、直播

⑥ 鹅颈麦克风配备硅胶减震功能，有效消除按键音

⑦ 充电收纳盒，便捷续航，一键开启充电，可为手机充电

⑧ 适用多种音域的萨克斯、小号、圆号等乐器

产品部件

① 发射器

② 接收器（卡侬接口）

③ 充电仓（可当移动充电宝）

④ 鹅颈麦克风

⑤一出二充电线

⑥ 内录线（1.5m）

⑦Type-C 转3. 5音频转接头



Product Specifications

Product Name: DK Saxophone Wireless System
Model: MP-10Pro
Communication Frequency Range: UHF Band (657.3MHz- 661.2MHz)
Frequency Response: 20HZ-18KHZ
Audio Dynamic Range: ≧106dB
Sample Rate and Accuracy: 48KHZ/16bit
Latency: ＜5ms
Signal Distortion: ＜0.5%
Sensitivity: ＜-108dBm @12dB SINAD
Transmitter Battery Capacity: ＞950mAH/3.7V
Receiver Battery Capacity: ＞500mAH/3.7V
Charging Case Battery Capacity: 5000mAH/3.7V
Transmitter/Receiver Battery Life: Approximately 5 hours
Dimension (Length : x Width x Height):
Charging Case: 137.95*94.95*36.64 mm
Transmitter: 60.00 x 45.00 x 25.68mm
Receiver: 66.08 x 27.58 x 21.01mm

Safety Guidelines

1.Before installation and use, please read the user manual thoroughly.
2.This product has a built-in lithium battery. To ensure better performance, it needs to be charged and activated once every six months.
3.This product is a high-precision electronic device. Unauthorized modifications are strictly prohibited; otherwise, the warranty will be automatically voided.
4.Store the product in a well-ventilated and dry environment. Avoid exposure to moisture or extreme temperature conditions.
5.Prevent any foreign objects or any type of liquid from entering the device, such as flammable materials, water, soft drinks, etc.
6.To avoid noise and interference issues, please refrain from using other brands of wireless transmission products alongside this device.
7.When the product is not in use for an extended period, please turn off the power switch. If you need to charge it, use a charger with a voltage of 5V/2A. Additionally, when the battery level is critically low, it is necessary to turn off the power switch before charging.
8.To ensure the proper operation of the device and avoid interruptions during your performance, check the battery status of the device eight hours before the performance. If the battery level is insufficient, charge it promptly. To extend the device's lifespan, charge it every 2-3 months.during your performance, check the battery status of the device eight hours before the performance. If the battery level is insufficient, charge it promptly. To extend the device's lifespan, charge it every 2-3 months.It is strictly prohibited to leave the product powered on without shutting it down, which may lead to excessive discharging.
9.This product has a built-in lithium battery. Avoid exposing the battery to excessive heat sources, and make sure to dispose of used batteries in accordance with local regulations for safe disposal of electronic waste.
10.Do not attempt to repair this device or replace internal components. If any repairs are needed, please contact your retailer or authorized service center for assistance.

Quality Assurance

Dear User,

Hello! When using DK products, please carefully review the product manual. If you encounter any difficulties or have questions, please reach out to your local authorized dealer.
Official Phone: +86-756-3666689
Official Website: www.dk-music.cn
We are here to assist you with any inquiries or concerns you may have.
Thank you for choosing DK products.
Sincerely,
Guangzhou DK Electronic Technology Co.,Ltd

Certificate of Quality

Inspector 合格证

Product's name Saxophone Wireless System
Model MP-10Pro
This product has passed the inspection

安装使用方法

1.先将鹅颈麦克风插入发射器顶部，并将其拧紧
2.将发射器固定在萨克斯风管口，向下拉动发射器往里推
3.弯下鹅颈麦克风，使咪头指向萨克斯的喇叭口，并保持适中距离
4.将接收器插入音箱、调音台或声卡的卡侬接口即可开始使用



安装使用示意图

功能说明



⑤ Internal Recording With a Sound Card

In normal working conditions, you can use a data cable to connect one end to the "CATCH" button on the transmitter and the other end to a computer to achieve internal recording with a sound card.



⑥ Battery Status Instructions

Function	Operation Introduction
Low Battery Warnin	When the battery is low, the indicator light on the transmitter or receiver will turn red. In such a case, it is important to immediately charge the device to ensure proper functioning.
Storage and Charging	①When placing the product into the charging case, it will automatically start charging. The device's indicator light will be green during the charging process, and when it is fully charged, the device's indicator light will turn off. ②If you wish to stop charging manually, you can do so by double-clicking the "Manual Charging Switch" twice, which will turn off the charging. The charging case's indicator light will also turn off. ③The charging case's indicator light will be green and show a full battery when it's fully charged. If the battery level is only one bar, please charge it promptly.  Manual Charging Switch ④When charging the charging case, the indicator light will stay steadily lit in green. It will automatically turn off when it's fully charged (please use a charger with a voltage of 5V/2A).  ⑤The charging case can also serve as a portable power bank and can be used to charge external devices through the "External Device Interface. ⑥You can use the included dual-head Type-C charging cable to directly charge the transmitter and the charger separately. The indicator lights will automatically turn off when they are fully charged.

充电仓





① 开关与连接

功能	操作方法
发射器-开机/关机	发射器短按一秒【CATCH】键开机或关机 开机时指示灯亮，关机时指示灯熄灭，无信号时自动关机
接收器-开机/关机	接收器短按一秒【CATCH】键开机或关机 只要设备配对中，成功连接时指示灯常亮青色，未连接时指示灯慢闪青色，关机时指示灯熄灭
蓝牙	设备开机状态下，发射器【BT蓝牙】长按一秒开启蓝牙功能，指示灯呈蓝色闪烁，请使用您的手机设备打开蓝牙并搜索系统名称“DK.Audio”，然后选择配对，蓝牙连接成功时指示灯常亮蓝色
U段配对连接	发射器【CATCH】键长按十秒进入配对模式，指示灯亮绿灯后呈快闪状态，连接成功时常亮绿色。接收器【功能键】则需短按一秒，指示灯常亮青色，自动完成U段配对连接
跳频	当多套设备或有外部同频设备使用情况下，可双击发射器【CATCH】键，有效避免信号干扰
耳麦孔	支持麦克风和监听功能

②Scene Modes:

While the device is in normal operating mode, you can easily switch between different sound scenes to adapt to different saxophone types by short-pressing the "CATCH" button on the transmitter. When the device is powered on and paired correctly, the working status indicator lights on the transmitter and receiver will stay steadily lit in blue.



Function	Indicator light remains on
Alto Saxophone Scene (Default)	Cyan ●
Tenor Saxophone Scene	Yellow ●
Soprano Saxophone Scene	Purple ●

③ Reverb Sound Effect Mode

Function	Operation Introduction	Tips
Reverb Adjustment	In the three scene modes, you can freely adjust the reverb space and wet/dry ratio.	Scroll the "Reverb Adjustment" slider upward to increase the effect, and downward to decrease or disable the effect.

④ Live Recording

When the transmitter is in normal working condition, you can use the included charging adapter cable to enable monitoring, recording, and live streaming functions.



The above is the live microphone diagram

② 场景模式

设备在正常工作状态下，您可以短按发射器【CATCH】键即可切换不同的音色场景来适配萨克斯风的类型。本机正常开机并配对后，发射器与接收器的工作状态指示灯呈青色常亮状态



功能	指示灯常亮
中音萨克斯场景(默认)	青色 ●
次中音萨克斯场景	黄色 ●
高音萨克斯场景	紫色 ●

③ 混响音效模式

功能	操作方法	提示
混响调节	在三种场景模式下，可以任意调节混响空间和干湿度比例	滚动【混响调节】滑钮，向上为增大效果，向下为减小或关闭效果

④ 直播内录

发射器在正常工作状态下，您可以使用标配中的充电转接线实现监内录直播功能



以上为麦克风直播图解

Charging Bin



① Switching On and Connecting

Function	Operation Introduction
TX Power On/Off	Press the transmitter for one second to power on or off.When powered on, the indicator light is on, and when powered off, the indicator light is off. When there is no signal, it will automatically power off.
RX Power On/Off	Press the "CATCH" button for one second to power on or off. When the device is in the pairing mode, the indicator light will be steadily lit in blue when successfully connected. When not connected, the indicator light will slowly flash in blue, and it will turn off when powered off. It can be connected to an external mobile device.
Bluetooth	With the device powered on, long-press the "BT(Bluetooth)" button on the transmitter for one second to activate the Bluetooth function. The indicator light will start flashing in blue. Please use your mobile device to turn on Bluetooth and search for the system named "DK.Audio." Then select "Pair," and when the Bluetooth connection is successful, the indicator light will stay steadily lit in blue.
Pairing and Connecting in the U Segment	To enter pairing mode for the transmitter, long-press the "CATCH" button for ten seconds. The indicator light will turn green and then start flashing rapidly. When the connection is successful, it will stay steadily lit in green. For the receiver, you should press the "Function" button for one second. The indicator light will remain steadily lit in blue, automatically completing the U segment pairing connection.
Frequency Hopping	When using multiple sets of devices or in the presence of external devices operating on the same frequency, you can double-click the transmitter's "CATCH" button to effectively avoid signal interference.
Headphone Interface	Supports microphone and monitoring functions.

⑤ 声卡内录

发射器在正常工作状态下，您可以使用数据线一端连接发射器【CATCH】键，另一端连接到电脑，即可实现声卡内录



⑥电量提示说明

功能	操作方法及提示
低电提示	低电时，发射器或接收器的指示灯显示红色，请立即为本机充电
收纳及充电	①将产品放入充电仓内时自动充电，充电状态下，设备指示灯为绿色，充满电时设备指示灯熄灭 ②如果不充电，双击两下【手动充电开关】为关闭充电，充电仓指示灯熄灭 ③充电仓绿灯满格为满电状态，电量仅剩一格时，请及时充电 ④给充电仓充电时，指示灯绿灯常亮，充满后自动熄灭(请使用充电电压5V/2A的充电器)  手动充电开关 ⑤充电仓可当移动充电宝，可以连接【外接设备接口】充电  ⑥可以使用附赠的双头Type-C充电线分别为发射器和充电器直接充电，充满电后指示灯自动熄灭

Using Gudance

1.Please put the Microphone and plug into the top of the Transmitter and fix it.

2.Fix the Transmitter on the outlet of Saxophone, pull the transmitter down and push - shown as picture.

3.Bend the Microphone down, make it to the bell and stay in a best situation.

4.Put the Receiver into the amp, Sound console or Sound card, then, you can enjoy it.



USING GUIDANCE

Function



产品参数

产品名称：DK萨克斯无线系统
型号：MP-10Pro
通讯频段：UHF频段（657.3MHz～661.2MHz）
频响:20HZ-18KHZ
音频动态范围：≧106dB
采样率及精度：48KHZ/16bit
延迟时间：＜5ms
信号失真度：＜0.5%
灵敏度：＜-108 dBm@12 dB SINAD
发射器电池容量：＞950mAH/3.7V
接收器电池容量：＞500mAH/3.7V
充电收纳盒电池容量:5000mAH/3.7V
发射器/接收器电池使用时长：约5小时
尺寸（长x宽x高）
充电收纳盒：137. 95x94. 95x36. 64mm
发射器：60.00x45.00x25.68mm
接收器：66.08x27.58x21.01mm

注意事项

1、安装和使用前，请详细阅读说明书
2、本产品内置锂电池，为保证产品更好的使用，需要六个月充电激活一次
3、本产品属于高精密电子产品，禁止私自改装，否则将视为自动放弃保修
4、通风干燥下保存，切勿受潮或放置在极端温度的环境下
5、防止任何物品或任何类型的液体进入本设备内，例如可燃材料、水、软饮等
6、为避免出现噪声及串扰问题，请尽量避免将其他品牌的无线传输产品与本设备一起使用
7、本产品长时间不使用时，请关闭电源开关；如需充电，请使用充电电压5V/2A的充电器，同时当电量过低时，必须关闭电源开关在进行充电
8、为确保设备的正常使用，不耽误您的演出行程，请在演出前八小时检查设备的电量情况，电量不足请及时充电；为了更好的延长设备使用寿命，每隔2-3个月为设备充一次电，产品严禁开机后不关机产生过度放电现象
9、本产品内置锂电池，避免电池接触过高热源，同时必须按照您所在地区关于废旧电池安全弃置的规定弃置废旧电池
10、请勿尝试维修本设备或更换内部零件，进行任何维修时，请联系您的零售商

质量承诺

亲爱的DK用户：
您好，在您使用DK产品时，请仔细参阅产品说明书，当有任何疑难问题时，请添加售后服务二维码

官方热线：0756-3666689
官方网址：www.dk-music.cn

售后二维码

换修政策

一、包换政策：
1.消费者自购机之日起1个月之内，在正常使用情况下出现非人为的产品性能故障、且产品外观及包装保持完好，可向所购机的经销商换机
2.消费者在换机时，应出示由经销商开出的购机收据及保修卡，否则经销商可以不予更换
二、保修政策：
产品自购买之日起1年内，可免费享有维修服务。对于超过1年或人为及不可抗力因素造成损坏的产品，我司可提供有偿维修服务

合格证

检验员 合格证

名称 萨克斯无线系统
型号 PM-10Pro
本产品经检验合格

Product Introduction

Thanks for purchasing DK MP-10Pro Saxophone Wireless System Optimized for the saxophone audio curve, using DSP audio digital signal processing technology for high-fidelity reproduction of the saxophone's original sound.

1.UHF communication frequency range, allowing multiple sets to be used simultaneously.

2.Unobstructed transmission up to 40 meters with low latency.

3.Built-in reverb effect function, adjustable reverb space and dry/wet ratio.

4.Three dynamic frequency adjustments, suitable for soprano, alto, and tenor saxophones.

5.Supports Bluetooth car connection, headphone monitoring, microphone input, internal recording, and live streaming.

6.Gooseneck microphone with silicone shock absorption function effectively eliminates key noise.

7.Charging storage case for convenient and extended battery life, one-button charging activation, and the ability to charge your phone.

8.Suitable for a variety of instruments in different ranges, including saxophones, trumpets, and French horns.

Components of the product:

①Transmitter
②Receiver (XLR interface)
③Charging case (can also be used as a portable power bank)
④Gooseneck microphone
⑤One-to-two charging cable
⑥Internal recording cable (1.5m)
⑦Type-C to 3.5mm audio adapter