良值 IINE

Pictures above for refence only

WIRELESS CONTROLLER

C E

## Button Layout

**Description of Switch button layout differences:**

[Share] = [−]　　[options] = [+]

[PS] = [Home]　　Touch pad =screenshot

## Instructions Before Use

Before using the controller, it is important to follow these preparation steps to ensure optimal performance and functionality.

### Compatibility

PS3/PS4 | Phone/Pad | Switch | PC

Note: Can only support native gamepad games on iOS APP Store

### Check steps

**1.Package Checking**
Before using the product, please check that everything is complete. Open the package and inspect the product and accessories for completeness and condition. If you find any issues or missing items, contact our customer service immediately for assistance.

**2.Controller Inspection**
Before proceeding with the setup, check that the controller is in good condition and has no obvious damage or cracks.

**3.Check the Hardware**
Check if the buttons are not sticking, the joysticks rotate smoothly, and the trigger buttons operate seamlessly.

**4.Reading the Product Manual**
Before using the product, carefully read the instruction manual. It provides essential information, usage guidelines, and important considerations. Thoroughly understanding the manual helps grasp the product's features, functions, and prevents unnecessary mistakes.

**5.Power Supply and Charging Cable Checking**
Examine the included charging cable for any issues. Firstly, inspect its appearance for abnormalities. Next, connect the charging cable to the charger and assess its functionality to ensure there are no issues.

**6.Environment**
When using the product, it's crucial to ensure the safety of the operating environment. For instance, extreme temperatures or high humidity may impact its performance. Before usage,assess the operating environment and take necessary safety precautions.

## How to Connect

### Connection to PS3/PS4

**Wired Connection**

For the first connection of this controller to a PS3/PS4, use the included USB cable to connect the controller to the console.

**Wireless Connection**

(Must be wired connection first to activate wireless mode): Press and hold the [PS] button until the top LED indicator flashes briefly then stays on.

### Connection to Switch

**Wired Connection**

- Wired Connection in TV Mode: Use the included USB cable connect controller and Switch console. The top LED will flash briefly then stay on once connected successfully. (In wired connection to Switch, the controller supports 3.5mm audio.)

Hold on
[Home]
Hold on
[Home]
Hold on
[Home]