CELLRY

Wet and dry vacuum floor washer

KC-W01-US

Instruction Manual

Please read the instructions carefully before using the appliance

IMPORTANT SA FEGUARDS

1. The appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Cleaning and user maintenance shall not be made by children.Keep children and pets away and do not allow children to play with the appliance. Children should be supervised to ensure that they do not play with the appliance.
2. Do not use the appliance on pets and the appliance.
3. Unplug from electrical outlet when not in use, before cleaning, maintaining or servicing the appliance, and if your appliance has an accessory that is not functioning, before connecting or disconnecting the tool.
4. Do not pull the cord to unplug the appliance.
5. Keep cord, cleaning fluids, and all parts of body, away from spinning and moving parts of the appliance and its accessories.
6. Do not use the appliance in the rain.
7. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
8. Do not use the appliance without its accessories. Accessories: The batteries can explode or burn.
9. The battery is to be disposed of safely.
10. The battery should be replaced only by a person qualified to do so.
11. Under abnormal conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.
12. Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
13. Locking charge the electrical socket when not in use, before cleaning, maintaining or servicing the appliance, and if your appliance has an accessory tool which is not functioning, before connecting or disconnecting the tool.
14. The battery must be removed from the appliance before it is scrapped.
15. Do not use the appliance in an explosive atmosphere, such as in the presence of flammable liquids or gases or combustible dust. Do not use the appliance in temperatures below 0°C or above 40°C.
16. Do not use the appliance in extreme temperature conditions. Exposure to fire or temperature above 130°C may cause explosion.
17. Follow all charging instructions and do not charge the appliance outside of the temperature range specified in the battery; and recheck the risk of fire.
18. Avoid overcharging; overcharge is a significant hazard, proceed carefully. Overcharge may cause the battery to explode and cause a fire.
19. Do not modify or attempt to repair the appliance, except as indicated in the instructions for use and care.
20. Do not use the appliance outside range of between 0-40°C, when charging battery, storing unit or storing tool.
21. Plastic: Prone to be dangerous. To avoid danger of suffocation, keep away from children.
22. Use only as described in this user manual.
23. Use only manufacturer's recommended attachments.
24. Do not use the appliance if the cord or plug has been damaged, damaged, left outdoors, or dropped into water. If the cord is damaged, it will have to be replaced at a authorized service center.
25. Do not pull on or carry the cord to carry the appliance.
26. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
27. Do not pick up liquids.
28. Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas in which they are present.
29. Do not pick up toxic material (chlorine bleach, ammonia, drain cleaner, etc).
30. Do not use appliance in an enclosed space filled with vapors given off by oil based paint, paint thinner, moth proofing substance, flammable dust, or other substance of this nature.
31. Do not pick up hard or sharp objects such as glass, nails, screws, coins, etc.
32. Do not use as a sprayer. Use only for cleaning or mixing, such as cigarettes, cinders or hot ashes.
33. Do not use without filters in place.
34. Do not disassemble.
35. Do not store the appliance at the place where may rust.

KNOW YOUR VACUUM CLEANER

INSTRUCTION FOR FLOOR BRUSH

INTRODUCTION FOR CONTROL PANEL

INTRODUCTION OF THE APPLIANCE

The appliance is radically large. For the convenience of transportation and storage, the charger, the handle and the body are packaged separately. Please follow the steps below to assemble the appliance before the first use.

Installing a STANDOUT FOR BODY AND THE HANDLE

Insert the handle into the corresponding position of the body and fasten it with screws. Insert the charger into the corresponding position of the handle and fasten it with screws after you hearing a sound of "click" (see Fig.1).

Fig.1

INTRODUCTION FOR THE BODY AND THE DIRTY WATER TANK

Insert the dirty water tank into the corresponding position of the front end as shown in Fig.2. There is a sensor in the dirty water tank, and the dirty water tank is installed well in position after you hearing a sound of "Click" (see Fig.3).

Fig.2

INTRODUCTION FOR THE ROLLER BRUSH

Insert the roller brush into the corresponding position at the front end as shown in Fig.3. There is a sensor in the roller brush, and the roller brush is installed well in position after you hearing a sound of "click" (see Fig.3).

Fig.3

INTRODUCTION FOR THE ROLLER BRUSH COVER

Insert the roller brush cover into the corresponding position of the front brush as shown in Fig.3. There is a sensor in the roller brush cover, and the roller brush cover is installed well in position after you hearing a sound of "Click" (see Fig.3).

Fig.3

OPERATION

CHARGE THE APPLIANCE

1. Insert the charger into the socket.
2. Put the appliance into the charger, and the battery indicator lamp on and the appliance enters into the charging condition. A red light charging is flicked after the battery indicator lamp on, it is charging.
3. After Fully charged, unplug the adapter.

Fig.4

4. If you want to activate the auto clean function to clean the applicators, follow the operation as below. Firstly, put the appliance into the charger to perform charging, and then press the power button for 3 seconds to activate the auto clean function. The UV light and the Eight Fog will start flickering and flickering during the auto clean process.

NOTE: The auto clean function can be only activated when the appliance is being charged.

CLEANING THE DIRTY WATER TANK AND THE ROLLER BRUSH

1. Empty the dirtwater of the water tank and remove the roller brush. Wash the dirty water tank and the roller brush with clean water.

Fig.5

2. Remove the UV lamp cover tank and then empty the dirty water tank (see Fig.5).

Fig.5

TROUBLESHOOTING

If you have found some abnormal conditions, you can check the below sheet in the following table before contact authorized agency for repair.

Abnormal condition	Check the Sheet
The vacuum cleaner cannot work	1. Please check if the appliance needs to be charged. 2. Please check if the appliance is switched on and if the power switch button is in the off position. 3. Please check if the dirtwater tank has been installed well in position.
The suction force is degraded and absorbed more and more	1. Please check if there are foreign objects at the inlet. 2. Please check if the dirty water tank has been overfilled and 3. Please check if the dirty water tank and filtration cloth has been blocked.

ENVIRONMENTAL PROTECTION OPERATION

Please recycle the product to protect the environment.
Dispose of the product in accordance with local regulations.
Hand in the non-working electrical equipment to an appropriate waste disposal center.

PRODUCT SPECIFICATION

Product name	KC-W01-WHITE-EN
Product size	30.5*8.5*12.5cm
Product weight	1.5kg
Dimensions of Product (pack)	30.5*8.5*12.5cm
Power	20W

A LIMITED ONE YEARS WARRANTY

This product is covered by a limited one years warranty. If you have any problems with this product, or questions under the warranty, please contact us through better worldwide. And the benefits of supporting Lifetime Warranty

HOW TO UPGRADING WARRANTY

Contact CELLRY Service Center with your Name, Amazon Order and Product Model Number.

US Market

Visit **Cellry@Outlook.com** to contact the service center.

Visit CELLRY Official Site or Message us through the service center.

UK Market

Visit **Cellry@Outlook.com** to contact the service center.

Visit CELLRY Official Site or Message us through the service center.

CELLRY

型號 KC-W01-US
乾湿両用家用掃除機

取扱説明書
Instruction Manual

ホワイト商品登録をお日頃ご愛顧いただき誠にありがとうございます。ご注文日、ご注文番号とご登録されたEmail、ご注文されたAmazonアカウントを明記して登録されますと、ホワイト商品登録ページにて、ホワイト保証期間を延長することができます。ホワイト保証期間は、ご購入日から1年間です。ホワイト保証期間を延長することで、ホワイト保証期間は、ご購入日から2年間となります。ホワイト保証期間を延長することで、ホワイト保証期間は、ご購入日から3年間となります。

ホワイト保証期間を延長するには、商品名、商品番号、ご注文番号、ご登録されたEmail、ご注文されたAmazonアカウントを明記して、ホワイト商品登録ページにて、ホワイト保証期間を延長してください。

ホワイト商品登録ページ：https://www.better-ltd.com/pages/white-product-registration

ホワイト保証期間を延長するには、商品名、商品番号、ご注文番号、ご登録されたEmail、ご注文されたAmazonアカウントを明記して、ホワイト商品登録ページにて、ホワイト保証期間を延長してください。

ホワイト商品登録ページ：https://www.better-ltd.com/pages/white-product-registration

製品説明

取り付け方

取り付け方

ボタンでローラーブラシを取り外します。

取り付け方

製品仕様

品番型式	KC-W01-WHITE-EN
本体寸法	30.5*8.5*12.5cm
バッテリー容量	5Ah
バッテリー電圧	20V
バッテリー	Li-ion 18650*4PCS
充電時間	5-6hours
作動時間	15-20min
吸引電圧	1.8kpa
吸引力	20W
本体重量	1.5kg
電源コード	1.5m ~ 1.8m(AC ~ DC)3.5
電源タイプ	7.5cm ~ 7.8cm ~ 7.8cm
充電時間	2.5-3h
充電時間	480min ~
動作周波数	2.4GHz

保証に関する注意事項

保証は1年間（ご注文日を基準とします）です。（輸入業務法人の場合は、ご注文日を基準とします。）ご注文日を証明するものとしては、Amazonの注文番号、商品名、商品番号、ご注文されたAmazonアカウントを明記して、ホワイト商品登録ページにて、ホワイト保証期間を延長することができます。（ホワイト商品登録ページは、上記に記載されています。）

ホワイト商品登録ページ：https://www.better-ltd.com/pages/white-product-registration

個人情報の利用目的について

製品保証期間内に問題発生した場合の動作確認と修理のため、下記情報をCELLRY Service Center（以下、CELLRY）に提供することがあります。CELLRYは、下記情報を修理のみに使用します。

1. ご注文日、商品名、商品番号、ご注文番号、ご登録されたEmail、ご注文されたAmazonアカウント
2. 商品の不具合内容、修理内容、修理日、修理担当者名

CELLRYは、下記の場合のみ、第三者に提供することがあります。

1. 法令に基づく開示を求められた場合
2. 人の生命、身体または財産の保護のために必要であると判断した場合

CELLRYは、個人情報の取扱いを、CELLRYの個人情報保護方針に従って適切に取り扱います。詳細は、CELLRYのWebサイトに掲載されている個人情報保護方針をご参照ください。

CELLRYの個人情報保護方針：https://www.better-ltd.com/pages/privacy-policy

個人情報のお問合せ先：Cellry@Outlook.com