Pairing AirFly with AirPods	1
Pairing AirFly with Wireless Headphones	4
Volume Control & Mute	10
Battery Indicator	11
Turning AirFly On & Off	12
Reconnecting Headphones to iPhone	13
Charging	14
Tips & Tricks	15
Status Light Guide	16

Pairing AirFly with AirPods

1. To enter Pairing Mode on AirPods, first **place AirPods inside the Charging Case** and open the lid. Then, press and hold the Rear Button. Open the Charging Case and the light flashes white.

2. Turn AirFly on by sliding the ON/OFF switch up. The AirFly will automatically enter Pairing Mode and the light will go into a pulsing white and amber light.

Note: To re-pair or reset AirFly to the factory settings, press and hold the Pairing Button for five seconds to enter Pairing Mode.

For easiest pairing, first turn off Bluetooth connections on other devices (including your phone).

3. Once successfully paired, the light on AirPods Charging Case will turn green and the light on AirFly will be solid white and turn off after 10 seconds.

4. Plug AirFly into any device with a standard headphone jack to audio wirelessly.

5. If you take up to 90 seconds to re-pair AirPods, Apple will remember your AirPods when reconnecting in the future.

Pairing AirFly with Wireless Headphones

1. Turn AirFly on by sliding the ON/OFF switch up. The AirFly will automatically enter Pairing Mode and the light will turn on, indicated by the flashing white and amber light.

Note: To re-pair or reset AirFly to the factory settings, press and hold the Pairing Button for five seconds to enter Pairing Mode.

For easiest pairing, first turn off Bluetooth connections on other devices (including your phone).

2. Put your headphones into Bluetooth Pairing Mode (refer to your headphones' owner's manual for more details).

3. Once successfully paired, the light on AirFly will be solid white and turn off after 10 seconds.

*If you take up to 90 seconds to re-pair headphones, Apple will remember your headphones in the future.

Airfly Volume Controls & Mute

To adjust the volume of AirFly, press Volume. Balance (up "+" or down "-"). The can also press and hold the Volume button (up "+" or down "-") to gradually increase the desired volume until it reaches its max level is reached.

Press the Volume button simultaneously double-click Volume Down button. Light will flash amber continuously to let you know Volume is MUTED.

Double-Click Volume Down again to unmute audio and return to previous volume setting.

Battery Indicator

To check AirFly battery status, double-click the Volume Up button (+). Battery status will be:

- 2 amber blinks = over 75%
- 1 amber blinks = over 50%
- 1 amber blink = over 25%

Turning AirFly On & Off

Use the switch on the side of AirFly to turn it on and off.

Slide down to turn off.

AirFly will reconnect to your headphones when turned back on.

Reconnecting Your AirPods or Headphones Back to Your Smartphone/Tablet

Once paired, AirFly will remember your AirPods / headphones and switch to your smartphone/tablet. Simply open the Bluetooth settings on your Smartphone/tablet and pair your AirPods or headphones.

On your device, open Bluetooth Settings, and select your headphones from the list. Status and Charge Now Not Connected to Connected. Your headphones are successfully paired with your device.

Charging AirFly



1. **Use the included USB-C to USB-A Charging Cable.** Plug the USB-C end into the Charging Port on AirFly to fully charge within 3 hours.

The internal battery of AirFly lasts about 20 hours. We recommend fully charging AirFly before using it for the first time. Use the charging cable provided and plug into a USB port to start your first and every charge.

While charging, the AirFly will illuminate in amber and stay on. When fully charged, the light will turn off. While charging, AirFly can remain plugged in and charging within in use.

Tips & Tricks

1. If you are in a noisy scene, to be playing audio, turn AirFly off and back on to reset the noise cancelling and transparency mode settings.

2. If you want to pair a new set of headphones to AirFly, or are having trouble connecting your headphones, reset AirFly by pressing and holding the Reset button on the side of AirFly for 5 seconds. Once reset, AirFly will blink amber 3 times, and then will go into Pairing Mode.

Status Light Guide

Power On	White LED flashes twice
Pairing Mode	White & Amber LED flash alternately
Disconnected Standby Mode	White LED flashes twice every 5 seconds
Connected Standby Mode	Solid White LED
Low Power	Amber LED flashes 3 times every 10 seconds
Charging	Solid Amber
Fully Charged	Amber LED turns off

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Safety Statement

Do not use this product in environments outside the range of temperatures 0°C - 35°C (32°F - 95°F). Do not place this product in environments outside the range of temperatures -20°C - 45°C (-4°F - 113°F).

Bluetooth

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by twelve south is under license. Other trademarks and trade names are those of their respective owners.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RSS Statement

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Safety Statement

Do not use this product in environments outside the range of temperatures 0°C - 35°C (32°F - 95°F). Do not place this product in environments outside the range of temperatures -20°C - 45°C (-4°F - 113°F).

Bluetooth

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by twelve south is under license. Other trademarks and trade names are those of their respective owners.

Manufactured under license from Dolby Laboratories. Dolby, Pro Logic, and the double-D symbol are trademarks of Dolby Laboratories.

Designed by twelve south in Nashville, TN. Assembled in China.

Have questions?

Visit twelvesouth.com/support/airfly-se or support@twelvesouth.com

© 2025 Twelve South, LLC. All rights reserved.
1010 King St. Charleston, SC 29403 - USA

Jumelage du AirFly avec AirPods	23
Jumelage du AirFly avec des écouteurs sans fil	28
Contrôle du volume et sourdine	32
Indicateur de pile	33
Activer et désactiver le AirFly	34
Reconnexion des écouteurs au iPhone	35
Chargement	36
Conseils et astuces	37
Guide des voyants d'état	38

Jumelage du AirFly avec AirPods

1. Pour entrer en mode Jumelage sur les AirPods, placez d'abord les AirPods dans leur étui de chargement. Ouvrir le couvercle ouvert, appuyer et maintenez enfoncé le bouton à l'arrière du Mains du chargement jusqu'à ce que le voyant clignote.

2. Allumez le AirFly en faisant glisser le commutateur ON/OFF vers le haut. Le AirFly passera automatiquement en mode Jumelage et le voyant clignotera en blanc et ambre, indiquant que le dispositif est prêt à être jumelé.

Remarque: Pour remettre à zéro ou réinitialiser le AirFly à l'usine, appuyez et maintenez le bouton de réinitialisation pendant cinq secondes pour entrer en mode Jumelage.

Pour un jumelage plus facile, désactivez d'abord les connexions Bluetooth sur d'autres appareils (y compris votre téléphone).

3. Une fois le jumelage réussi*, la lumière sur l'étui de chargement des AirPods deviendra verte et la lumière du AirFly deviendra blanche continu et s'éteindra après 10 secondes.



4. Branchez le AirFly sur n'importe quel appareil à prise jack pour le diffuser sans fil à toutes les enceintes standards ou casques sans fil. Faudra sans fil.

*Le jumelage initial peut prendre jusqu'à 90 secondes, sous la forme de souvenirs de vos AirPods lors des connexions futures.

Jumelage du AirFly avec des écouteurs sans fil

1. Mettez vos écouteurs en mode Jumelage conformément à la manière la mieux du jumelation des vos écouteurs pour plus de détails).

2. Une fois le jumelage complété*, la lumière sur le AirFly sera blanche en continu et s'éteindra après 10 secondes.

*Le jumelage initial peut prendre jusqu'à 90 secondes, sous la forme de souvenirs du AirFly et des écouteurs lors des connexions futures.

3. Actives le AirFly en faisant glisser le commutateur ON/OFF vers le haut. Le AirFly passera automatiquement en mode Jumelage lors de la première mise sous tension, indiquée par le clignotement de lumières blanches et ambrées.

Remarque: Pour remettre à zéro ou réinitialiser le AirFly à l'usine, appuyez et maintenez le bouton de réinitialisation pendant quelques secondes afin d'entrer en mode Jumelage.

Pour un jumelage plus facile, désactivez d'abord les connexions Bluetooth sur d'autres appareils (y compris votre téléphone).

4. Une fois le jumelage complété*, la lumière sur le AirFly sera blanche en continu et s'éteindra après 10 secondes.

*Le jumelage initial peut prendre jusqu'à 90 secondes, sous la forme de souvenirs du AirFly et des écouteurs lors des connexions futures.

Contrôle du volume et sourdine sur le AirFly

Pour ajuster le volume du AirFly, appuyez sur les boutons de volume (+ ou -). Balance (+ ou -). Vous pouvez également appuyer et maintenir enfoncé le bouton de volume (+ ou -) pour augmenter ou diminuer progressivement le volume jusqu'à ce que le niveau souhaitez ou atteigne le niveau max.

Pour mettre en SOURDINE simultanément double-cliquez sur le bouton de volume (-). Le voyant ambre clignotera pendant quelques secondes pour vous informer que le mode sourdine est activé.

Double-cliquez à nouveau sur le bouton de volume (-) pour désactiver le mode sourdine et revenir au réglage de volume précédent.

Indicateur de pile

Pour vérifier l'état de la pile du AirFly, double-cliquez sur le bouton de volume (+). Le voyant indiquera:

- 2 clignotements orange = entre 50% - 75%
- 1 clignotements orange = entre 25% - 50%
- 1 clignotements orange = entre 10% - 25%
- 1 clignotement orange = entre 0% - 25%

Activer et désactiver le AirFly

Utilisez l'interrupteur sur le côté du AirFly pour l'activer ou le désactiver.

Faites glisser vers le haut pour l'activer.

Faites glisser vers le bas pour le désactiver.

AirFly se reconnectera à vos écouteurs lorsqu'il sera activé à nouveau.

Reconnecter vos AirPods ou écouteurs à votre téléphone intelligent/tablette

Une fois jumelé, le AirFly se souviendra de vos AirPods/écouteurs et basculera vers votre smartphone/tablette. Ouvrez simplement votre AirFly et ouvrez votre téléphone intelligent ou tablette, puis sélectionnez votre AirPods/écouteurs.

Sur votre appareil, ouvrez les paramètres Bluetooth et sélectionnez vos écouteurs dans la liste. Le statut passera de Non connecté à Connecté une fois que les écouteurs seront jumelés avec succès à votre appareil.

Chargement du AirFly

Pour charger, branchez simplement le câble de chargement USB-C inclus dans le port de charge du AirFly. Le voyant ambre s'allumera. Le AirFly est entièrement chargé en 3 heures.

La pile interne du AirFly dure plus de 20 heures. Nous recommandons de charger entièrement le AirFly avant de l'utiliser pour la première fois. Si votre AirFly est hors-ser-vice, veuillez le recharger. Il faut pour mieux qu'il dure deux heures chargé.

Pendant la charge, le AirFly s'illuminera en orange et restera allumé. Une fois complètement chargé, le voyant s'éteindra. Si vous le souhaitez, le AirFly peut rester branché et en charge pendant son utilisation.

Conseils et astuces

1. Si vous êtes dans une scène bruyante, pour que le AirFly fonctionne, éteignez le AirFly puis rallumez-le pour réinitialiser les paramètres de suppression du bruit et de transparence.

2. Si vous souhaitez jumeler une nouvelle paire d'écouteurs au AirFly, ou vous avez du mal à connecter vos écouteurs, réinitialisez le AirFly en appuyant et en maintenant le bouton de réinitialisation sur le côté du AirFly pendant 5 secondes. Une fois réinitialisé, le AirFly clignotera ambre à trois reprises, puis passera en mode Jumelage.

Guide des voyants d'état

Activation	Les voyants DEL blancs s'éteignent deux fois
Mode Jumelage	Les voyants DEL blancs et orange clignotent alternativement
Mode veille non connectée	Les voyants DEL blancs s'éteignent deux fois toutes les 5 secondes
Mode veille connecté	Les voyants DEL blancs en continu
Faible puissance	Les voyants DEL orange clignotent 3 fois toutes les 10 secondes
Chargement	Orange en continu
Entièrement chargé	Les voyants DEL orange s'éteient

FCC Déclaration

Cet appareil est conforme à la partie 15 des règles de la FCC. Son fonctionnement est soumis à la condition suivante : (1) Cet appareil ne doit pas causer d'interférences préjudiciables, et (2) Cet appareil doit accepter toutes les interférences reçues, y compris les interférences susceptibles de nuire au fonctionnement.

Avertissement : Les modifications apportées à cet appareil non expressément approuvées par la partie responsable de la conformité peuvent annuler le droit de l'utilisateur à utiliser l'équipement.

Remarque : Cet équipement a été testé et déclaré conforme aux limites d'un appareil numérique de classe B, conformément à la partie 15 des règles de la FCC. Ces limites sont conçues pour offrir une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet équipement génère, utilise et peut émettre des fréquences radio et, s'il n'est pas installé et utilisé conformément aux instructions, il peut causer des interférences nuisibles aux communications radio. Toutefois, rien ne garantit qu'il ne se produira pas d'interférences dans une installation particulière. Si cet équipement cause des interférences nuisibles à la réception de la radio ou de la télévision, ce qui peut être déterminé en éteignant puis en allumant l'équipement, l'utilisateur est invité à essayer de corriger les interférences par l'une ou plusieurs des mesures suivantes :

- Réorientez ou déplacez l'antenne de réception.
- Augmentez la distance entre l'équipement et le récepteur.
- Connectez l'équipement à une prise sur un circuit différent de celui auquel le récepteur est connecté.
- Consultez le revendeur ou un technicien radio/TV expérimenté pour obtenir de l'aide.

Déclaration de sécurité

Ne pas utiliser ce produit dans des environnements en dehors de la plage de températures 0°C - 35°C (32°F - 95°F). Ne pas placer ce produit dans des environnements en dehors de la plage de températures -20°C - 45°C (-4°F - 113°F).

Bluetooth

La marque et les logos Bluetooth sont la propriété du Bluetooth SIG, Inc. et toute utilisation de ces marques par twelve south est sous licence. Les autres marques et noms commerciaux sont ceux de leurs propriétaires respectifs.

Fabriqué sous licence de Dolby Laboratories. Dolby, Pro Logic, et le symbole double-D sont des marques de Dolby Laboratories.

Conçu par twelve south à Nashville, TN. Assemblé en Chine.

Des questions?

Visitez twelvesouth.com/support/airfly-se ou contactez-nous sur support@twelvesouth.com

© 2025 Twelve South, LLC. Tous droits réservés.
1010 King St. Charleston, SC 29403 - USA

BACK COVER