英

日

Xiaomi Air Fryer Essential 6L User Manual

Xiaomi エアフライヤー Essential 6L 取扱説明書

Read this manual carefully before use, and retain it for future reference.
Thank you for choosing Xiaomi Air Fryer Essential 6L. This product is for household use only. Please read the instructions carefully before first use. Keep the manual for future reference.
Contents may change without prior notice. Actual product and functions may vary due to product enhancements.

Safety Instructions

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Please keep the air fryer and the power cord out of the reach of children aged under 8.
- Do not use if the power cord is damaged or broken. It must be replaced by the manufacturer or after-sales service department to avoid hazards.
- The temperature of the accessible surface may rise while the air fryer is working.
- The surface will heat up easily while the air fryer is in use and remain hot for a period of time after use or external timer or a separate remote control.
- Do not block the air fryer's air inlet and outlet; not the heat generated during use may cause accident affecting the normal heat dissipation.
- Only authorized professional technicians should not modify the internal wiring of the air fryer.
- Do not place the fryer near other fuel sources to heat the basket, or fire may occur.
- Do not place the basket on any other heat sources, such as stoves, ovens, microwave ovens.
- Do not plug or unplug the power cord with wet hands to avoid the risk of an electrical shock.
- Do not use a power cord with loose connection or poor contact.
- Do not let the power cord cross through sharp objects to avoid damage to the power cord.

- Do not use the air fryer to store any items, especially flammable, explosive, or corrosive items.
- Do not place the air fryer on the edge of or place heavy objects on the power cord to prevent from exposing or breaking its core.
- Stop using the air fryer immediately and unplug it from the power source if it doesn't function normally or malfunctions.
- The air Fryer cannot be started without the basket being in place.
- Do not touch the basket directly with your hands during or right after use to avoid getting scalded.
- Do not place the basket with food in it, along with the cling wrap and packaging to avoid suffocation accidents.
- Do not use any plastic utensils or normal paper wrapping materials in the air fryer basket.
- Do not drop this air fryer or bump it against hard objects to avoid damage or malfunction.
- Do not block the air vents or other objects into any of the openings of the air fryer to avoid an electrical shock or injury.
- Do not use any accessories that are not recommended by the manufacturer.
- The normal operating altitude range of this product is 0-2000 meters.
- Maintain a distance of 30 cm or more between the air outlet and other devices during use.
- Do not move or shake the air fryer during use.
- Do not insert any foreign objects into the safety switch to avoid causing any danger.
- When placing the air fryer in a kitchen cabinet, etc., please ensure the cabinet is heat-resistant.
- Please be sure to unplug the air fryer before cleaning or repairing it.
- The product must be used on a level, heat-resistant surface to avoid damage to the product or accidents.
- Ensure that the silicone parts of the air fryer do not come into contact with ethanol or solutions that contain more than 50% of alcohol.
- Please ensure that the electrical outlet the air fryer is plugged into is grounded to avoid an electrical shock or other safety hazards.

- Only use a grounded electrical outlet with a rated current of 10 A to avoid the risk of fire and other potential hazards.

⚠ CAUTION：Hot surfaces.

Product Overview



Please ensure the power cord is connected to the power outlet before use. Insert the power plug into the outlet and the power cord into the connection port on the back of the air fryer.

First-time Use

1. Be sure to remove all packaging materials before use.
2. Use hot water and liquid detergent with a soft sponge sponge to wipe the frying pans and baskets, then rinse and dry them. Wipe the fryer with a damp cloth and dry it.
3. Place their trays gently in some oil or fatty food. It is recommended to run the air fryer for 5 minutes at 200°C to burn off any residual oil or odor from the manufacturing process. This will help prevent smoke or odor during cooking with an empty basket, which is normal.

Use

1. Place the air fryer on a stable, level surface and ensure that there is an unobstructed airflow around the fryer.
2. Ensure the power cord is connected to the outlet and the Temperature Probe is inserted into the frying pans. It is recommended to keep the food inside the PFAS-free coil the basket, or directly in the basket if it is not suitable for the coil, to prevent sticking and damage.
3. Completely pull the basket into the air fryer, set the temperature and time according to the recipe selected and your personal preference, and then start the air fryer for cooking.
4. When the cooking time is nearing its end, the air fryer will beep to remind you. Either the fryer basket is pulled out again, the air fryer will resume cooking.
5. When cooking is complete, the air fryer will beep continuously to remind you. Remove the cooked food from the basket and serve it.

CAUTION: Do not touch the basket or the cooked food with your bare hands during or after cooking to avoid burns. Use oven mitts or other heat-resistant tools to handle the basket and cooked food.

Cleaning & Maintenance

- Regularly clean the air fryer and its components to prevent contaminants on their and food from to cross contaminate and affect cooking results. Please remove the power cord from the air fryer before cleaning.
- Surface of the air fryer:
  - Use a damp cloth to wipe the stained with a soft, cloth or a sponge moistened with a neutral cleaning detergent.
  - Do not use abrasive cleaners.
- The Temperature Probe:
  - The Temperature Probe is made of the air fryer, apply a suitable amount of detergent and water to a soft sponge and wipe the probe gently. Rinse the probe with water and dry it with a soft cloth. Do not use abrasive cleaners.
- Basket:
  - Take the air fryer after each use. The basket of the air fryer is coated, so we not recommend using metal utensils or abrasive cleaning materials to clean the frying pan. Use sponge for cleaning.
- Frying pan:
  - Use a damp cloth or sponge moistened with neutral detergent to clean it clean. Rinse thoroughly with clean water and dry it with a soft cloth.
- Cleaning the Air Fryer Exterior: Wipe the exterior with a damp cloth or sponge moistened with a neutral detergent. Avoid contact with water and ensure the electrical components, such as the power cord, are not exposed to water. Clean the exterior only when the fryer is cooled down.

Cleaning Precautions

- Only use the recommended cleaning agents and tools to avoid damage to the fryer.
- Do not use any corrosive or abrasive cleaning materials or detergents.
- Do not immerse the fryer in water or other liquids to avoid damage to the fryer.
- Do not use the dishwasher to clean the fryer components.

Maintenance Tips

- Only professionals (same pro qualified technicians should open the air fryer.
- Unless absolutely sure that an fryer without permission to avoid serious consequences.
- When the air fryer malfunctions, please refer to Troubleshooting before contacting the after-sales service.
- After each use, please unplug the power cord to disconnect it and contact the after-sales service.

Troubleshooting

Issue	Possible Causes	Solutions
The air fryer doesn't operate	The air fryer is not connected to a power outlet	Plug the power cord into a compatible power outlet
	The basket is not correctly inserted	Pull out the basket and push it back in until it clicks into place
	Fryer and temperature can cat	Turn the fryer inside out and remove the basket and the Fryer and temperature
The fan makes a stuck	The fan blade is stuck	Contact the after-sales service
The fan doesn't cooks	The motor is damaged or other electrical components are short circuit	Contact the after-sales service
White smoke is coming out	Cooking high fat ingredients	It is normal for the air fryer to work out fat or oil when cooking high fat ingredients
	Residue residual from the manufacturing process	Clean the air fryer after each cooking
Can't insert the basket properly	The basket is not correctly inserted	Remove the basket and reinsert it properly
Food cooking unevenly	The basket is not properly inserted	Properly insert the basket

Specifications

Model / Model Number	Capacity / 容量	Color / 颜色
Xiaomi / MAF01	Rated Frequency / 额定频率	Jade / 翡翠绿
Rated Voltage / 额定电压	Rated Power / 额定功率	Total Weight / 总重
Operating Temperature / 工作温度	Operating Humidity / 工作湿度	Dimensions / 尺寸
Size / Dimensions / 型号 / 尺寸 / 型号 / 尺寸		

Manufacturer / 生产厂商：
Xiaomi Communications Co., Ltd.
Xiaomi Technology Building, Haidian District, Beijing
Manufacturer / 生产厂商：
Shenzhen Kaiyuan Electronics Manufacturing Co., Ltd.
Shenzhen Kaiyuan Electronics Manufacturing Co., Ltd.
Address: No.2 Kaiyuan Road, Kaiyuan Industrial Zone, Yuanshan Town, Pingshan District, Shenzhen, Guangdong, China
Address: No.2 Kaiyuan Road, Kaiyuan Industrial Zone, Yuanshan Town, Pingshan District, Shenzhen, Guangdong, China
Made in China / 中国制造

「取扱説明書」は慎重に読んでお読みください。また、いつでも参照できるように保管してください。

Xiaomi エアフライヤー Essential 6L をお選びいただきありがとうございます。この製品は家庭用のみです。ご使用前に説明書をお読みください。説明書は、今後の参照のために保管してください。内容は予告なく変更されることがあります。製品のアップグレードにより、実際の製品とエアフライヤーの機能は異なる場合があります。

安全上の注意

- 本製品は、使用に伴う危険性を理解したうえで、安全な使用方法を理解し、監督または指示を受けた8歳以上の子供、および身体的、感覚的または精神的に障害があるか、または経験や知識が不足している人が使用することができます。子供は本製品で遊んではいけません。8歳未満の子供の監視または指示がない限り、お子様の手の届かない場所に本製品とその電源コードを保管してください。
- エアフライヤーと電源コードは、8歳未満のお子様の手の届かない場所に保管してください。
- 電源コードが損傷している場合、使用しないでください。
- 電源コードが損傷したまたは破損した場合、安全上の問題を回避するために、必ず製造元またはアフターサービスセンターに連絡して交換してください。
- エアフライヤーの使用中は、触れることができる表面の温度が上昇する場合があります。
- 使用後または使用中、エアフライヤーは熱くなりやすいです。
- エアフライヤーは、外部タイマーや別のリモコンで操作しないでください。
- 通常の熱に影響を与えないように、発熱中はエアフライヤーの吸気口や排気口、排気口を塞がないでください。
- 内部配線の改造は、専門の技術者のみ、エアフライヤーの内部配線を変更しないでください。
- パスチャライクライパンを加熱するために本体やその他の同様の表面に直接置かないでください。
- パスチャライは（調理器具やエンジンなどの他の熱源と）に直接置かないでください。
- 明確な理由を説明するため、濡れた手で電源コードを抜き差ししないでください。

- 本製品は、食品の保管や、特に可燃性、爆発性、腐食性の物を保管するためのものではありません。
- 電源コードを傷つけないように、電源コードを鋭利な物体に近づけないでください。
- 動作しない場合、または、特に可燃性、爆発性、腐食性の物を保管しないでください。
- 電源コードを過度に曲がったり、曲げたり、ねじったり、重いものを乗っけたりしないでください。芯線が露出したり破損したりすると感電の恐れがあります。
- 本製品は、推奨されていない、または、あるいは互換性と場合は、修理に連絡先または、電源プラグを抜いてください。
- バスケットが取り付けられていないと、エアフライヤーを起動することはできません。
- 調理後または、使用中は金属手袋なしでバスケットに手が直接触れないでください。
- 窒息事故を防ぐため、ラップフィルムや包装材に子供が近づかないようにしてください。
- 調理用の金属製品を使用しないでください。プラスチック製の食器や通常の紙の調理用容器を使用しないでください。
- 振動や衝撃を防ぐため、このエアフライヤーを落としたりぶつけたりしないでください。
- 感電や故障を防ぐため、エアフライヤーの開口部にいかなるものを挿入しないでください。
- メーカーが推奨していないアクセサリを使用しないでください。
- この製品の通常の使用高度範囲は0～2000メートルです。
- 使用中は、排気口と他の機器との間隔を 30 cm 以上開けてください。
- 使用中にエアフライヤーを動かしたり揺らしたりしないでください。
- 危険を避けるため、安全スイッチに異物を入れないでください。
- エアフライヤーをキッチンキャビネットに置く場合は、その場所が十分に耐熱されていなければなりません。
- エアフライヤーを掃除または修理する前に、必ずプラグを抜いてください。

- この製品は、製品の損傷や事故を防ぐため、半乾燥物質のみを使用する必要があります。
- エアフライヤーのシリコン部分がエタノールまたはアルコール含有量が 50% を超える溶液に触れないようにしてください。
- 感電や火災の危険を防ぐために、エアフライヤーを接続する電源コンセントが接地されていることを確認してください。

⚠ **注意：表面が高温になります。**

製品紹介

電源コードを電源コンセントに接続し、温度プローブをフライパンに挿入することを推奨します。食品を PFAS フリーのコイルバスケットに入れることを推奨します。コイルバスケットに適していない場合は、バスケットに直接入れることを推奨します。これは、焦げ付きや損傷を防ぐためです。これは正常です。

初めてお使いいただく際のお知

1. 梱包材はすべて開封前に取り外してください。
2. 柔らかいスポンジに温水と液体洗剤を塗ってフライパンとバスケットを拭き取り、洗浄後乾かします。エアフライヤーを湿布で拭き、乾かします。
3. トレイを優しくオイルまたは脂肪分の多い食品に入れます。製造プロセスの残留油や臭いを焼き切るために、エアフライヤーを200°Cで5分間運転することをお勧めします。空のバスケットを使用した調理中に発生する煙や臭いは正常です。これは通常の現象です。

使い方

1. 安定した平らな表面にエアフライヤーを置き、エアフライヤーの周囲に障害物がないことを確認します。
2. 電源コードが接続されていることを確認し、温度プローブをフライパンに挿入します。食品を PFAS フリーのコイルバスケットに入れることを推奨します。コイルバスケットに適していない場合は、バスケットに直接入れることを推奨します。これは、焦げ付きや損傷を防ぐためです。
3. バスケットを完全に引き出し、温度と時間を調理レシピまたは個人の好みに合わせて設定し、エアフライヤーを起動して調理を開始します。
4. 調理時間が終了に近づくと、エアフライヤーはビープ音を鳴らして通知します。バスケットを再び引き出すか、エアフライヤーは調理を再開します。
5. 調理が完了すると、エアフライヤーはビープ音を鳴らし続けます。バスケットから調理済みの食品を取り出してください。

CAUTION: 調理中または調理後、素手でバスケットや調理済みの食品に触れないでください。火傷を防ぐためです。オーブンミトンまたは耐熱性の工具を使用してください。

クリーニングとメンテナンス

- エアフライヤーの清潔さを保つ。汚染物質や食品が交差汚染を防ぎ、料理の結果に影響を与えないようにします。クリーニングする前に、エアフライヤーから電源を抜きます。
- エアフライヤーの表面：
  - 汚れた部分を、柔らかい布、または、中性洗剤を含ませたスポンジまたはスポンジで拭きます。
  - 研磨剤を使用しないでください。
- テンプレート温度プローブ：
  - 温度プローブは、エアフライヤーの本体を作ります。適当な量の洗剤と水を柔らかいスポンジに塗り、プローブを優しく拭きます。プローブを水で洗い流し、柔らかい布で乾かします。研磨剤を使用しないでください。
- バスケット：
  - 使用後は取り出してください。エアフライヤーのバスケットはコーティングされているため、メタルの調理器具や研磨剤を使用して調理パンを清掃することはお勧めしません。スポンジを使用してください。
- フライパン：
  - 乾いた布やスポンジを使用して、中性洗剤を含ませてフライパンをきれいにします。よくすすぎ、きれいな水で洗い流します。乾いた布で乾かします。研磨剤を使用しないでください。
- エアフライヤーの外観をクリーニング：外観を乾いた布やスポンジで拭き、中性洗剤を含ませます。水との接触を避けます。特に、電源コードなど、電気部品が水にさらされないようにします。本体が冷めたときにのみ清掃してください。

お手入れに関する注意

- 損傷を防ぐために、適切な洗剤と工具のみを使用してください。
- 腐食性または研磨性の洗剤や洗剤を使用しないでください。
- 故障を防ぐために、エアフライヤーを液体に浸漬しないでください。
- エアフライヤーの部品を食器洗い機で洗浄しないでください。

メンテナンスのヒント

- エアフライヤーの解体は、専門の技術者のみが実施する必要があります。エアフライヤーを分解しないでください。
- 修理中は、エアフライヤーを解体する前に、アフターサービスセンターに連絡してください。
- 使用後は毎回、エアフライヤーの電源を抜いてください。アフターサービスセンターに連絡してください。

トラブルシューティング

問題	考えられる原因	解決策
エアフライヤーが動作しません	電源コードがコンセントに接続されていません。	電源コードをコンセントに差し込んでください。
	バスケットが正しく挿入されていません。	バスケットを引き出してプッシュインしてください。
	フライパンと温度計は調理中に冷えます。	フライパンと温度計を裏返してください。バスケットを取り出してください。
ファンが詰まります。	ファンブレードが詰まっています。	サービスセンターにお問い合わせください。
ファンが動きません。	モーターが損傷しているか、他の電気部品がショートしています。	サービスセンターにお問い合わせください。
白い煙が出ています。	高脂肪分の食材を調理しています。	エアフライヤーは、高脂肪分の食材を調理する際に油や脂肪を出すのが正常です。
	製造工程の残留物	毎回使用後にエアフライヤーを清掃してください。
バスケットを正しく挿入できません。	バスケットが正しく挿入されていません。	バスケットを取り出して、正しく再挿入してください。
食べ物がムラになる	バスケットが正しく挿入されていません。	バスケットを正しく挿入してください。

基本パラメータ

型番名：メーカー / エアフライヤー		容量：6L	カラー：ジェイド
定格電圧：220V～	定格周波数：50/60Hz	定格電力：1700W	総重量：7.27kg
動作温度：0～40℃	動作湿度：10%～90%RH	製品寸法：W 370 × D 370 × H 320 mm	
製品寸法：370 × 370 × 320 mm			

製造元：Xiaomi Communications Co., Ltd.
Xiaomi Technology Building, Haidian District, Beijing
製造元：Shenzhen Kaiyuan Electronics Manufacturing Co., Ltd.
Shenzhen Kaiyuan Electronics Manufacturing Co., Ltd.
住所：No.2 Kaiyuan Road, Kaiyuan Industrial Zone, Yuanshan Town, Pingshan District, Shenzhen, Guangdong, China
住所：No.2 Kaiyuan Road, Kaiyuan Industrial Zone, Yuanshan Town, Pingshan District, Shenzhen, Guangdong, China
Made in China / 中国制造

製造年：シリアル番号 / 生産日