英

日

XIAOMI Air Fryer Essential 6L User Manual

Airyeno エアフライヤー Essential 6L 取扱説明書

Read this manual carefully before use, and retain it for future reference.
Thank you for choosing Xiaomi Air Fryer Essential 6L. This product is for household use only. Please read the instructions carefully before operating the product. Keep the instructions for future reference. Actual product and illustration may vary due to product enhancements.

Safety Instructions

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. Children shall be supervised to ensure that they do not play with the appliance.
- Please keep the air fryer and the power cord out of the reach of children aged under 8.
- Pets should not use it.
- If the power cord is damaged or broken, it must be replaced by the manufacturer or after-sales service department to avoid hazards.
- The temperature of the accessible surface may rise while the air fryer is working.
- The surface will heat up easily while the air fryer is in use.
- The air fryer can only be operated via an external timer or a separate remote control.
- Do not block the air fryer's air inlet and outlet; nor the heat dissipation holes, to avoid poor heat dissipation, the internal overheating and damage.
- Only authorized or qualified technicians should not modify the internal wiring of the air fryer.
- Do not place the fryer near other similar fuel sources to heat the basket, or frying pan.
- Do not place the basket on any other heat sources, such as a stove or electromagnetic oven.
- Do not plug or unplug the power cord with wet hands to avoid the risk of an electrical shock.
- Do not use a power cord with loose connection or poor contact.
- Do not let the power cord cross through sharp objects to avoid damage to the power cord.

- Do not use the air fryer to store any items, especially flammable, explosive, or corrosive items.
- Do not place the basket, the air fryer, or any place heavy objects on the power cord to prevent from exposing or breaking its core.
- Please unplug the air fryer immediately and unplug it from the power source if it doesn't function normally or malfunctions.
- The air fryer cannot be started without the basket being in place.
- Do not touch the basket directly with your hands during or right after use to avoid getting burned.
- Do not use the basket without the air fryer; play with the cling wrap and packaging to avoid suffocation accidents.
- Do not use any plastic utensils or normal paper wrapping materials in the air fryer to avoid fire.
- Do not drop this air fryer or bump it against hard objects to avoid damage or malfunction.
- Do not use any sharp objects or other objects into any of the openings of the air fryer to avoid an electric shock or injury.
- Do not use any accessories that are not recommended by the manufacturer.
- The normal operating altitude range of this product is 0-2000 meters.
- Keep a distance of 30 cm or more between the air outlet and other devices during use.
- Do not move or shake the air fryer during use.
- Do not insert any foreign objects into the safety switch to avoid causing any danger.
- When placing the air fryer in a kitchen cabinet, etc., please ensure good ventilation.
- Please be sure to unplug the air fryer before cleaning or repairing it.
- The product must be used on a level, heat-resistant surface to avoid damage to the product or accidents.
- Ensure that the silicone parts of the air fryer do not come into contact with ethanol or solutions that contain more than 50% of alcohol.
- Please ensure that the electrical outlet the air fryer is plugged into is grounded to avoid an electrical shock or other safety hazards.

- Only use a grounded electrical outlet with a rated current of 10 A to avoid the risk of fire and other potential hazards.

⚠ CAUTION : Hot surfaces.

Product Overview



Note: Actual product and illustration may vary due to product enhancements.
Note: Please ensure that the heating tube and heating plate are fully immersed in the food when using the air fryer to prevent uneven heating.

First-time Use

1. Be sure to remove all packaging materials before use.
2. Lift the basket and lid and thoroughly wash it and silicone sponge to clean the frying pan and the inner and outer surfaces of the air fryer with a damp cloth or sponge. Dry it thoroughly.
3. Place the air fryer plug off a nonslip place on flat ground. It is recommended to set the air fryer at least 30 cm away from other objects to ensure good ventilation and avoid overheating and damage. Place the air fryer plug into a single power socket or an other power outlet with an unused appliance, which is normal.

Use

1. Place the air fryer on a stable, level surface and ensure that there is an unobstructed ground flow at the bottom.
2. Pull out the frying pan and place it into the basket, ensure that the basket fits into the frying pan. It is recommended to place the food inside the mesh tray in the basket, or directly place the food into the basket if the food is too small to fit into the mesh tray.
3. If necessary, you can increase the time of food, add the temperature and flip according to the recipe selected and your personal preference, and then start the air fryer for cooking.
4. When the cooking time is up, the air fryer will beep and stop automatically. Pull out the basket to examine if cooked again. Do not touch the basket directly.
5. Pour out the food and serve. Be careful not to touch the basket directly to avoid burning the complexion of cooking. Carefully take out the basket and use tongs to remove the food.

Cleaning & Maintenance

- Please unplug the air fryer and let it cool down before cleaning the air fryer, and wait for it to cool down to avoid accidental scalds and burns. Please remove the power cord from the air fryer and place it in a safe place.
- Wipe the surface of the air fryer.
- Use a damp cloth or sponge to wipe the stained with a pity, soft cloth or a sponge moistened with a neutral cleaning detergent.
- Do not use any abrasive cleaners.
- The internal stainless steel the cavity of the air fryer, apply a suitable amount of detergent and water, and use a sponge to wipe the stained with a pity, soft cloth or sponge moistened with water to wipe away the detergent residue.
- Clean the air fryer after each use. The basket of the air fryer is coated, so be sure to clean it after each use to prevent cleaning difficulties due to long-term stains.
- Frying pan:
  - Soak the frying pan with an sponge moistened with neutral detergent to soak it clean, then rinse it with water and wipe the detergent residue.
  - Avoid using hard or sharp objects to scrape the frying pan, which may cause the coating to peel off, causing it to rust and affecting food safety. Use a sponge or cleaner.
- Lid:
  - Remove the lid and soak it in a sponge moistened with neutral detergent to soak it clean, then rinse it with water and wipe the detergent residue.
  - Avoid using hard or sharp objects to scrape the lid, which may cause the coating to peel off, causing it to rust and affecting food safety. Use a sponge or cleaner.
- Silicone sponge:
  - Remove the silicone sponge from the lid, and soak it in a sponge moistened with neutral detergent to soak it clean, then rinse it with water and wipe the detergent residue.
  - Avoid using hard or sharp objects to scrape the silicone sponge, which may cause the coating to peel off, causing it to rust and affecting food safety. Use a sponge or cleaner.
- Heating tube and heating plate:
  - Remove the heating tube and heating plate, and use a sponge to wipe the stained with a pity, soft cloth or sponge moistened with water to wipe away the detergent residue.
  - Avoid using hard or sharp objects to scrape the heating tube and heating plate, which may cause the coating to peel off, causing it to rust and affecting food safety. Use a sponge or cleaner.
- Air inlet and outlet: Use a soft cloth or sponge moistened with neutral detergent to wipe the stained with a pity, soft cloth or sponge, then wipe the detergent residue.
- Power cord: Wipe the power cord with a damp cloth or sponge, then wipe the detergent residue.
- Do not use the air fryer if the power cord is damaged or broken.
- Do not use any abrasive cleaning materials or detergents.
- Do not immerse the air fryer in water or other liquids to avoid electrical shock.

Cleaning Precautions

- Please unplug the power cord and let it cool down before cooling it. Use the lid (wear it, wear gloves) and pull out the basket and place it on a stable, flat surface. Do not place the power plug directly on the air fryer, or the surface that be in contact by the power plug.
- Do not use the air fryer to store any items, especially flammable, explosive, or corrosive items.
- Do not use any corrosive or abrasive cleaning materials or detergents.
- Do not immerse the air fryer in water or other liquids to avoid electrical shock.

Maintenance Tips

- Only authorized or qualified technicians should open the air fryer.
- Without prior consent, open the air fryer without permission to avoid serious consequences.
- When the air fryer malfunctions, please refer to Troubleshooting before contacting the after-sales service.
- Wait for the product to cool down before cleaning the power cord to disconnect it and contact the after-sales service.

Troubleshooting

Issue	Possible Causes	Solutions
The air fryer doesn't operate	The air fryer is not connected to a power source	Plug the power cord into a power source and try again
	The basket is not properly inserted	Pull out the basket and push it back in until it clicks into place
	Time and temperature not set	Turn the timer knob and temperature knob to the desired time and temperature
The fan blades do not rotate	The fan blade is stuck	Contact the after-sales service for assistance
	The motor is overheated or other motor issues	Contact the after-sales service center
The air fryer doesn't heat	Cooking too high expectations	It is normal for the air fryer to take time to heat up and reach the set temperature
White smoke is coming out	Oil/grease residue from the previous use	Clean the air fryer after each cooking
Food is not cooked properly	The food is too thick	Increase the cooking time
	Too much food in the basket	Cook smaller portions at a time
The food is not properly seasoned	Uneven seasoning	Shake the basket halfway through cooking
	Too much oil or moisture	Pat food dry before adding seasoning
Food is not crispy	Food not properly prepared	Properly coat the food

Specifications

Model: Mi Air Fryer Essential 6L	Capacity: 6 L	Color: White	
Voltage: 220V	Rated Frequency: 50/60 Hz	Net Weight: 4.5 kg	
Rated Power: 1800 W	Rated Voltage: 220 V	Gross Weight: 5.2 kg	
Operating Temperature: 0°C ~ 40°C	Rated Current: 8A	Dimensions: 300 × 300 × 320 mm	
Max Temperature: 200 °C	Max Power: 1800 W		

Note: Actual product and illustration may vary due to product enhancements.

Manufacturer: Airyeno Electronics Co., Ltd.
Address: Airyeno Electronics Co., Ltd. Room 1101, 11F, Building 1, Yuanxin Technology Park, Yuanxin Road, Nanshan District, Shenzhen, Guangdong, China
Contact Author: Airyeno Electronics Co., Ltd.
Author Address: Airyeno Electronics Co., Ltd.
Email: support@airyeno.com

Made in China

- 組成が違っていたり接続不良な電源コードは使用しないでください。
- 電源コードが傷害しないように、電源コードを鋭利な物体にかけないでください。
- 電源コードが傷害した場合、特に感電、爆発性、腐食性の物は本体に置いてはいけません。
- 電源コードを過度に熱あるいは、曲げたり、ねじったり、重いものを乗っけたりしないでください。万一の感電ショートなどを防止するため。
- パスタ、小麦粉などを使用する場合は、必ず専門家に相談してください。
- 本製品は、使用中は表面温度が上がりやすくなります。
- 本製品は、使用中は表面温度が上がりやすくなります。
- エアフライヤーは、タイマーまたは別のリモコンでのみ動作します。
- 吸気口と排気口、および放熱穴を塞がないでください。放熱不良、内部過熱および損傷を防ぐため。
- 認定または資格のある技術者のみが、エアフライヤーの内部配線を改変してください。
- 他の類似燃料源の近くに、バスケットまたは調理鍋を置かないでください。
- バスケットを他の熱源、例えばコンロまたは電磁調理器の上に置かないでください。
- 濡れた手でプラグの差し込みや抜きをすると、感電のリスクがあります。
- 接続が緩んでいたり、接触不良な電源コードを使用しないでください。
- 電源コードを鋭利な物体の上を通さないでください。
- 感電の危険を防ぐため、接地されたコンセントを使用してください。
- 定格電流10Aの接地されたコンセントを使用してください。

- 本製品は、8歳以上の子供および身体的、感覚的、または精神的能力が低下している人、または知識や経験が不足している人が、安全な方法で製品の使用について監督または指示を受けており、関連する危険を理解している場合に使用することができます。子供は製品で遊んではいけません。子供は、製品の清掃およびユーザーによるメンテナンスを監督なしで行うことはできません。子供は製品で遊ぶことがないように監督されなければなりません。
- 8歳未満のお子様やペットの手の届かない場所に保管してください。
- 電源コードが損傷した場合、安全上の問題を回避するために、必ず製造元またはアフターサービスセンターに連絡して交換してください。
- エアフライヤーの使用中は、触れることができる表面の温度が上がる場合があります。
- エアフライヤーを使用すると、表面が熱くなりやすいです。
- エアフライヤーは、外部タイマーや別のリモコンでのみ動かしてください。
- 通風口や排気口、放熱穴を塞がないように、発熱不良やエアフライヤーの内部過熱および損傷を防ぐため。
- 認定または資格のある技術者のみが、エアフライヤーの内部配線を変更してください。
- 他の類似燃料源の近くに、バスケットまたは調理鍋を置かないでください。
- バスケットを他の熱源、例えばコンロまたは電磁調理器の上に置かないでください。
- 濡れた手でプラグを差し込んだり抜いたりすると、感電のリスクがあります。
- 接続が緩んでいたり、接触不良な電源コードを使用しないでください。
- 電源コードを鋭利な物体の上を通さないでください。
- 感電の危険を防ぐため、接地されたコンセントを使用してください。
- 定格電流10Aの接地されたコンセントを使用してください。

- この製品は、製品の損傷や事故を防ぐため、半径0.5m以内に他の物体を置かないでください。
- エアフライヤーのコンセントが、ぬれたエアフライヤーまたはフルーム金属部が 50% を超える部分に触れないようにしてください。
- 安全上の理由から、特に可燃性、爆発性、腐食性の物は本体に置いてはいけません。
- 電源コードを過度に熱あるいは、曲げたり、ねじったり、重いものを乗っけたりしないでください。万一の感電ショートなどを防止するため。
- パスタ、小麦粉などを使用する場合は、必ず専門家に相談してください。
- バスケットが取り付けられていないと、エアフライヤーを起動することはできません。
- 使用中または使用後すぐに直接バスケットに手が触れないようにしてください。
- 使用後は、ラップやパッケージなどのプラスチック製の食器や通常の紙製の食器を使用しないでください。
- 窒息事故を防ぐため、エアフライヤーの外でバスケットを遊ばないでください。
- 火災を防ぐため、プラスチック製の食器や通常の紙製の食器を使用しないでください。
- 衝撃や損傷を防ぐため、このエアフライヤーを落としたり、硬い物にぶつけたりしないでください。
- 感電や怪我を防ぐため、エアフライヤーの開口部にいかなるものを挿入しないでください。
- イーバーナ電磁レンジなどのプラグを使用しないでください。
- この製品の通常の使用高度範囲は0~2000メートルです。
- 使用中は、安全上の問題と火災の発生 30 cm 以上離してください。
- 使用中は、エアフライヤーを動かしたり揺らしたりしないでください。
- 異物を差し込むと、安全スイッチに異物を入れないでください。
- エアフライヤーをキッチンキャビネットに置く場合は、その場所が十分に換気されていなければなりません。
- エアフライヤーを開始または修理する前に、必ずプラグを抜いてください。

製品紹介



注意：実際の製品と異なる場合があります。

初めてお使いいただく際のご注意

1. 梱包材はすべて取り外してください。
2. バスケットとリッドを持ち上げて、スポンジ状の洗浄剤を使用してフライパンとエアフライヤーの内外面を清潔にします。エアフライヤーを乾燥させる。エアフライヤーは、安全な場所に置いてください。
3. エアフライヤーを平坦な地面に置いてください。エアフライヤーの通風を確保し、過熱や損傷を防ぐために、エアフライヤーから他の物体から少なくとも30cmの距離を保つことをお勧めします。これは正常な現象です。

使い方

1. 安定した平らな耐熱表面に置いてください。エアフライヤーの底面に流れが確保されていることを確認してください。
2. フライパンを引き出してバスケットに置き、バスケットにフライパンが収まっていることを確認してください。食材は、バスケットのメッシュトレイに置くか、食材が小さすぎてメッシュトレイに収まらない場合は、食材をバスケットに直接置くことをお勧めします。
3. 必要に応じて、選択したレシピに従って、または個人の好みに合わせて、時間を増やしたり、食材をひっくり返したりすることができます。その後、エアフライヤーを起動して調理します。
4. 調理時間が終了すると、エアフライヤーはビープ音を鳴らして自動的に停止します。バスケットを引き出して、調理されているかどうかを確認します。バスケットに直接触れないでください。
5. 食材を注ぎ、盛り付けます。バスケットに直接触れて、調理中に顔を火傷しないように注意してください。バスケットを慎重に取り出し、調理された食材を取り出します。

クリーニングとメンテナンス

- エアフライヤーの電源プラグを抜いて、冷却時に電源コードを保管、冷却を開始する前に冷却してください。火傷や怪我を防ぐために、エアフライヤーを慎重に扱ってください。エアフライヤーを安全な場所に置いてください。
- エアフライヤーの表面を拭く。
- 汚れが目立ちにくい柔らかい布または、中性洗剤を含ませた柔らかい布または、スポンジで拭いてください。
- 研磨剤を使用しないでください。
- エアフライヤーの内部ステンレス鋼製キャビティ：適量の洗剤と水を塗布し、スポンジを使用して洗剤を拭き取ります。
- 使用後はエアフライヤーを清潔にしてください。長期間の汚れによる取り除きにくさを防ぐため。
- 内鍋の取り外し方法：まず、内鍋のハンドルを上に持ち上げてください。内鍋を取り外す前に、エアフライヤーの電源を切ってください。
- 内鍋の洗浄：
  - 内鍋を中性洗剤を含ませたスポンジで浸漬して清潔にし、その後水で洗い流して洗剤残渣を拭き取ります。
  - 硬い物や鋭利な物でこすり洗いしないでください。コーティングが剥がれて錆びの原因となり、食品の安全性に影響を与えます。スポンジまたはクリーナーを使用してください。
- リッド：
  - リッドを取り外し、中性洗剤を含ませたスポンジで浸漬して清潔にし、その後水で洗い流して洗剤残渣を拭き取ります。
  - 硬い物や鋭利な物でこすり洗いしないでください。コーティングが剥がれて錆びの原因となり、食品の安全性に影響を与えます。スポンジまたはクリーナーを使用してください。
- シリコンスポンジ：
  - シリコンスポンジをリッドから取り外し、中性洗剤を含ませたスポンジで浸漬して清潔にし、その後水で洗い流して洗剤残渣を拭き取ります。
  - 硬い物や鋭利な物でこすり洗いしないでください。コーティングが剥がれて錆びの原因となり、食品の安全性に影響を与えます。スポンジまたはクリーナーを使用してください。
- 加熱チューブと加熱プレート：
  - 加熱チューブと加熱プレートを取り外し、スポンジを使用して汚れを拭き取ります。中性洗剤を含ませた柔らかい布または、スポンジで拭き取ります。
  - 硬い物や鋭利な物でこすり洗いしないでください。コーティングが剥がれて錆びの原因となり、食品の安全性に影響を与えます。スポンジまたはクリーナーを使用してください。
- 吸気口と排気口：柔らかい布または、中性洗剤を含ませたスポンジで拭き取ります。中性洗剤を含ませた柔らかい布または、スポンジで拭き取ります。
- 電源コード：電源コードを柔らかい布または、スポンジで拭き取ります。中性洗剤を含ませた柔らかい布または、スポンジで拭き取ります。
- 電源コードが損傷または破損している場合は使用しないでください。
- 研磨剤または洗剤を使用しないでください。
- 感電を防ぐために、本製品を水やその他の液体に浸漬しないでください。

メンテナンスのヒント

- エアフライヤーの開封は、資格のある専門家または認定技術者のみが行うことができます。
- 事前の承諾なしに、本製品の開封などを行うと、重大な結果を招くことがあります。
- エアフライヤーが故障した場合、アフターサービスに連絡する前にトラブルシューティングを参照してください。
- 製品が冷めるまで待ってから、電源コードを拭いて、電源を切ってください。
- エアフライヤーを安全な場所に置いてください。

トラブルシューティング

問題	考えられる原因	解決策
エアフライヤーが動作しない	電源コードが電源に接続されていない	電源コードを電源に接続してください。
	バスケットが正しく挿入されていない	バスケットを引き出して、カチッと音がするまで押し戻してください。
	時間と温度が設定されていない	タイマーノブと温度ノブを目的の時間と温度に合わせてください。
ファンが回転しない	ファンブレードが詰まっている	サポートに連絡してアフターサービスを受けてください。
	過熱または他のモーター関連の問題	アフターサービスセンターに連絡してください。
加熱しない	期待値が高すぎる	エアフライヤーが設定温度に到達するまで時間がかかることがあります。
白い煙が出ている	前回使用時の油脂残留物	毎回の調理後にエアフライヤーを清掃してください。
食材がうまく調理されない	食材が厚すぎる	調理時間を延長してください。
	バスケットに食材を入れすぎている	一度に少量ずつ調理してください。
味付けが均一でない	味付けが均一でない	調理の途中でバスケットを揺すってください。
	食材に油分や水分が多すぎる	味付けする前に食材を乾燥させてください。
食材がサクサクしない	食材が適切に調理されていない	食材を適切にコーティングしてください。

基本パラメータ

製品名：エアフライヤー Essential 6L		容量：6 L	色：ホワイト
電圧：220V	定格周波数：50/60 Hz	本体重量：4.5 kg	
定格入力：1800 W	定格電圧：220 V	総重量：5.2 kg	
動作温度：0°C ~ 40°C	定格電流：8A	外寸：300 × 300 × 320 mm	
最大温度：200 °C	最大電力：1800 W		

注：実際の製品とイラストは、製品の改良により異なる場合があります。

製造元：Airyeno Electronics Co., Ltd.
住所：Airyeno Electronics Co., Ltd. Room 1101, 11F, Building 1, Yuanxin Technology Park, Yuanxin Road, Nanshan District, Shenzhen, Guangdong, China
連絡先：Airyeno Electronics Co., Ltd.
作成者住所：Airyeno Electronics Co., Ltd.
メール：support@airyeno.com
Made in China