PXN P50L

Wireless Gaming Controller

User Manual

使用说明书



感谢您对 PXN 某任达的选择和支持，在使用前请仔细阅读本手册。

## 01 产品外观

## 02 系统要求

| | |
|---|---|
| 支持平台 | SWITCH主机、PC电脑、iPhone |
| PC系统要求 | Windows 7 /8 /10 /11, iOS 16+ |

## 03 开/关机

**开机：**长按电源键 3 秒进入开机配对。
**关机：**短按电源键复位关机。

## 04 移动端APP功能

iOS下载地址：App Store搜索【智玩社区】
安卓下载地址：www.e-pxn.com.cn
手柄连接 SWITCH 主机或 PC 设备后，通过移动端APP 进行互联设置手柄功能。
APP 功能说明：

- 手柄空间坐标复位分享
- 手柄振动强度调节
- 手柄按键设置分享
- 手柄摇杆死区调节
- 手柄灯效设置调节

* 更多功能持续开发中

## 05 SWITCH平台使用

- 蓝牙连接

Step 1　在SWITCH主机主界面下方，进入 手柄 → 更改握法/顺序；
Step 2　长按手柄电源键 3 秒进入配对，显示当前剩余电量后，手柄 4 个LED灯循环闪烁，进入连接状态；
Step 3　5 秒后，手柄 LED 1 灯长亮，表示连接成功。

- SWITCH主机回连唤醒

蓝牙连接模式下，按下手柄 键即可回连唤醒 SWITCH主机。

- 有线连接

在SWITCH主机主界面下方，选择 设置 → 手柄与感应器 → 选择 Pro 手柄的有线连接选项，确保该选项状态为开启状态。

- 与SWITCH直连

* 使用有线连接前，请将手柄处于关机或休眠状态。

Step 1　使用 Type-C 数据线和 OTG 转换头连接手柄与 SWITCH 主机。
Step 2　LED 指示灯闪烁，手柄连接成功。
(注：OTG转换头需自行购买)

- 与SWITCH底座连接

* 使用有线连接前，请将手柄处于关机或休眠状态。

Step 1　使用 Type-C 数据线连接手柄与 SWITCH 底座。
Step 2　LED 1 指示灯闪烁，手柄连接成功。

SWITCH底座的USB端口



- 手柄体感3D摇杆校准

当体感功能异常或摇杆出现漂移不归中时，可使用手柄校准功能。

Step 1　睡眠状态下，同时按下手柄【L3+R】进入校准模式，手柄 4 个LED灯分两组交替闪亮。

Step 2　此时将手柄放置于水平桌面，再按手柄的 键，释放按键后 3 秒钟后自动完成传感器校准及3D摇杆校准，此时手柄进入睡眠状态。
(*3D摇杆校准：当用户开机使用摇杆时，出现摇杆不归中的问题，可通过上述校准方式，解决摇杆不归中的问题)

## 06 PC平台使用

- 有线连接

Step 1　使用 USB 数据线连接手柄与 PC 电脑的 USB 接口。
Step 2　电脑将提示发现新硬件并完成安装，手柄 LED2 指示灯闪烁。
(当电量充满时，LED2 指示灯为长亮) 表示连接成功，连接后为Xinput模式。

- 手柄测试功能

在PC电脑使用，可打开电脑游戏控制器进行功能自检，具体如下：
打开控制面板 → 设备和打印机 → 鼠标右键点击 游戏手柄图标 → 游戏控制器设置，点击属性进行手柄测试。



## 07 辅助功能

- 手柄振动调整功能

开机连接后，按住【 键 + 左摇杆上/下】调整马达振动强度，手柄振动默认为中档。振动调节具有记忆功能。




| | | |
|---|---|---|
| | 强振动(100%) | LED1+LED2+LED3 闪烁一下 |
| | 中振动(70%) | LED1+LED2 闪烁一下 |
| | 低振动(30%) | LED1闪烁一下 |
| | 无振动 | 所有LED熄灭 |

- 连发 (TURBO) 功能

可设定TURBO功能的按键有：A、B、X、Y、L、R、ZL、ZR。

| | |
|---|---|
| 手动连发 + 功能键 | 第一次设置后长按该功能键时触发连发，键值色灯闪烁 |
| 自动连发 + 功能键 | 第二次设置后按下功能键自动触发连发，键值色灯闪烁。再按下暂停连发 |
| 清除连发 + 功能键 | 第三次设置后取消设置的连发功能。键值色灯不闪烁 |
| 清除全部连发 + 或 | 取消所有功能键设置的连发功能 |
| 连发速率调节 + | 手柄长按【 键 + 右摇杆上/下】可调整连发速率，默认5次/秒<br>5次/秒时LED1亮一下<br>10次/秒时LED1+LED2亮一下<br>15次/秒时LED1+LED2+LED3亮一下 |



- 宏编程 (MACRO) 功能

**动作键：**左摇杆 (上下左右) 、右摇杆 (上下左右) 、十字键 (上下左右) 、A B X Y、L/ R/ ZL/ ZR/ L3/ R3/ + / - 。
**编程键：**M1 、M2。

**宏编程功能设定：**
① 按下 M1 或者 M2 其中一个编程键，再按住 键，此时 键色灯长亮进入编程状态。
② 按下需要被编程的动作键，如左摇杆 (上下左右) 、十字键 (上下左右) 、A B X Y、L/ R/ ZL/ ZR/ L3/ R3 进行输入。
③ 编程结束后按下编程键，白灯熄灭橙色灯长亮。(每一组宏编程，最多可编程32个动作键，当动作键超过32 个时，编程结束程序长亮 )

**宏编程功能清除：**
① 按下 M1 或者 M2 其中一个编程键，再按住 键，此时 键色灯长亮进入编程状态。
② 再按下 M1 或者 M2 其中一个编程键，即可清除该宏按键的编程。清除完成后色灯熄灭，橙色灯长亮。

## 08 充电功能

**充电电源：**标准USB 5V电压，可使用手机充电器、电脑等USB接口为手柄充电。手柄充满电时间约为 2-3 个小时。

| 手柄状态 | 电量状态 | 指示灯状态 |
|---|---|---|
| 工作状态 | 低电量 | 慢闪 |
| | 充电中 | 慢闪 |
| | 满电 | 长亮 |
| 关机状态 | 充电中 | 闪烁 |
| | 满电 | 熄灭 |



## 09 睡眠功能

| 手柄状态 | 进入睡眠状态 |
|---|---|
| 回连状态 | 30秒无连接 |
| 首次配对状态 | 60秒无连接 |
| 工作状态 | 5分钟无任何操作和移动 |

在关机状态下按【L3+L】按键后，可通过【十字键上/下】调节自动睡眠时间

| | |
|---|---|
| | 睡眠 5分钟时，<br>LED1 灯同时亮一下 |
| | 睡眠 10分钟时，<br>LED1+LED2 灯同时亮一下 |
| | 睡眠20 分钟时，<br>LED1+LED2+LED3 灯同时亮一下 |
| | 睡眠关闭时，<br>LED1+LED2+LED3+LED4 灯同时亮一下 |

## 10 复位功能

当手柄出现功能错乱、死机或者其它异常时，短按电源键进入关机状态下长按电源键6秒手柄振动提示一次进行恢复出厂设置，恢复出厂设置后再重新进行配对连接。
**恢复内容：**按键连发清空，手柄连发速度默认为 5次/秒，手柄振动默认为中档。
手柄睡眠时间默认为 5分钟，手柄宏配置恢复为出厂配置。

## 11 注意事项

- 避免强烈振动，不可自行分拆、改装及修理。
- 避免水或其它液体进入手柄内部，以免造成损坏。
- 避免存放于潮湿、高温、油烟等场所。
- 内有电池，请勿将手柄掉进火中，有爆炸危险。
- 儿童需在成年人的监护下使用本产品。
- 如有质量问题或建议请与销售商或售后人员联系。

## 12 产品规格

| | |
|---|---|
| 产品型号 | PXN-P50L |
| 连接方式 | 无线/有线连接 |
| 工作电源 | 内置550mAh锂电 |
| 工作电流 | 工作时20mA，振动时小于130mA |
| 产品尺寸 | 约 163*106*61 mm |
| 包装尺寸 | 约 195.5*150*75.5 mm |
| 本体重量 | 约 216 g |
| 使用温度 | 10~40 ℃ |
| 使用湿度 | 20-80 % |

Wireless Gaming Controller

User Manual



Thank you for choosing and supporting PXN, please read this manual carefully before starting to enjoy your gaming experience.

## 01 Product Overview

## 02 System Requirement

| | |
|---|---|
| **Supported platform** | SWITCH, PC, iPhone |
| **PC system requirement** | Windows 7 /8 /10 /11, iOS 16+ |

## 03 Power ON / OFF

**Power ON:** Long press [ Power Switch ] for 3s to power ON and enter pairing.
**Power OFF:** Short press [ Power Switch ] to reset and power OFF.

## 04 Mobile APP Function

**Download for iOS:** App Store search [ PXN Play ].
**Download for Android:** Google Play search [ PXN Play ].
After connecting the controller to SWITCH or PC, connect with APP and the function of the controller can be set in the APP.

APP Function Introduction:

- Controller Macro function setting and sharing
- Controller joystick sensitivity adjustment
- Controller vibration intensity adjustment
- Controller Turbo function adjustment

* More functions are under development

## 05 How to use in SWITCH

- Wireless Connection

Step 1　Click Controller → Change Grip/Order on SWITCH homepage.
Step 2　Long press [ Power Switch ] for 3s to enter pairing. Four LED indicators on the controller will flash circularly when the remaining battery life displaying, then enter connection state.
Step 3　LED1 on the controller will remain ON after 5s, the connection is successful.

- SWITCH Console re-connection and wake-up

In wireless connection, press button on the controller to reconnect and wake up the SWITCH Console.

- Wired Connection

Click Setting on SWITCH homepage → Controllers and Sensors → click Pro Controller Wired Connection. Please make sure this option state is ON.

- Connect with SWITCH Console

* Please make sure the controller is OFF / under Sleep state before wired connection.

Step 1　Use Type-C cable and OTG Adapter to connect the controller and SWITCH console.
Step 2　The connection is successful when LED1 indicator flashing.
(Note: OTG adapter is not included)




- Connect with SWITCH Dock

* Please make sure the controller is OFF / under Sleep state before wired connection.

Step 1　Use Type-C cable and OTG Adapter to connect the controller and SWITCH Dock.
Step 2　The connection is successful when LED1 indicator flashing.

USB Port of SWITCH Dock



- Controller Sensor / 3D Joystick Calibration

When the controller occurs disorder or joystick problem, you can use calibration function to fix it.
Step 1　In sleeping state, press [ L3 + R ] to enter the calibration mode, the 4 LED indicators on the controller will flash alternately in 2 groups.

Step 2　Place the controller on a horizontal table and press [ + ] button, the sensor and 3D joystick will automatically complete after releasing the button in 3 seconds.
(3D joystick calibration: When the user starts to use the joystick, if the joystick can not return back to the center, it can be solved through the above calibration steps.)

## 06 How to use in PC

- Wired Connection

Step 1　Use USB cable to connect the controller and the USB port in PC.
Step 2　The PC will prompt new hardware and install automatically, the connection is successful when LED2 indicator flashing. It is in X-input mode after connecting. (LED2 indicator will remain ON when it is fully charged.)

- Testing Function

Function testing is available when use in computer: The specific steps show below: Open Control Panel → Devices and Printers → Right click Controller icon → Game Controller, Setting and click Properties Testing.



## 07 Auxiliary Function

- Vibration Adjustment Function

After connection, hold press the [ L3 ] button and operate the UP/Down of Left Joystick at the same time to adjust vibration level, default vibration level is medium. Vibration adjustment has memory function.

| | |
|---|---|
| High Vibration | LED1+LED2+LED3 light up |
| Medium Vibration | LED1+LED2 light up |
| Low Vibration | LED1 lights up |
| No Vibration | All LED OFF |

- Turbo Function

**Buttons can be set Turbo Function:** A, B, X, Y, L, R, ZL, ZR.

| | |
|---|---|
| Manual Turbo + Function Button | After the first setting, long press the function button can launch TURBO manually, indicator will flash in Orange. |
| Auto Turbo + Function Button | After the second setting, press the function button can launch TURBO automatically, indicator will flash in Orange. Press the button again can be stopped Turbo function. |
| Clear Turbo Setting + Function Button | After the third setting, the TURBO function will be cleared. indicator will not flash. |
| Clear all Turbo Setting + or | Clear all button TURBO function |
| Adjustable Rapid Fire + | Long press [ ] and operate the UP/ Down of Right Joystick at the same time can adjust the rapid fire rate.<br>5 times/second,LED1 lights up<br>10 times/second,LED1+LED2 light up<br>15 times/second,LED1+LED2+LED3 light up |



- Macro Function

**Action Button:** Left Joystick (↑/↓/←/→), Right Joystick (↑/↓/←/→), D-pad (↑/↓/←/→), A /B /X /Y /L / R/ ZL/ ZR/ L3/ R3/ + / - .
**Programming Button:** M1, M2.

**Macro Function Setting:**
① Press one of the Programme Button (M1 / M2), then press , now the button white indicator will remain ON and enter to programming state.
② Press the action buttons you want to be programmed. Action buttons include Left Joystick (↑/↓/←/→), Right Joystick (↑/↓/←/→), D-pad (↑/↓/←/→), A /B /X /Y /L / R/ ZL/ ZR/ L3/ R3/ + / - .
③ Press again the Programming Button when complete, the white indicator will OFF and orange indicator will remain ON. (Up to 32 action buttons can be programmed in each group of Macro program. If the action buttons are more than 32, the program will finish and the orange indicator will remain ON.)

**Clear Macro Function:**
① Press one of the Programme Button (M1 / M2), then press , now the button white indicator will remain ON and enter to programming state.
② Press again the Programme Button (M1 / M2) to clear the Macro function. The white indicator will OFF and orange indicator will remain ON when complete.

## 08 Charging Function

**Charging Power:** standard USB 5V voltage. The controller can be charged by connecting the USB port of phone charger, computer, etc.Fully-charged will take about 2-3 hours.

| Controller State | Battery State | Indicator State |
|---|---|---|
| Working State | Battery State | Slowly |
| | Charging | Flash Slowly |
| | Fully Charged | Remain ON |
| Power OFF | Charging | Flash |
| | Fully Charged | OFF |



## 09 Sleeping Function

| | |
|---|---|
| Controller State | Enter Sleeping State |
| Re-connect State | 30 seconds without connection |
| First Pairing State | 60 seconds without connection |
| Working State | 5 minutes without any action |




Press [ L3 + L ] in Power OFF state, then the auto sleep time can be adjusted by operating UP/DOWN of D-pad.

| | |
|---|---|
| | Sleep after 5mins,<br>LED1 lights up |
| | Sleep after 10mins,<br>LED1+LED2 light up |
| | Sleep after 20mins,<br>LED1+LED2+LED3 light up |
| | Sleep function OFF,<br>LED1+LED2+LED3+LED4 lights up |

## 10 Reset Function

When the controller has functional disorder, freezes or other abnormalities, short press [ Power Switch ] to enter Power OFF state, then long press [ Power Switch ] for 6 seconds and the controller will vibrate once to enter to restore factory settings. After restoring, please re-connect and pair it.

## 11 Attention

- Avoid strong vibration, do not disassemble, modify or repair by yourself.
- Prevent water or other liquids from entering the controller to avoid damage.
- Avoid storing in humid, high temperature, oily smoke and other places.
- Built-in battery, please do not throw the controller into fire to avoid explosion.
- Children should be under adult's supervision at all times when using this product.
- If you have any problems or suggestions about the product, please contact the seller or the after-services.

## 12 Product Specifications

| | |
|---|---|
| Model | PXN-P50L |
| Connection Method | Wireless / Wired |
| Working Power | Built-in 550mAh lithium battery |
| Working Current | 20mA in working, <130mA in vibration |
| Product Size | About 163*106*61 mm |
| Package Size | About 195.5*150*75.5 mm |
| Product Weight | About 216 g |
| Use Temperature | 10~40 ℃ |
| Use Humidity | 20-80 % |





Wireless Gaming Controller

使用マニュアル



PXN製品をお買い上げいただきまして、誠にありがとうございます。ご使用になる前に、本取扱説明書をよくお読みください。

## 01 製品外観

## 02 システム要件

| | |
|---|---|
| 対応プラットフォーム | SWITCH, PC, iPhone |
| PCシステム要件 | Windows 7 /8 /10 /11, iOS 16+ |

## 03 電源オン/オフ

**電源オン：**電源ボタンを3秒間長押しすると、電源が入り、ペアリングが開始されます。
**電源オフ：**電源ボタンを短押しすると、電源が切れます。

## 04 モバイル APP 機能

iOS用のダウンロード：App Storeで「PXN Play」を検索してください。
Android用のダウンロード：Google Play で「PXN Play」を検索してください。
コントローラーをSWITCHまたはPCに接続した後、モバイルAppを通してコントローラーの機能を設定します。
App機能説明：

- コントローラーのマクロ機能の設定及び共有
- コントローラーのスティックの感度調整
- コントローラーの振動レベル調整
- コントローラーの連射機能調整

*より多くの機能が開発中です

## 05 SWITCHでの使用方法

- BT接続

ステップ 1　SWITCHのホーム画面から、「コントローラー」-「持ちかた/順番を変える」を選択します。
ステップ 2　電源ボタンを 3 秒間長押しすると、現在のバッテリー残量が表示された後、コントローラーの4つのLEDライトが点滅を繰り返し、ペアリング状態になります。
ステップ 3　5 秒後、コントローラーのLED1が点灯したままになると、接続成功です。

- SWITCH本体の再接続とウェイクアップ

BT接続モードでコントローラーの ボタンを押すと、再接続が行われ、SWITCH本体がウェイクアップされます。

- 有線接続

SWITCHのホーム画面から 「設定」→「コントローラーとセンサー」→「Proコントローラーの有線通信」を選択し、「Proコントローラーの有線通信」がオンになっていることを確認してください。

- SWITCH本体との接続

* 有線接続を使用する前に、コントローラーをシャットダウンまたはスリープ状態にしてください。

ステップ 1　Type-Cケーブルとo.TGアダプタを使って、コントローラーとSWITCH本体を接続します。
ステップ 2　LED1 が点滅すると、接続成功です。
(注：OTGアダプタは別途購入する必要があります)

- SWITCHドックとの接続

* 有線接続を使用する前に、コントローラーをシャットダウンまたはスリープ状態にしてください。

ステップ 1　Type-Cケーブルを使って、コントローラーとSWITCHドックを接続します。
ステップ 2　LED 1 が点滅すると、接続成功です。

SWITCHドックのUSBポート



- 体性感覚3Dスティックの校正

体性感覚機能に異常が発生したり、スティックが中央に戻らない場合は、コントローラーの校正機能を使用することができます。
ステップ 1　スリープ状態でコントローラーの「L3」と「R」を同時に押すと、校正モードに入り、コントローラーの4つのLEDライトが2組に分かれて交互に点滅します。




ステップ 2　コントローラーを平らなテーブルの上に置いて「+」ボタンを押し、指を離して約3秒にセンサーと3Dスティックの校正が自動的に完了します。この時コントローラーはスリープ状態になります。
(*3Dスティックの校正：スティックを使い始めた時、スティックが中央に戻らない場合は、上記の手順で問題を解決できます)

## 06 PCでの使用方法

- 有線接続

ステップ 1　USBケーブルを使ってPCのUSBポートにコントローラーを接続します。
ステップ 2　デスクトップで「新しいハードウェアが見つかりました」が表示され、自動的にインストールが完了し、コントローラーのLED2が点滅すると、接続成功です。接続後はXInputモードになります。(完全に充電されると、LED2が点灯したままになります)




- コントローラーのテスト機能

PCでコントローラーの機能テストを行うことができます。具体的には以下の通りです。
「コントロールパネル」→「デバイスとプリンター」→「ゲームパッドのアイコンを右クリック →「ゲームコントローラーの設定」を開く。「プロパティ」を選択して、テストを行います。



## 07 補助機能

- 振動調整機能

接続後、ボタンを押しながら 左スティックを上下に動かして、モーターの振動レベルを調整します。デフォルトの振動レベルは「中」です。振動調整はメモリー機能を備えています。

| | |
|---|---|
| | 強振動(100%) | LED1+LED2+LED3、1回点滅 |
| | 中振動 (70%) | LED1+LED2、1回点滅 |
| | 弱振動(30%) | LED1、1回点滅 |
| | 振動なし | すべてのLEDライトが消灯 |

- 連射 (TURBO) 機能

TURBO機能を設定できるボタン：A、B、X、Y、L、R、ZL、ZR。

| | |
|---|---|
| 手動連射 + 機能ボタン | 第一回目の設定後、機能ボタンを長押しすると連射が開始し、 ボタンのオレンジ色のライトが点滅します。 |
| 自動連射 + 機能ボタン | 第二回目の設定後、機能ボタンを押すと連射が自動的に開始し、 ボタンのオレンジ色のライトが点滅します。もう一度ボタンを押すと、連射が停止します |
| 連射をクリア + 機能ボタン | 第三回目の設定後、連射機能がクリアされ、 ボタンのオレンジ色のライトが点滅します。 |
| すべての連射をクリア + または | 機能ボタンのすべての連射機能をクリアします |
| 速射スピード調整 + | コントローラーの ボタンを押しながら右スティックを上下に動かすと、連射スピードを調整することができます。デフォルトの連射スピードは5回/秒です。<br>5回/秒　LED1 が1回点滅<br>10 回/秒　LED1+LED2 が1回点滅<br>15 回/秒　LED1+LED2+LED3 が1回点滅 |



- マクロプログラミング (MACRO) 機能

**アクションボタン：**アクションボタン：左スティック (上下左右) 、右スティック (上下左右) 、十字ボタン (上下左右) 、A B X Y、L/ R/ ZL/ ZR/ L3/ R3/ + / - 。
**プログラミングボタン：**M1 、M2。

**マクロプログラミング機能設定：**
① M1、M2のいずれかを押してから ボタンを押し続けると、 ボタンの白色のライトが点灯し、プログラミング状態になります。
② プログラミングしたいアクションボタンを押します。例えば、左スティック (上下左右) 、十字ボタン (上下左右) 、A B X Y、L/ R/ ZL/ ZR/ L3/ R3を押して入力します。
③ プログラミング完了後、プログラミングボタンを押すと、白色のライトが消灯し、オレンジ色のライトが点灯します。(ママロプログラミングの各グループには、最大32個のアクションボタンをプログラミングすることができます。アクションボタンの数が32個以上の場合、プログラミングが終了し、オレンジ色のライトが点灯します)

**マクロプログラミング機能をクリア：**
① M1、M2のいずれかを押してから ボタンを押し続けると、 ボタンの白色のライトが点灯し、プログラミング状態になります。
② もう一度M1、M2のいずれかを押すと、このボタンのマクロプログラミングをクリアすることができます。クリア後、白色のライトが消灯し、オレンジ色のライトが点灯します。

## 08 充電機能

**充電電源：**USB規格で電圧は5V。スマホ充電器やPCなどのUSBポートを使ってコントローラーを充電することができます。フル充電には約2~3時間かかります。

| コントローラー状態 | バッテリー状態 | 表示ライト状態 |
|---|---|---|
| 動作状態 | 低残量 | ゆっくり点滅 |
| | 充電中 | ゆっくり点滅 |
| | フル充電 | 常時点灯 |
| 電源オフ状態 | 充電中 | 点滅 |
| | フル充電 | 消灯 |



## 09 スリープ機能

| コントローラー状態 | スリープ状態になる |
|---|---|
| 再接続状態 | 30秒間接続なし |
| 初回ペアリング状態 | 60秒間接続なし |
| 動作状態 | 5分間無操作 |




電源オフの状態で【L3】と【L】を同時押しした後、十字ボタンの上下によってオートスリープ時間を調整します。

| | |
|---|---|
| | 5分後にスリープ、<br>LED1 が1回点滅 |
| | 10分後にスリープ、<br>LED1+LED2 が1回点滅 |
| | 20分後にスリープ、<br>LED1+LED2+LED3 が1回点滅 |
| | スリープがオフになると、<br>LED1+LED2+LED3+LED4 が1回点滅 |

## 10 リセット機能

コントローラーに動作の不安定、フリーズまたはほかの異常が発生した場合、電源ボタンを押して電源をオフにした後、電源ボタンを 6 秒間長押しすると、コントローラーが 1 回振動して工場出荷時の設定に戻ります。その後もう一度、ペアリングをやり直してください。
リセット内容：連射機能はクリアされ、デフォルトの連射スピードは 5回/秒、デフォルトの振動レベルは「中」、デフォルトのスリープ時間は 5分、コントローラーのマクロ設定は工場出荷時の設定に戻ります。

## 11 注意事項

- 激しい振動を避けてください。ご自分での分解・改造・修理はしないでください。
- コントローラー内部に水やその他の液体が入らないようにしてください。破損の原因となることがあります。
- 湿気の多い場所、高温の場所、油煙のある場所などでの保管は避けてください。
- 電池が内蔵されているため、コントローラーを火の中に入れないようにご注意ください。爆発する恐れがあります。
- お子さまが本製品を使用する場合は、大人の監督の下で使用するようにしてください。
- 品質に問題が生じた場合、またはご提案がある場合、販売業者またはアフターサービス担当者までご連絡ください。

## 12 製品仕様

| | |
|---|---|
| 製品型番 | PXN-P50L |
| 接続方式 | 無線/有線接続 |
| 動作電源 | 内蔵550mAhリチウム電池 |
| 動作電流 | 動作時20mA、振動時<130mA |
| 製品サイズ | 約 163*106*61 mm |
| パッケージサイズ | 約 195.5*150*75.5 mm |
| 本体重量 | 約 216 g |
| 使用温度 | 10~40 ℃ |
| 使用湿度 | 20-80 % |



* PXN is a registered trademark of ShenZhen PXN Electronics Technology Co., Ltd.
Nintendo /Nintendo SWITCH /Amiibo is a registered trademark of Nintendo Co., Ltd.
All trademarks are the property of their respective owner. Technical specifications are subject to change. Information contained herein is subject to change without prior notice. ShenZhen PXN Electronics Technology Co., Ltd. shall not be made liable for any errors that may appear. Please keep this information for later reference.

S-P50-V8-2303