尺寸：80*115mm

POWER HBQ PRO

Bluetooth 5.3 Headphones

Product Manuals

If you have a question that is not listed here, please do not hesitate to contact us by email. Customer Service Department email address.

amazonservice@kinganda.cn

CONTENTS

Product introduction——1
Package Contents——2
Instructions for use
1.Power supply——2
2.Calling call function——3
3.Listen music——3
4.Monaural / Binaural mode——4
5.Reset pairing——5
Common problems
1.Bluetooth not found——6
2.Charging problem——7
3.Auto turn off——8
4. Only one ear has sound——8
5. Sound intermittent——9
Parameter Specification——10
Warranty measures——11

Product Introduction

Package Contents

Charging case*1 Headphones*2 Ear caps*4
Instruction manual*1 USB cable*1

Operation Instructions

1.Manual power on/off

Power on: long press 3s
(Blue light blinking that is on)

Power off: long press 5s
(Red light blinking that is off)

2.Calling Features/Calls



Call/End: Press MFB once.
Reject: Press MFB twice.
Redial: Press MFB twice.
Siri Call: Press and hold the MFB button for 2 seconds

3.Listening to song



Play/pause music: Press MFB once.
Previous song (press "+" for 2 seconds)
Next song (press "-" for 2 seconds)

4.Mono/Dual mode

①For the first time use, please remove either ear from the charging case.
②Open Bluetooth and search for Bluetooth.
③Search for the name of the Bluetooth device "YYK-QA7" to connect.

Place the other one in the case as it is. Or turn off the power. Otherwise, it will not be in one ear mode. Please note.

Binaural mode

Automatic: Remove from charging case and it will automatically turn on and connect to Bluetooth device.
Manual: Press and hold the left and right earphone buttons for 3 seconds to power on and connect to Bluetooth device.

Select "YYK-QA7" in the list of Bluetooth devices on your phone. Enter pairing. A voice will present the word "Continue," and the indicator light will alternately red/blue flashes and then goes out, indicating success to continue.

As soon as the earphones are placed in the charging case, they turn off. It will then begin charging. Once the earbuds are removed from the case, they will immediately turn on and automatically pair and connect to a paired Bluetooth device.

5. Reset pairing

Using the one-ear mode will deactivate the binaural mode. If the binaural pair is removed by mistake, please follow the procedure below to reset the pair.
Phenomenon of binaural pair removal
On start-up, the red/blue lights flash respectively and the phone displays two identical device names; it is not possible to connect to both earphones at the same time.
Solution: You need to reset the device manually.

1. Turn off the Bluetooth function of your phone. Before turning off, delete the Bluetooth device name.
Cancel all the previously connected device names "YYK-QA7".

2. Remove the left and right earphones from the case and manually press and hold the button for 3 seconds to power off.

3. With the device shut down, manually press and hold the multi-function button on the left and right earphones for 10 seconds, until the red and blue lights alternately flash, and then hold for 10 seconds. After the red and blue lights flash twice.

4. Put the left and right earphones back into the charging case and check if the charging mode is activated.

5. Remove the left and right earphones from the charging case at the same time and connect them to your phone.

FAQ

Bluetooth not found

1.The Bluetooth communication distance is 10 m. Make sure there are no obstacles in between and the distance to the smart phone. Smartphones and earphones should be used in close proximity.
2. Other smartphones or devices may already be connected to the earpiece. If this is the case, first release the bearing with the connected smartphone/device.
3.If the connection problem has not been resolved, try rebooting the Bluetooth device and resetting the earphones.
4.If the earphones do not find the device within 5 minutes of turning it on, it will automatically shut down.
5. When connecting to another phone, the earpiece must first search for the previously connected device and then wait for about 2 minutes.

Charging problem

1. Make sure that there is no problem with the charging cable or the adapter for charging, and that the charging cable is inserted correctly.
2. There is a possibility of poor contact. Press the left and right earphones with your fingers, and make sure the charging contact points of the left and right earphones are fully connected to the charging case.
3. The charging contact points on the left and right earphones may have dirt, dust, or sweat on them. Wipe with a cloth.
4. When you hear the "Battery low" message, please charge the earphones. When the LED display on the case reaches the number "10", please charge the case. Please be careful not to run out of power in the earphones and charging case. This may shorten the life of the battery in the earphones.
The built-in lithium battery may shorten the usage life of the earphones.

Automatic shutdown

Please make sure that the earphones are fully charged. In addition, please make sure the earphones will automatically shut down 10 minutes after Bluetooth is disconnected. In this case, please put them back in the charging case or press and hold the multifunction button for 2 seconds to turn on the power.

Only one headset has sound

First reset the earphones and restart your smartphone.
Delete the Bluetooth connection history of the earphone, and then search and try pairing again. If the problem persists, please try the following steps.

1. remove the left and right earphones from the charging case and press and hold the multi-function button for about 5 seconds to turn off the earphones.

2. manually press and hold the multi-function button on the left and right earphones for 10 seconds until the red and blue lights turn on twice and release your finger.

3. put the left and right earphones back into the charging case and check to see if the charging mode is activated.

4. Remove the left and right earphones from the charging case at the same time.

5. delete the connection history of the smart phone, then search and pair again.

Parameter Specification

Bluetooth Version	TWS V5.3
Support Contract	A2DP1.3,HFP1.6,HSP1.2,AVRCP1.6,D1.3
Bluetooth Frequency	2.402HZ
Bluetooth distance	10m(No entity obstacles)
Earbud Charging case	Earbud battery capacity: 130mAh
Battery capacity	Charging case battery capacity: 950mAh
Call/Music playtime	Music playtime:talk time in one ear: about 18-20 hours Music playtime:talk time in two ear: about 10 hours (435 battery level page display)
Standby time :	Standby time in one ear: 240 hours Binaural standby time: 200 hours
Full charge time:	1.5hours
single earcharging case weight:	Earphones: 6.5g*2/ Charging case: 60g
Package weight:	0.16kg
Product Size:	95*60*34mm

Attention

1. Do not handle this product roughly. Do not eject heavy objects into the earphones, and do not place the earphones in a high temperature and humid environment.
2. Do not place this product in the presence of WIFI, routers or other high frequency transmitting equipment.
3. Use this product in an effective environment (10m) and ensure that there are no obstacles between the Bluetooth device and the earphones (e.g. walls).
4. Please charge this charging case using a legitimate charging facility.
5. This earphone is compatible with any Bluetooth device.
6. If you do not use it for a long time, please recharge it before use.

Safety Precaution

The following instructions are to be observed in order to prevent injury to the user or others and damage to property.
Please read the text after carefully understanding the contents of the indications and symbols described here, and be sure to observe them.
●The following symbols classify and explain the degree of harm or damage to humans that may occur if the product is used incorrectly and the contents of the labeling are ignored.

⚠Dangerous	A threat of imminent danger of death or serious injury.
⚠Warning	Are there that could result in death or serious injury.
⚠Note	Maybe cause injury or property damage.

●The following pictorial symbols are used to classify and explain the types of contents to be observed.

attention/Warning symbol Prohibited action symbol Mandatory action

Warranty

1. If this product fails within 6 months from the date of purchase in spite of proper use in accordance with the instruction manual, connection examples, and notes, etc., for home use, we will replace it free of charge.
2. If the product fails within 6 months from the date of purchase, we will replace it free of charge.
3. The customer is responsible for carry-in repair. The customer will be responsible for shipping charges when sending the product to us.
4. Please keep this document in a safe place and do not lose it.

⚠Dangerous

Do not short-circuit the terminals. Do not carry or store the product together with metal necklaces, coins, or other small metal objects as this may cause fire, ignition, or explosion.
Do not bend the product into a fire or charger, use, or leave it at high temperatures that do not heat it, as this may cause it to overheat, catch fire, or explode.

⚠Warning

Never use headphones while riding a bicycle, car, motorcycle, etc. Doing so may cause a traffic accident.
When using the headphones outdoors, be aware of surrounding traffic, obstacles, and surroundings to avoid the headphones.
Do not disassemble or modify the product. Doing so may cause malfunction, overheating, fire, or electric shock.
If the USB cable is not plugged in securely, it may cause fire or electric shock. Do not touch the main unit or USB cable with wet hands. Do not give a strong shock or throw the product. Doing so may cause fire, burns, or injury. Do not leave within the reach of children or infants, who may accidentally swallow the earphones or earpieces.

⚠Note

Use and store the product in a place with little moisture or dust as it may cause heat generation, ignition, or electric shock. When using this product, do not use the earphones at a high volume for a long time. Listening to music at a high volume for a long period of time may adversely affect hearing. If the volume is turned up too high from the beginning, a sudden loud sound may irritate your ears, turn up the volume gradually.
Do not cover the earbuds with blankets or clothing while charging or using it. Doing so may cause overheating, fire, or explosion.
Do not use the product if the USB cable is damaged or the terminals are loose, as this may cause fire or electric shock.
Do not use the product near a fire or stove, in a car, in the bathroom, or in any other place subject to high temperatures or high humidity.
Doing so may cause overheating, fire, or explosion.

Warranty measures

1. 6 months long warranty period
2. Warranty does not apply to malfunctions caused by failure to follow the instructions for use. Please note that the warranty does not cover any damage caused by failure to follow the instructions for use.

Warranty measures:
Warranty Number:
User Name:
Phone Number:
Address:
Time of Purchase :
Receipt Number:
Product Seller Name:
Vendor Address:
Edition Store Phone Number:
Failure Description:

POWER HBQ PRO

耳写分離型耳掛ワイヤレスイヤホンV5.3+EDR

取扱説明書

ここに記載されていない質問がある場合は、遠慮なく電子メールでお問い合わせください。
カスタマー・サービスのメールアドレス:

amazonservice@kinganda.cn

目次

各部の名称 1
付属品 2
操作方法一覧 2
電源 3
通話する 3
音楽を聴く 3
お気に入りモード 4
ペアリングをリセット 5
故障かな？と思ったら 6
充電について 7
自動電源オフについて 8
片耳しか使えない 8
音が断続的について 9
商品仕様 10
製品の品質 11
安全上の注意 11
パラメーター一覧 12
安全上のご注意 13

各部の名称

イヤホンのLEDが点灯/消灯/点滅しているときは、ボタンを押すとプロトコルが作動しているようです。

付属品

両耳品：充電ケース*1、イヤホン*2、イヤピース*4、説明書*1、充電USB*1

操作方法一覧

1.電源

電源ON:
MFBを3秒押して、電源ONになります。
(説明：青ランプは点滅するとすぐ
手を放してください。)

電源OFF:
MFBを3秒押してランプは点滅し、次第
電源OFFになります。

2.通話する

通話/終了: MFBを1回押します。
拒否: MFBを2回押します。
リダイヤル: MFBを2回押します。
Siri呼び: MFBを2秒押して、ターンバックの音が聞こえた後手を放します

3.音楽を聴く

音楽再生一時停止:
MFBを1回押します。

前の曲(一"+"を2秒押す)
次の曲("-"を2秒押す)

4.片耳/両耳モード

①初回ご使用の時、任意の片耳を充電ケースから取り出してください。
②BluetoothをONにして、ブルートゥースを検索します。
③Bluetooth機器に"YYK-QA7"を選んで、接続します。

片耳のみを充電ケースに入れたままにしておいてください。

両耳モード

自動：充電ケースから取り出して、自動的に電源オンになりまして、Bluetoothに接続します。
手動：左右のボタンを3秒長押しし、電源オンにして、Bluetoothデバイスに接続します。

スマホのBluetoothデバイスのリストにて"YYK-QA7"を選んでペアリングします。「続ける」との音声を聞いた後、指をリリースしてください。

解決方法：手動でリセットする必要があります

1.スマホのBluetooth機能を一旦閉じてください。オフ前に、前接続したデバイス名"YYK-QA7"を全てキャンセルしてください。
電源をオフにしてください。

2.ケースからそれぞれ左右、手動で電源をオフにしてください。長押しボタンを10秒長押しにしてください。赤と青のランプが点滅した後、

3.左右イヤホンを充電ケースに戻して、充電モードになるか確認してください。

4.左右イヤホンを同時に充電ケースから取り出します。

5.左右イヤホンを同時に充電ケースから取り出します。

イヤホンを充電ケースに入れるとすぐ電源オフになります。
そして、充電し始めます。イヤホンをケースから取り出したら、
すぐ電源オンになります。接続のペアリングしてください。
ペアリングのステップに進びます。

5. ペアをリセット

片耳モードを使えば、両耳モードが解除されます。または接続作によって両耳ペアが崩れたと感じた場合は、下記の処置方法に従ってリセットしてください。

両耳ペア解除の現象
起動後にそれぞれ赤/青ランプが点滅し、スマホに同じ装置名が2つ表示します。2つのイヤホンを同時に使うことはできません。

解決方法：手動でリセットする必要があります

1.スマホのBluetooth機能を一旦閉じてください。オフ前に、前接続したデバイス名"YYK-QA7"を全てキャンセルしてください。

1.Turn off the Bluetooth function of your phone. Before turning off, delete the Bluetooth device name.
Cancel all the previously connected device names "YYK-QA7".

2.ケースからそれぞれ左右、手動で電源をオフにしてください。長押しボタンを10秒長押しにしてください。赤と青のランプが点滅した後、

2. Remove the left and right earphones from the case and manually press and hold the button for 3 seconds to power off.

3.左右イヤホンを充電ケースに戻して、充電モードになるか確認してください。

3. With the device shut down, manually press and hold the multi-function button on the left and right earphones for 10 seconds, until the red and blue lights alternately flash, and then hold for 10 seconds. After the red and blue lights flash twice.

4.左右イヤホンを同時に充電ケースから取り出します。

4. Put the left and right earphones back into the charging case and check if the charging mode is activated.

5.左右イヤホンを同時に充電ケースから取り出します。

5. Remove the left and right earphones from the charging case at the same time and connect them to your phone.

故障かな？と思ったら

Bluetoothについて

1.Bluetoothの通信距離は10mであり、間に障害物がないこと、スマートホンとの距離を確認してください。スマートホンとイヤホンは近くで使用してください。
2.他のスマートホンまたはデバイスがすでにイヤホンに接続されている可能性があります。その場合は、まず接続されたのスマートホン/デバイスとペアリングを解除してください。
3.接続の問題が解決していない場合、Bluetoothデバイスを再起動し、イヤホンをリセットしてみてください。
4.イヤホンを電源を入れてから、5分間にデバイスが見つからない場合、自動シャットダウンになります。
5.他のスマートに接続する場合、イヤホンは先に前接続のデバイスを検索から、2分間ほどいかなければなりません。

充電について

1.充電ケースとは は低電圧のアダプタに問題が無いこと、充電ケースが正しく挿入されていることを確認してください。
2.接続不良の可能性があります。指で左右イヤホンを押し、左右イヤホンの充電接続点は充電ケースに完全に接続してください。
3.左右イヤホンの充電接続点に汚れ、ホコリや汗などがついた可能性があります。布で拭いてください。
4.「バッテリーLOW」の音声が聞こえましたらイヤホンへご充電ください。ケースのLEDディスプレイ数字「10」になりましたらケースへご充電をしてください。イヤホンの電ケースの電源量を使い切りないようにご注意ください。内蔵のリチウムバッテリーの使用寿命を短縮する可能性があります。

自動電源オフについて

イヤホンがセットに完全ではないと判断されない場合、ケースに戻してBluetoothの接続が切れた10分後に自動的にシャットダウンします。その場合は、電源ケースに戻すか、多機能ボタンを2秒間押し続けて電源をオンにしてください。

片耳しか音が聞こえない

まずイヤホンをリセットして、スマートホンを再起動してください。
スマートホンのBluetooth接続機能を閉じたことで、再度接続してペアリングをおこなってください。それでも改善できない場合は、以下の手順をおこなってください。

1.充電ケースから左右イヤホンを取り出し、多機能ボタンを約10秒間長押しし、イヤホンをオフにします。
2.手動で左右のイヤホンの多機能ボタンを10秒長押しし、赤と青のランプが同時に点灯し、指を放します。
3.左右イヤホンを充電ケースに戻して、充電モードになるを確認してください。
4.左右イヤホンを同時に充電ケースから取り出します。
5.スマートホンの接続履歴を削除した後、再度検索してペアリングしてください。

商品仕様

Bluetoothバージョン	TWS V5.3+EDR超低電力技術
サポート契約	A2DP1.3,HFP1.6,HSP1.2,AVRCP1.6,D1.3
Bluetooth周波数	2.402HZ
Bluetooth伝送距離	10m(障害物無し)
イヤホン充電ケース	イヤホンバッテリー容量:130mAh
バッテリー容量	充電ケースバッテリー容量:950mAh
通話/音楽再生時間	片耳音楽再生/通話時間:約18~20時間 両耳音楽再生/通話時間:約12~14時間 (435レベルでの一時表示に表示)
スタンバイ時間:	片耳スタンバイ時間:240時間 両耳スタンバイ時間:200時間
完全充電時間:	1.5時間
マテリン充電ケース重さ:	イヤホン:各5g/ 充電ケース:60g
製品重さ:	160g
製品サイズ:	95*60*34mm

使用上の注意

1.本製品を乱暴に扱わないでください。重い物をイヤホンに押ないでください。
高温高湿の環境に置かないようにご注意ください。
2.WIFIルーターや他の高周波送信機器があるところに置かないでください。
本機の使用に際しましては、使用の中断の中断まかなどの問題にいたします。
3.本製品を有効距離(10m)で使用して、Bluetoothのデバイスとイヤホン間などに
の間に障害物等がないようにしてください。
4.近くの充電器を使って、充電ケースにご充電ください。
5.このイヤホンは任意のBluetoothデバイスに対応できます。
6.長時間ご使用されませんようにしたら、使用前にご充電してください。

安全上のご注意

お使いになる人や他の人への危害、財産への損害を未然に防止するため、下記に記載されていることを、あらかじめ説明しています。
記載している表示・図記号について内容を十分に理解してから本文をお読み頂くようにお願いします。

●表示内容を無視して誤った使い方をしたときに生じる人への危害や損害の程度を、次の表示で区分し、説明しています。

⚠危険	死亡、または重傷を負う可能性が切迫してきなおそれがあるもの。
⚠警告	死亡、または重傷を負う可能性があるもの。
⚠注意	傷を負ったり財物損害が生じる可能性があるもの。

●おかりやしたご内容の種類を、次の絵表示で区分し、説明しています。

注意を与える内容 行為禁止の表示 行為を指示する記号

保証規定

1.この商品を家庭用として、取扱説明、規格書、注意書き などに従って、通常ご使用の場合で、万一、故障が生じた場合には、当社にて無償修理いたします。
2.本書ご一緒ご提出のお客様書(レシートなど)ご持参のうえ、ご購入の時期ご記入ください。
3.ご使用中に故障が生じた場合、ご連絡頂ければ、お客様負担なしで修理いたします。
4.本書は、大切に保管してください。

⚠危険

端子をショートさせないこと。金属製のネックレスやコインなどの金属小物といっしょに携帯または保管しないでください。火災、発火、または感電の原因になります。
ヘッドフォンを電子レンジ、ヒーターなどに挿入したり、高温状態になるような場所に放置しないでください。過熱、発火、または破裂の原因になります。
ぬれた手で本体やUSBケーブルをさわらないでください。けがや感電になります。
本製品を改造したり、分解したりしないでください。火災や感電などの原因になります。
USBケーブルが緩んでいる場合、火災や感電の原因になります。
ぬれた手で本体やUSBケーブルをさわらないでください。感電の原因になります。
本製品を強い衝撃を与えたり、投げたりしないでください。火災や感電などの原因になります。
本製品を、直接火を使用する場所や、ストーブの近くなどに置かないでください。火災や感電などの原因になります。
本製品を、直接日光が当たる場所や、高温になる車の中、浴室などの高温多湿な場所に保管しないでください。火災や感電などの原因になります。

⚠警告

長時間、大音量でヘッドホンなどを使用しないでください。聴力に悪影響を及ぼす原因になります。
音楽を聴いている時に、周囲の音が聞こえにくくなるため、交通事故などの原因になります。
自転車、自動車、バイク、電車、バス、歩行中などでは、使用しないでください。
USBケーブルは確実に差し込んでください。ぬれた手で差し込まないでください。火災や感電などの原因になります。
ぬれた手で本体やUSBケーブルをさわらないでください。感電の原因になります。
本製品を改造したり、分解したりしないでください。火災や感電などの原因になります。
USBケーブルが傷んだり、端子が緩んでいるときは使用しないでください。火災や感電などの原因になります。
ぬれた手で本体やUSBケーブルをさわらないでください。感電の原因になります。
本製品を強い衝撃を与えたり、投げたりしないでください。火災や感電などの原因になります。
本製品を、直接火を使用する場所や、ストーブの近くなどに置かないでください。火災や感電などの原因になります。
本製品を、直接日光が当たる場所や、高温になる車の中、浴室などの高温多湿な場所に保管しないでください。火災や感電などの原因になります。

保証対策

1.お客様保証期間
2.使用上の注意を本書ではいただけないかたことによる故障に関しては保証対象外とさせて頂きました。

ユーザー名前：
保証カード番号：
電話番号：
アドレス：
購入時期：
シリーズ番号：
販売店名：
販売店アドレス：
販売店電話番号：
故障説明：