105mm

anko

K 4335355 | T 6976980 (Model: JLR-7977)

Bluetooth Speaker and Alarm Clock Instruction Manual

Safety instructions:
Please read all safety instruction warnings carefully before using this product. Improper use of the product may result in damage to this product. To ensure the production works well, please never use this in the following conditions.

1. The system shall not be placed in a high temperature and humid environment, let alone be caught in the rain, to avoid damage to the host.
2. Do not open the back cover at will to prevent electric shock and other accidents.
3. If maintenance is needed, please ask the company's maintenance station or professional maintenance personnel to deal with it.
4. If the battery is replaced improperly, there will be an explosion risk, which can only be replaced with the same or equivalent battery.
5. In order to avoid charging failure, the original USB cable for charging. Accidents and machine damage caused by non-original charging cables are not enjoy free warranty.
6. The product using the power of high temperature, exposure, fire source position, in order to prevent the battery explosion and other dangers!

Product features:
1 Compatible with Bluetooth® enabled devices
2 Built-in 1200 mAh battery
3 Play time up to 16 hours
4 Support TF card (support 16G max)

Packing contents:
Speaker *1
Manual *1
Type-C charging cable *1

Product overview:
In the power on state, display the "HI" welcome message, in Bluetooth mode display "BLUE", in radio mode display radio frequency, in TF playback, show the time of the song played, after 10 seconds, show the clock time.



1



1. Power on/off / play / pause
2. Mode
3. Previous song / volume decrease
4. Next song / volume increase
5. Time set
6. Bluetooth mode indicator
7. TF Card mode indicator
8. FM Radio mode indicator
9. Alarm 1 indicator
10. Alarm 2 indicator
11. TF Card slot port
12. Type C charging port
13 Charging light

2

Functional description:

General function:
1. Main volume: in any play state, short press "-" to reduce the volume, short press "+" to increase the volume, long press "-" fast song down.
2. Mode: Play status switch button, the switch order is: BT-TF-FM
3. Next song: short press the button "+" to switch, highly

Song Function Description:
1. TF disk: insert the TF disk with songs in MP3 / WAV format for playing.
2. Play / pause button: Short press for play / pause function in play mode.
3. Next song / fast song button: long press in playing mode: for the previous song, long press + for the next song.

Bluetooth function description:
1. Bluetooth connection: power on, automatically enter the Bluetooth waiting for pairing state, open the mobile phone Bluetooth search device model is "ankuoh320305 ", click pair, and the speaker will automatically enter the Bluetooth connection state.
2. When playing music: long press -/+ in previous song and next song.

FM radio function Description:
1. Turn on the power switch, enter the FM mode, FM blue light on.
2. Double-click the power on/off button, enter the automatic radio automatic search. The first channel will play automatically after the search.
3. Long press -/+ to switch channel.

Clock function description:
1. Clock Settings: Short press "SET" to enter time setting, then short press "SET" to choose hour/minute, short press "+/-" to adjust hour /minute, long press "SET" to save setting.
2. Alarm Settings: double-click the "SET" to enter alarm setting, then short press "SET" to choose hour/minute, short press "+/-" to adjust hour /minute, then short press "SET" to enter alarm CRYCN, short press "+/-" to choose alarm CRYCN, then continue to short press "SET" to setting alarm 2. The alarm clock 11 blue light will be turned on if the alarm clock ON.

Note: the alarm settings need to be completed setting two alarms at once, if exiting midway will not save the settings.

3. Short press any button can cancel alarms clock prompt sound.
4. The alarm clock can be only works when power on, so please charge the speaker in time. It's better to keep connecting a 5pcs charge cable all the time.

Charging indication and battery low description:
1. When the speaker shows 20%, it means that charging is needed to enter the low power state, and the speaker will automatically shut down after 5 minutes of the main volume.
2. When charging, use the USB cable delivered by the product for charging. USB power supply should be more than 5V / 1A, the current less than 1A will lead to longer charging time.

Note: 12 hours of full charge is good for the first charge. If the battery is not used for a long time, it should be replaced before use, otherwise the battery will be damaged.

3

Specification:
Output power: 2W
Speaker frequency range: 200Hz-20K Hz
Speaker specification: 4 Ω * 1
SNR: ≥80dB
Power supply voltage: USB 5V
Product size: 147*87mm

12 Month Warranty

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.
For New Zealand customers, the warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear reasonable expenses of returning the goods.
This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below. Any costs for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd Customer Service Centre 690 Springvale Road, Mulgrave Vic 3170 Australia wide 1300 124 125 (Australia) or 0800 945 883 (New Zealand) Or via Customer Help at kmart.com.au	Target Australia Pty Ltd Level 5, Corporate Centre 2 Kendall Street, Williams Landing, VIC 3027 Customer Service 1300 753 067 or via Customer Help at target.com.au/help/contact-us

4

back

70 mm

front