Please read the instruction carefully before using it.

Note:

Before turn on the amplifier, operate that the MIC don't point at the amplifier, avoid any anonymous accelerated sirth howling, for ensure better amplification, and keep the acoustic MIC capsule when speaking, and keep the distance between the voice amplifier and the MIC almost the same as the speaker around waist, and mounting distance.

Function Illustration:

Function Illustration:

1.Power switch and volume control: Rotate the knob to "+" to turn on the amplifier,the blue mode indicator will volume till the amplifier is turn on;

volume rotate to "-" continuously to decrease the volume, rotate to "+" continuously to increase the volume till the amplifier is turn off.

2.Mode: Short press to switch to TF card mode /FM mode/Bluetooth mode/UHF mode(for wireless version only).

3.Previous: Short press to play previous song,Long press to fast rewind.

4.Play / pause: Short press to play or to pause,and fast again to forward.

5.Next: Short press to play next song,Long press to fast forward.

6.Mode indicator

7.Microphone Jack: Insert the wired microphone into this socket to amplify voice.

8.TF card slot: Insert the TF card to play audio, the maximum capacity is 32GB.

9.DC 5V charging port: Please use the DC 5V power adapter to charge the speaker.

10.Charging indicator

Specification:

Max output power	10W	Frequency response	100Hz-18KHz
Signal noise	≥80db	Charging time	2-3hours
Microphone sensitivity	5-7hours	Charging time	2-3hours

产品使用注意事项:

1、为了达到适切的音量效果，请将琴头放置离正面前方1-2CM处对准琴头处发音，若有啸声，可适当调小音量或将机器与琴头的距离拉开，以防出现干扰；

2、尽量避免频繁或强度灭风插口，以免造成插口松动而引起接触不良，不可将诱惑和音源插错；

3、为保证锂电池使用寿命，建议使用完两充电，频繁充电将加速电池芯片老化，长时间不用时应每隔两个月充一次电；

4、因响机锂电较强，不可将机器和银行卡等带磁性的东西放一起，以免造成无磁性带来不必要的麻烦；

5、本产品所有配件皆按本机工作需要设计，如需更换配件尽量使用本公司提供配件，以达到最佳工作状态；

6、本产品在充电和正常使用过程中可能会经保变热，这属于正常现象；

7、请使用抗静电软布来清洁擦拭本产品，在清洁本产品时请先关闭电源开关，并用开有外部插孔，请勿用化学物质擦拭（如：酒精、苯等化学剂或有敏感性的清洁擦拭剂）；

8、若在博洛，抛掷或者踩踏本产品，请勿擅自拆解本产品，否则不予享受本公司的免费保修服务；

9、将会“微功率短距离无线电发射设备目录和技术要求”的具体条款和使用场景，采用的无线类型和性能，控制、调整及开关等使用方法；

10、不得擅自改变使用场景或使用条件，扩大发射频率范围，加大发射功率（包括额外加装射频功率放大器），不得擅自更改发射天线；

11、不得对其他合法的无线电设备（以下简称“其他无线电设备”）产生有害干扰，也不得提出其他受有害干扰保护；

12、应当承受辐射射频能量的工业、科学及医疗（ISM）应用设备的干扰或其他合法的无线电台（以下简称“其他无线电台”）干扰；

13、如对其他合法的无线电台（以下简称“其他无线电台”）产生有害干扰时，应立即停止使用，并采取措施消除干扰后方可继续使用；

14、在防空器内和依据法律法规、国家有关规定、标准划定的航天文业、气象意动站、卫星地球站（含测控、测距、接收、导航站）等军民用无线电台（站）机场等的电磁环境保护区域内使用微功率设备，应当遵守电磁环境保护及相关行业主管部门的规定；

15、禁止在以机场跑道中心点为圆心，半径5000米的区域内使用各类模型遥控器；

16、微功率设备使用时温度和电压的环境条件。

17、制造型号-S29. 销售型号:S820(具体型号以实物为准)

常见问题的自我解决:

1、开关开启，扩音器没有声音

A、显示屏不亮，电池没电，充电解决；

B、检查话筒是否损坏位置。

2、扩音器有明显噪叫

A、正确配戴话筒，将麦头尽可能对准嘴角方向，麦克风与主机保持60-70CM距离。

B、空间受小时应适当调低音量以减少回声造成啸叫。