midocean MO9921 Alarm Clock User Manual

Contents

1 midocean MO9921 Alarm Clock
2 Instructions
2.1 Features
3 Precautions
4 Documents / Resources
4.1 References
5 Related Posts

midocean MO9921 Alarm Clock

Instructions

Features

1. **Display mode**: Time, date, temperature
2. **Calendar:** 2000-2099 years
3. Temperature(C/F)
4. 12/24H format selectable: (initial mode:24-hour)
5. Three groups of alarm, each alarm 1 minute
6. 18:00-07:00 half luminance; and four luminance to set (L0 – L1 – L2 – L3)
7. 4xAAA batteries (not included) or DC(5V/500mA) power

Display and keys

1. Display mode select DP-1/DP-2 Initial mode DP1; Press “SET” to transform DP1-DP2
2. Sound control mode select (Power-saving mode on AAA batteries): Press “DOWN on: Sd” means sound control works; “-:SD” means sound control closed
3. Press “UP” to change temperature display format C–I.
4. Press “SET” for 3 seconds to enter the setting mode, set: YEAR -MONTH-DATE12H/24HHOUR MINUTE-AL(ALARM) -ALA1-ALA2-ALA3-WORKDAR ALARM ON/OFF YEAR symbol flashing. press “UP” or “DOWN” key; MONTH symbol flashing, press “UP” or “DOWN” key; 12 hour format display; a red dot will display next to time figure at the afternoon.
5. **Display luminance adjustment**
   Press and hold “UP” key for 3 seconds, “L3” wil show on the display. Press “DOVWN” key to decrease luminance level to “L2”. Press “UP” key for luminance enhancement. 4 different levels: L3-0.
6. **RESET**
   Press the button “RESET” to reset the setting

Precautions

1. Use the clock in dry area only do not wet or keep in extreme heat location.
2. Take out the AAA battery from battery compartment if power is depleted.
3. Only 5V/500mA AC adapter is applicable for power supply.

Documents / Resources

	midocean MO9921 Alarm Clock [pdf] User Manual MO9921, Alarm Clock, MO9921 Alarm Clock, Clock

References

- Export
- Error during processing.

Manuals+.