Manuals+ — User Manuals Simplified.

Parani A10 Motorcycle Intercom User Guide

Parani A10 Motorcycle Intercom User Guide

Contents

PRODUCT FEATURES

Blast your favorite tunes, talk over the intercom with your buddies, hear directions from your GPS and more, all through your A10 Bluetooth® headset. With built-in Bluetooth® capabilities, HD Intercom, technology has never felt so minimal or freeing.

- ✳ Bluetooth® Integrated
- 🎧 Intercom up to 1 km (0.6 mi)*
- Four-way Intercom
- LCD Display
- ⬇ Firmware Upgradeable

GETTING STARTED

Update this product for free with the latest firmware to fully enjoy the new advanced features built into this product. Visit **parani.com** to see how to update your product.

BEFORE STARTING

Package Contents

Wired Boom Microphone Type

- Headset Main Unit

Multi-function Button
(+) Button
(-) Button
Speakers and Microphone Port
LCD Display
DC Power Charging & Firmware Upgrade Port

- Speakers and Wired Boom Microphone

Wired Boom Microphone

- Clamp

- Glued Surface Mounting Adapter.

- Speaker Sponge (2)

- Microphone Sponge (2)

- Hook and Loop Fasteners for Speakers (2)

- USB Power & Data Cable (USB-C)

INSTALLING THE HEADSET ON YOUR HELMET

Before installing the headset, you need to choose between the clamp and the glued surface mounting adapter. To install the headset to the helmet, follow the steps below:

Using the Clamp

1. Insert the main module into the clamp using the two connecting slots on the back.
2. Insert the headset into the helmet using the clamp.

Using the Glued Surface Mounting Adapter

1. Insert the main module into the glued surface mounting adapter using the two connecting slots on the back.

2. Remove the cover of the adhesive sticker on the back to glue the headset on to the helmet.
3. Attach the headset on the left side of the helmet.

Installing the Speakers

Wired Boom Microphone Type

If you want to install speakers into the headset, follow the steps below:

1. Remove the cover of the adhesive sticker of the hook and loop fasteners for speakers.
2. Place the sticker on the helmet.

3. Place the speaker on the hook and loop fasteners.
4. Insert the Speakers and Microphone plug into the headset.

Note:

- If your speakers are too close to your ears and your ears are uncomfortable, you can attach a Speaker Sponge to the front of the speaker.
- Make sure that the microphone is located properly close to your mouth when you wear the helmet. Adjust the direction of the microphone so that the fin side of the microphone is facing outward, away from your lips.

Wired Microphone Type

If you have a full face helmet, you can use the wired microphone.

1. Remove the cover of the adhesive sticker of the hook and loop fasteners for speakers.

2. Place the sticker on the helmet.

3. Place the speaker on the hook and loop fasteners.

4. Peel off the cover of the hook and loop fastener for wired microphone to expose the adhesive tape. Then, attach the hook and loop fastener on the inside of the helmet's chin guard.

5. Attach the wired microphone to the hook and loop fastener for wired microphone.

6. Insert the Speakers and Microphone plug into the headset.

GETTING STARTED

Button

Tap/
Press and Hold

Multi-function Button

(+) Button

(-) Button

LCD Display

Battery Indicator

Pairing Status

Active Function — MUSIC

Volume Bar

Charging the Headset

The headset can be charged using many common methods via the supplied USB power & data cable. Depending upon the charging method, the headset will be fully charged in about 2.5 hours.

It takes about 2.5 hours to be completely charged.

Charging Status LCD

Charging   Fully Charged

Note:

- Any 3rd party USB charger can be used with Sena products if the charger is approved by either the FCC, CE, IC or other locally approved agencies that Sena accepts.
- The headset is compatible with 5 V input USB charged devices only.

Powering On and Off

- To power on the headset, press and hold the **(+) Button and (-) Button for 1 second.**

- To power off the headset, tap the **(+) Button and (-) Button.**

Adjusting the Volume

You can raise or lower the volume by tapping the **(+) Button** or the **(-) Button.** Volume is set and maintained independently at different levels for each audio source (i.e., phone, intercom), even when the headset is rebooted.

Downloadable Parani Software

Parani Device Manager

The **Parani Device Manager** allows you to upgrade firmware and configure settings directly from your PC. For more information on downloading the **Parani Device Manager**, please visit **parani.com**.

PAIRING YOUR HEADSET WITH OTHER BLUETOOTH DEVICES

Before using the headset with other Bluetooth devices for the first time, they will need to be "paired." This enables them to recognize and communicate with one another whenever they are within range. The headset can pair with multiple Bluetooth devices such as mobile phone, MP3 player, or GPS via Phone Pairing, Second Mobile Phone Pairing. The headset can also be paired with another Parani headset.

Phone Pairing

There are three ways to pair the phone.

Initially Pairing the A10

The headset will automatically enter the phone pairing mode when you initially turn on the headset or in the following situations:

- Rebooting after executing the **Factory Reset** feature; or
- Rebooting after executing the **Delete All Pairings feature.**

1. Press and hold the **(+) Button** and **(-) Button** for **1 second.** You will hear a voice prompt, **"Phone pairing".**

2. On your smartphone, search for **Parani A10.**
3. Enter 0000 for the PIN. Some smartphones may not ask for PIN.

Note:

- The phone pairing mode lasts for **3 minutes.**
- To cancel phone pairing, tap the M **ulti-function Button**.

Pairing When the A10 is Turned Off

1. While the headset is off, press and hold the (+) Button and (-) Button for 5 seconds. You will hear a voice prompt, "Phone pairing".
2. On your smartphone, search for **Parani A10.**
3. Enter 0000 for the PIN. Some smartphones may not ask for PIN.

Pairing When the A10 is Turned On

1. While the headset is on, press and hold the **Multi-function Button** for **8 seconds.** You will hear a voice prompt, **"Phone pairing".**

2. On your smartphone, search for **Parani A10.**
3. Enter 0000 for the PIN. Some smartphones may not ask for PIN.

Second Mobile Phone Pairing

1. To enter the configuration menu, press and hold the Multi-function Button for 12 seconds until you hear a voice prompt, "Configuration menu".
2. Tap the (+) Button until you hear a voice prompt, "Second mobile phone pairing".

3. On your smartphone, search for Parani A10.

4. Enter 0000 for the PIN. Some smartphones may not ask for the PIN.

MOBILE PHONE USAGE

Using Phone Functions

- **Answering a call**

  Tap the Multi-function Button.

- **Ending a call**

  Tap the Multi-function Button.

- **Rejecting a call**

  Press and hold the Multi-function Button for 2 seconds.

- **Make a Call with Voice dialer**

  Press and hold the Multi-function Button for 3 seconds in stand-by mode to activate the voice dialer of your mobile phone.


Speed Dialing

Assigning Speed Dial Presets

You need to assign speed dial numbers before using the speed dial. Speed Dial Presets could be assigned in the configuration menu.

Using Speed Dial Presets

1. Press and hold the (+) Button for 3 seconds and you will hear a voice prompt, "Speed dial".

2. Tap the (+) Button or the (-) Button to navigate between the menus. You will hear prompts for each menu item.
3. Tap the Multi-function Button to select a voice menu among the followings:

Last Number Redial

Speed Dial 1

Speed Dial 2

Speed Dial 3

Cancel

4. To redial the last number called, tap the Multi-function Button when you hear a voice prompt, "Last number redial".
5. To call one of the speed dials, tap the Multifunction Button when you hear a voice prompt, "Speed Dial (#)".
6. If you want to exit the speed dial immediately, tap the (+) Button or the (-) Button until you hear a voice prompt, "Cancel", and tap the Multi-function Button.

STEREO MUSIC

- **Play/Pause music**

  Press and hold the Multi-function Button for 1 second.
- **Track forward/back**

  Press and hold the (+) Button or the (-) Button for 1 second.

BLUETOOTH INTERCOM

Intercom Pairing

The headset can be paired with up to three other **Parani** headsets for Bluetooth intercom conversation.

1. Press and hold the Multi-function Button of the headset A and B for 5 seconds until you hear a voice prompt, "Intercom pairing".
2. Tap the Multi-function Button on either headset and wait until the intercom connection is automatically established.
3. Repeat steps 1 and 2 to pair with Intercom Friends C & D.
4. The intercom pairing queue is 'Last-Come, First-Served'. If a headset has multiple paired headsets for intercom conversations, the last paired headset is set as first intercom friend. The previous intercom friend becomes second intercom friend, and third intercom friend.

Last-Come, First-Served

Two-way Intercom

You can start/end an intercom conversation with one of any intercom friends by tapping the **Multifunction Button.**

- Tap the Multi-function Button

Intercom
Friend 1

- Double tap the Multi-function Button.

Intercom
Friend 2

- Triple tap the Multi-function Button.

Intercom
Friend 3

HD Intercom

HD Intercom enhances the two-way intercom audio from normal quality to HD quality. When you enter into a Multi-Way Intercom, HD Intercom will be automatically disabled. If this feature is disabled, the intercom audio will change to normal quality.

Note: HD intercom is only active for two-way intercom.

Multi-Way Intercom

Multi-Way Intercom enables conference-call-style conversations with up to three intercom friends at the same time. While Multi-Way Intercom is in progress, mobile phone connection is temporarily disconnected. However, as soon as Multi-Way Intercom terminates, the mobile phone connection will be reestablished.

## Start a Three-Way Intercom Conference

You (A) can have a three-way conference intercom with two other **intercom friends (B & C)** by establishing two intercom connections at the same time.

1. You (A) need to be paired with two other **friends (B & C)** for three-way conference intercom.


YOU

Intercom
Friend B

Intercom
Friend C

2. Start an intercom conversation with one of the two friends in your intercom group. For example, you (A) may start an intercom conversation with intercom friend (B). Or intercom friend (B) may start an intercom call with

you (A).

3. The second intercom friend (C) may join the intercom by making an intercom call to you (A).


4. Now you (A) and two intercom friends (B & C) are having a three-way conference intercom.

Starting a Four-Way Intercom Conference

You can have four-way conference intercom with three other intercom friends by adding one more intercom participant to the three-way intercom. A new participant (D) can make it a Four-Way Intercom Conference by making an intercom call to either (B) or (C).

Ending Multi-Way Intercom

You can completely terminate the conference intercom or just disconnect an intercom connection with one of your active Intercom Friends.

- **Terminate all intercom connections**

  Press and hold the Multi-function Button for 1 second.

- **Disconnect the intercom connection with one of the intercom friends**

  When you disconnect the second friend (C), you will be disconnected with the third participant (D) as well. This is because the third participant (D) is connected with you via the second friend (C). Disconnect (B) : Tap the Multi-function Button. Disconnect (C) & (D) : Double tap the Multifunction Button.

GENERAL SETTINGS

Function Priority

The headset operates in the following order of priority:

- **(highest)** Mobile phone Bluetooth Intercom
- **(lowest)** Bluetooth stereo music

A lower priority function is always interrupted by a higher priority function.

Configuration Menu

You can set the configuration of the headset by the voice menu instruction described below.

1. Press and hold the Multi-function Button for 12 seconds until you hear a voice prompt, "Configuration menu".

2. Tap the (+) Button or the (-) Button to navigate between the menus. You will hear voice prompts for each menu item.
3. You can enable/disable the feature or execute the command by tapping the Multifunction Button.

| Configuration Setting	Enable/Disable or Execute
 Second Mobile Phone Pairing	None
 Speed Dial	Execute
 Voice Prompt	Enable/Disable
 Delete All Pairings	Execute
 Factory Reset	Execute
 Exit Configuration	Execute

Assigning Speed Dial

1. To assign a phone number as a speed dial, tap the (+) Button until you hear a voice prompt, "Speed dial".
2. Tap the Multi-function Button, and you will hear a voice prompt, "Speed dial one" and "Phone connected".
   Tap the (+) Button or (-) Button to select one of three speed dial numbers by hearing a voice prompt, "Speed dial (#)".

Assigning Speed Dial

1. To assign a phone number as a speed dial, tap the (+) **Button** until you hear a voice prompt, **"Speed dial".**

2. Tap the Multi-function **Button,** and you will hear a voice prompt, "Speed dial one" and "Phone connected". Tap the (+) Button or (-) Button to select one of three speed dial numbers by hearing a voice prompt, "Speed dial (#)".


Speed Dial 1   Speed Dial 2

Speed Dial 3

3. Call a phone number you want to assign and you will hear a voice prompt, "Save speed dial (#)". The phone number is automatically assigned to the selected speed dial number. Then the phone call will hang up immediately.

4. To exit the menu, tap the (+) Button or (-) Button until you hear a voice prompt, "Cancel", and tap the Multi-function Button to confirm. You will then hear a voice prompt, "Cancel".

Voice Prompt (Default: Enable)

You can disable voice prompts by configuration setting, but the following voice prompts are always on.

- Voice prompts for configuration setting menu
- Voice prompts for factory reset
- Voice prompts for speed dial

Delete All Pairings

Delete all Bluetooth pairing information.

Firmware Upgrades

The headset supports firmware upgrades. You can update the firmware using the Parani Device Manager. Please visit Parani website at **parani.com** to check the latest software downloads.

TROUBLESHOOTING

Fault Reset

When the headset is not working properly, you can easily reset the unit:

1. Locate the Pin-hole reset button below on the back of the main unit.
2. Gently insert a paperclip into the hole and tap the Fault Reset Button with light pressure.

3. The headset will shut down.

Note: Fault Reset will not restore the headset to factory default settings.

Factory reset

If you want to restore the headset to factory default settings, use the Factory Reset in the configuration menu. The headset automatically restores the default settings and turns off.

Documents / Resources

Parani A10 Motorcycle Intercom [pdf] User Guide
A10, Motorcycle Intercom, A10 Motorcycle Intercom

References

- 🌐 **Parani | Bluetooth Smart Helmet Headset – Parani US**