Manuals+ — User Manuals Simplified.

WAVE XLR XLR Microphone Interface and Digital Mixing Solution User Guide

Contents

WAVE XLR XLR Microphone Interface and Digital Mixing Solution

OVERVIEW

WAVE XLR

Turn
Adjust

Push
Select Mode

Long Push
Toggle Phantom Power

Mic Gain
Headphone Volume
Mic/PC Mix
48 Volt Phantom Power

Tap to mute or unmute

MUTE

USB-C
Direct Monitor/3.5 mm Mini Jack
XLR Mic Input

INSTALLATION INSTRUCTION

1. Download the Elgato Wave Link app to get started.
2. Use the supplied USB-C cable to connect Wave XLR to your computer.


elgato.com/download

3. Toggle phantom power by pushing the control dial for 2 seconds.
4. Connect your mic using a standard XLR microphone cable.

5. Connect your headphones to the 3.5 mm jack.

6. Push the control dial to toggle between Mic Gain, Headphone Volume, and Mic/PC Mix.

7. Tap the capacitive sensor on the back of the unit to mute or unmute.

8. Easily switch out the faceplate to personalíze your setup.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed t0 provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. f this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. For questions about Elgato product compliance with FCC regulations, please contact Compliance Officer, Corsair Memory Inc., 115 North McCarthy Blvd, Milpitas,

CA 95035, USA

THIS PRODUCT HAS BEEN DESIGNED TO ASSIST YOU IN REPRODUCING MATERIALS IN WHICH YOU OWN THE COPYRIGHT OR HAVE
0BTAINED PERMISSION TO COPY FROM THE COPYRIGHT OWNER. UNLESS YOU OWN THE COPYRIGHT OR HAVE 0BTAINED PERMISSION
TO COPY FROM THE COPYRIGHT OWNER, YOU MAY BE VIOLATING COPYRIGHT LAW AND BE SUBJECT TO PAYMENT OF DAMAGES AND
OTHER REMEDIES. IF YOU ARE UNCERTAIN ABOUT YOUR RIGHTS YOU SHOULD CONTACT YOUR LEGAL ADVISOR.

Documents / Resources

WAVE XLR XLR Microphone Interface and Digital Mixing Solution [pdf] User Guide
XLR Microphone Interface and Digital Mixing Solution, XLR, XLR Microphone Interface, Microphone Interface and Digital Mixing Solution, Microphone Interface, Digital Mixing Solution, Mixing Solution

Manuals+,