

# **AAMP Commercial P-BUA-TRANSIT Wiring Harness for Backup Alarm Instruction Manual**

Home » AAMP Commercial » AAMP Commercial P-BUA-TRANSIT Wiring Harness for Backup Alarm Instruction Manual ™

**AAMP Commercial P-BUA-TRANSIT Wiring Harness for Backup Alarm** 



## Thank you for purchasing the P-BUA-TRANSIT

#### **Contents**

- 1 WHAT'S INCLUDED:
- **2 COMPATIBLE ACCESSORIES:**
- **3 TOOLS REQUIRED:**
- **4 INSTALLATION**
- **INSTRUCTIONS**
- **5 CUSTOMER SUPPORT**
- 6 Documents / Resources
- **7 Related Posts**

## **WHAT'S INCLUDED:**

• Vehicle Specific Wire Harness (P-BUA-TRANSIT)

# **COMPATIBLE ACCESSORIES:**

• 97dB Backup Alarm (BUA-97C)

## **TOOLS REQUIRED:**



- 1. 10mm Nut-setter
- 2. T-25 Torx Bit
- 3. Diagonal Cutters
- 4. Impact Drill

# **INSTALLATION INSTRUCTIONS**

## STEP 1:

Remove the (2) T-25 torque fasteners that are holding the tail lamp in place.



## STEP 2:

- Unplug the OEM tail lamp connection.
- Install the P-BUA-TRANSIT harness inline between the two OEM tail lamp connectors.



STEP 3:

Route the harness down through the bottom of the tail lamp opening, behind the bumper skin, and below the vehicle.



# STEP 4:

Use an impact drill and 10mm nut-setter to install a compatible backup alarm beneath the driver side rear corner of the vehicle.



**Note**: (2) 10mm TEK screws are provided with the compatible backup alarm.

# STEP 5:

Use the provided p-clamps and self tapping screws to secure the harness to the underside of the vehicle.



## STEP 6:

Plug the backup alarm connector into the mating connector on the P-BUA-TRANSIT harness.



#### STEP 7:

Re-install the tail lamp assembly and test the backup alarm.

#### **CUSTOMER SUPPORT**

Phone – 866-931-2021(option 3)

E-Mail – <a href="mailto:support@aampglobal.com">support@aampglobal.com</a>

AAMP Commercial is a Power Brand of AAMP Global

aampcommercial.com



#### **Documents / Resources**



AAMP Commercial P-BUA-TRANSIT Wiring Harness for Backup Alarm [pdf] Instruction Manual

P-BUA-TRANSIT Wiring Harness for Backup Alarm, P-BUA-TRANSIT, Wiring Harness for Backup Alarm, Harness for Backup Alarm

Manuals+,