




AMP RESEARCH 2015-2016 Running Board Assembly Installation Guide

[Home](#) » [AMP RESEARCH](#) » AMP RESEARCH 2015-2016 Running Board Assembly Installation Guide 

AMP RESEARCH 2015-2016 Running Board Assembly

Contents

- [1 INSTALLATION GUIDE](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)
- [3 Related Posts](#)

INSTALLATION GUIDE

Attaching motor to Linkage assembly. To be assembled in Steps 6.

EXPLODED VIEW

- Motor
- Socket cap screw
- Washer
- Drive Gear Housing Cover

CAUTION: HANDLE WITH CARE.

The motor must be put on in Step 6 after the linkage is tightened to the body of the vehicle.

To ensure our customers receive all components with full integrity, we pack the motors separate from their linkage assemblies. This requires that the installer position and fasten the motor before continuing with the install. Please follow the instructions below and handle the assembly carefully.

CAUTION: Dropping the assembly or any excessive impact MAY cause damage to the motor. Instructions:

1. Position the gear cover in place as shown if not already in place.
2. Seat motor into position on the three mounting bosses. This may require an adjustment of the gear by moving the swing arms.
3. After seating into place, fasten the motor with the three motor mount screws with 4mm Hex Head. Tighten screws to 36 in-lbs (4N-m). Do not over torque.

AMP RESEARCH POWERSTEP T M – CHEVROLET / GMC


Note: Some Applications require modification.

Application Cut Length

Crew Cab 85" (No Modification Required)

Extended Cab 79" (Trim 6" off of Board)

Documents / Resources

	<p>AMP RESEARCH 2015-2016 Running Board Assembly [pdf] Installation Guide 2015-2016 Running Board Assembly, 2015-2016, Running Board Assembly, Board Assembly</p>
---	---

References

- [AMP Research Accessories | RealTruck](#)
- [RealTruck Warranty Registration | RealTruck](#)