

Culligan WBA

Culligan WBA HD950 Whole House Water Filter Mounting Bracket User Manual

1. PRODUCT OVERVIEW

This manual provides instructions for the installation, operation, and maintenance of the Culligan WBA HD950 Whole House Water Filter Mounting Bracket. This bracket is designed to securely mount Culligan Big Blue and Big Clear whole house filter housings to a wall, ensuring stability and proper function of your water filtration system.



Image showing the L-shaped Culligan WBA HD950 mounting bracket made of zinc-plated steel, designed to secure whole house water filter housings. Four screws are visible in the foreground, intended for attaching the filter housing to

2. COMPONENTS INCLUDED

The Culligan WBA HD950 Mounting Bracket package includes the following items:

- 1 x Culligan WBA HD950 Mounting Bracket (Zinc Plated Steel or Stainless)
- 8 x Mounting Screws (5/16" x 1-1/2") for attaching the bracket to the filter housing.

Note: Additional hardware for mounting the bracket to the wall (e.g., lag bolts, wall anchors) is not included and must be purchased separately based on your wall material.

3. SETUP AND INSTALLATION

3.1 Tools Required

- Drill
- Drill bits (appropriate for wall material)
- Level
- Measuring tape
- Pencil
- Appropriate wall anchors/screws (not included for wall mounting)

3.2 Safety Precautions

- Ensure the main water supply is turned off before beginning any installation work.
- Wear appropriate personal protective equipment, including safety glasses.
- If you are unsure about any step of the installation process, consult a professional plumber.

3.3 Installation Steps

1. **Select Mounting Location:** Choose a sturdy wall surface capable of supporting the combined weight of the filter housing, bracket, and water. Ensure there is sufficient clearance around the filter housing for future filter changes and maintenance.
2. **Mark Mounting Points:** Hold the bracket against the wall at the desired height and position. Use a level to ensure the bracket is perfectly straight. Mark the locations for the wall mounting screws through the bracket's holes.
3. **Prepare Wall:** Drill pilot holes at the marked locations. The size of the drill bit will depend on the type of wall material and the wall mounting hardware you are using. Insert wall anchors if necessary (e.g., for drywall installations).
4. **Mount Bracket to Wall:** Secure the bracket to the wall using suitable screws or lag bolts (not included). Ensure the bracket is firmly attached and level. Over-tightening can damage the wall or bracket.
5. **Attach Filter Housing:** Align the top of your Culligan Big Blue or Big Clear whole house filter housing with the bracket. Use the eight provided 5/16" x 1-1/2" screws to securely fasten the filter housing to the bracket. Ensure the housing is properly seated and tightened to the bracket.
6. **Verify Installation:** Double-check all connections and mounting points for stability and tightness before restoring the water supply. Slowly turn on the water supply and check for leaks.

4. OPERATING INSTRUCTIONS

The Culligan WBA HD950 mounting bracket functions as a stable support for your whole house water filter housing. Once correctly installed, it securely holds the filter housing in place, preventing movement and reducing stress on plumbing connections during normal operation and when performing filter cartridge replacements.

5. MAINTENANCE

- **Regular Inspection:** Periodically inspect the bracket and its mounting points for any signs of corrosion, loosening, or damage. This is especially important during routine filter changes.
- **Cleaning:** Clean the bracket with a damp cloth as needed to remove dust or debris. Avoid using harsh or abrasive cleaners that could damage the finish of the zinc-plated steel.
- **Fastener Check:** During filter changes, verify that the eight screws attaching the filter housing to the bracket are secure. Tighten if necessary, but do not over-tighten.

6. TROUBLESHOOTING

- **Bracket feels loose after installation:** Check all wall mounting screws and the screws attaching the filter housing to the bracket. Tighten any loose fasteners. If wall anchors were used, ensure they are still securely seated in the wall.
- **Signs of corrosion observed:** The bracket is constructed from zinc-coated steel or stainless steel for enhanced corrosion resistance. If corrosion appears, clean the affected area thoroughly. For minor surface rust, a rust-inhibiting primer and paint can be applied if the finish is compromised. Ensure the installation environment is not excessively humid or exposed to corrosive chemicals.

7. SPECIFICATIONS

Attribute	Detail
Brand	Culligan
Model Number	WBA
Part Number	WBA
Material	Zinc Plated Steel or Stainless
Product Dimensions (L x W x H)	6.19 x 5.06 x 7.88 inches
Item Weight	1.4 pounds
Mounting Type	Plate Mount
Finish Type	Matte
Thickness	1 Inches
Included Components	Mounting Bracket, 8 Screws (for housing attachment)
UPC	033663005273

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This Culligan WBA HD950 Mounting Bracket comes with a standard manufacturer's warranty. For specific warranty details, including coverage period and terms, please refer to the documentation included with your original purchase or contact Culligan customer service directly.

8.2 Customer Support

For further assistance, technical support, or any inquiries regarding your Culligan product, please visit the official [Culligan Store on Amazon](#) or the main Culligan website. You can also find contact information for their customer service department there.

© 2025 Culligan. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question