Scosche AU2392B

Scosche AU2392B Dash Kit Instruction Manual

Model: AU2392B

Introduction

This instruction manual provides detailed guidance for the installation and proper use of the Scosche AU2392B DIN w/ISO Trim Dash Kit. This kit is designed to facilitate the installation of an aftermarket car stereo into specific 2006-2008 Audi A3 vehicles, ensuring a seamless and professional fit. Please read all instructions carefully before beginning the installation process.

Safety Information

Always prioritize safety during installation. Failure to follow these guidelines may result in damage to the vehicle, the product, or personal injury.

- Before beginning any installation, always disconnect the negative terminal of the vehicle's battery to prevent electrical shorts and damage.
- Ensure the vehicle is parked on a level surface with the parking brake engaged.
- Wear appropriate personal protective equipment, such as safety glasses.
- Use only the recommended tools and components.
- If you are unsure about any step, consult a qualified professional.
- Keep all small parts and tools away from children.

Package Contents

Verify that all components are present before starting the installation:

- Scosche AU2392B Dash Kit (DIN w/ISO Trim)
- Mounting Brackets (if applicable)
- Instruction Sheet
- Necessary Hardware (screws, clips, etc.)



Image: The Scosche AU2392B Dash Kit, showing the main trim piece and mounting brackets.

Installation Guide

Follow these steps to install your new aftermarket stereo using the Scosche AU2392B Dash Kit.

1. Prepare the Vehicle

1. **Disconnect Battery:** Locate your vehicle's battery and disconnect the negative (-) terminal. This prevents electrical shorts during installation.
2. **Remove Factory Stereo:**
    - Carefully remove any trim panels surrounding the factory stereo using a panel removal tool to avoid scratching the dashboard.
    - Unscrew the mounting screws holding the factory stereo in place.
    - Gently pull the factory stereo out of the dash opening.
    - Unplug all electrical harnesses and antenna cables from the back of the factory stereo.

2. Prepare the Dash Kit

3. **Review Instructions:** Refer to the specific instructions included with your Scosche dash kit for any unique requirements or tab removal.
4. **Remove Unnecessary Tabs:** Break off and remove any tabs on the dash kit's mounting brackets that are not required for your specific aftermarket stereo application. This ensures a proper fit.
5. **Mount New Stereo:** Install your new aftermarket stereo into the Scosche dash kit's mounting brackets. Use the screws provided with your new stereo to secure it firmly to the brackets. Ensure the stereo is centered and flush within the dash kit opening.

3. Install New Stereo

6. **Connect Wiring Harnesses:** Connect the vehicle's wiring harness to the aftermarket stereo's wiring harness. Ensure all connections are secure and properly insulated. Connect the antenna cable.
7. **Insert Stereo Assembly:** Carefully slide the new stereo, now mounted within the Scosche dash kit, into the vehicle's dash opening. Ensure all wires are tucked away and not pinched.
8. **Secure Stereo:** Screw the new stereo assembly into the dash using the factory mounting points.
9. **Reinstall Trim Panels:** Carefully reattach any trim panels that were removed earlier, ensuring they snap securely

into place.

4. Final Steps

10. **Reconnect Battery:** Reconnect the negative (-) terminal of the vehicle's battery.
11. **Test Functionality:** Turn on the vehicle's ignition and test the new stereo to ensure all functions (power, audio, radio, auxiliary inputs, etc.) are working correctly.

Operating Instructions

The Scosche AU2392B is an installation accessory and does not have operational controls. Refer to the instruction manual provided with your aftermarket car stereo for detailed operating instructions, including how to set up radio stations, connect Bluetooth devices, and adjust audio settings.

Maintenance

The Scosche AU2392B Dash Kit requires minimal maintenance. To keep it in optimal condition:

- Clean the surface with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- Ensure all mounting screws remain tight over time to prevent vibrations or movement of the stereo.

Troubleshooting

If you encounter issues after installation, consider the following common troubleshooting steps:

Problem	Possible Cause	Solution
New stereo does not power on.	Battery not reconnected, wiring harness loose/incorrectly connected, blown fuse.	Ensure battery is reconnected. Check all wiring harness connections. Inspect vehicle's fuse box and stereo's inline fuse.
Stereo is loose in the dash.	Mounting screws not tightened, tabs not removed correctly, incorrect dash kit.	Verify all mounting screws are tight. Re-check dash kit instructions for proper tab removal. Ensure the kit is compatible with your vehicle and stereo.
Poor audio quality or no sound.	Speaker wires incorrectly connected, amplifier issues (if applicable).	Double-check all speaker wire connections. Consult your stereo's manual for audio settings.

For further assistance, please contact Scosche customer support.

Specifications

- **Model:** AU2392B
- **Compatibility:** 2006-2008 Audi A3 (DIN w/ISO Trim)
- **Material:** High quality automotive grade ABS construction
- **Color:** Black
- **Dimensions:** Approximately 1.5 x 8.5 x 16 inches (Product dimensions as per data)
- **Weight:** Approximately 1.94 ounces (Item weight as per data)
- **Features:** Precision designed for a gapless fit, color and texture matches factory dash.

Warranty and Support

The Scosche AU2392B Dash Kit is backed by Scosche's Limited Lifetime Warranty. Scosche also offers Lifetime Tech Support, meaning their knowledgeable technical team is available to answer any product questions you may have for as long as you own the product.
For warranty claims or technical assistance, please visit the official Scosche website or contact their customer service department directly.

© 2024 Scosche. All rights reserved.