

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Schonbek](#) /

› [Schonbek Signature 3771-76 Renaissance Chandelier User Manual](#)

Schonbek 3771-76

Schonbek Signature 3771-76 Renaissance Chandelier User Manual

MODEL: 3771-76 | BRAND: SCHONBEK

Introduction

Thank you for choosing a Schonbek Signature Renaissance Chandelier. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read all instructions carefully before beginning installation and retain this manual for future reference.

Schonbek has been a leader in handcrafted crystal chandeliers since 1870, known for authentic design and heirloom quality. Your Renaissance chandelier, featuring Heirloom Bronze finish and Clear Heritage Handcut Crystals, is designed to provide lasting beauty and illumination.

Important Safety Information

- **WARNING:** Risk of electric shock. Disconnect power at the main circuit breaker or fuse box before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring installations.
- This fixture is rated for indoor use only.
- Ensure the mounting surface can support the weight of the fixture.
- Do not exceed the maximum wattage specified for the bulbs.
- Always wear safety glasses during installation.
- This product is UL, cUL, and CSA rated for indoor locations.

Package Contents

Carefully unpack your chandelier and inspect all components for damage. Keep all packaging materials until you are certain all parts are accounted for and the fixture is installed correctly.

- Lighting Fixture (Chandelier Frame)
- Mounting Hardware
- Instruction Sheets
- Certificate of Authenticity
- Manufacturer Warranty Certificate
- Crystal Components (Heritage Handcut Crystals)

Note: Light bulbs are sold separately and are not included in the package.

Setup and Installation

Professional installation is recommended for this fixture. Ensure power is disconnected at the circuit breaker before proceeding.

1. **Prepare Mounting Location:** The chandelier mounts to a standard electrical box. Ensure the electrical box and its support structure are capable of safely holding the fixture's weight (approximately 40 lbs).
2. **Install Mounting Hardware:** Attach the mounting bracket to the electrical box using the provided screws.
3. **Adjust Chain Length:** The fixture is chain-suspended from a canopy. It includes 40 inches of chain in a matching finish. This chain can be shortened during installation to achieve the desired hanging height. Additional chain can be purchased separately if a longer suspension is required. The fixture includes 144 inches of total wire, allowing for a maximum suspension of up to 180.5 inches with additional chain.
4. **Wire the Fixture:** Connect the fixture's electrical wires to the house wiring according to local electrical codes. Typically, this involves connecting live to live, neutral to neutral, and ground to ground. Secure all connections with approved wire connectors.
5. **Attach Canopy:** Slide the canopy up the chain and secure it to the mounting bracket, covering the electrical box.
6. **Assemble Crystal Components:** Carefully attach the Heritage Handcut Crystals to the chandelier frame as per the detailed instructions provided in the included instruction sheets. The durable steel frame is adorned with crystal drops and rosettes, and aluminum candleslips with crystal bobeches.
7. **Install Light Bulbs:** Refer to the Operating Instructions section for bulb type and wattage requirements.

Slope Ceiling Installation: This fixture can be installed on a slope ceiling up to a 45-degree angle.



Image 1: The Schonbek Signature Renaissance Chandelier, showcasing its Heirloom Bronze finish and Clear Heritage Handcut Crystals. This image illustrates the overall design and crystal arrangement.



Image 2: A detailed view of a decorative element, possibly the canopy or a crystal bobeche, featuring the Heirloom Bronze finish and intricate design.

Operating Instructions

- **Bulb Requirements:** The chandelier requires 8 x E12 base, B10 shape 120V light bulbs (60W max each) and 1 x E12 base, T7 shape 120V light bulb (15W max). Incandescent or LED bulbs can be used. Bulbs are sold separately.
- **Power On:** Once installation is complete and all bulbs are securely in place, restore power at the main circuit breaker.
- **Control:** The chandelier can be controlled via a standard wall switch. For dimming functionality, use a compatible dimmer switch (smooth and continuous dimming is supported).

Maintenance

- **Cleaning the Fixture:** To clean the metal frame, gently wipe with a soft, dry cloth. Avoid abrasive cleaners or solvents, as these can damage the finish.
- **Cleaning Crystals:** Heritage Handcut Crystals are handcrafted and require careful handling. Use a soft, lint-free cloth, slightly dampened with distilled water or a specialized crystal cleaner, to gently wipe the crystals. Do not spray cleaner directly onto the fixture. Ensure no moisture enters electrical components.
- **Bulb Replacement:** Always disconnect power at the circuit breaker before replacing bulbs. Allow bulbs to cool completely before touching. Replace bulbs with the specified type and wattage.
- **Periodic Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

Troubleshooting

- **Light Does Not Turn On:**

- Check if the power is on at the circuit breaker.
- Ensure all bulbs are correctly installed and not burnt out.
- Verify all wire connections are secure.

- **Lights Flicker:**

- Ensure bulbs are fully tightened.
- If using a dimmer, ensure it is compatible with the installed bulbs (especially LED bulbs).
- Check for loose wire connections.

- **Fixture is Loose:**

- Disconnect power and re-tighten mounting hardware.

If issues persist after performing these checks, consult a qualified electrician or contact Schonbek customer support.

Product Specifications

Model Name	Renaissance
Model Number	3771-76
Brand	Schonbek
Dimensions (L x W x H)	26.5" x 26.5" x 32"
Item Weight	40 Pounds
Color	Heirloom Bronze
Style	Clear Heritage Handcut Crystals
Material	Alloy Steel (Frame), Crystal (Shade)
Number of Light Sources	8
Bulb Base	E12
Max Wattage (per bulb)	60W (B10 shape), 15W (T7 shape)
Voltage	120 Volts
Total Wattage	495 watts (8x60W + 1x15W)
Brightness	3360 Lumen
Finish Type	Powder Coated
Assembly Required	Yes

Certifications

UL, cUL, CSA rated



Warranty and Support

This Schonbek Signature Chandelier is covered by a **5-year manufacturer's warranty**. Please refer to the included Manufacturer Warranty Certificate for full terms and conditions.

For technical assistance, replacement parts, or warranty claims, please contact Schonbek customer support. Contact information can typically be found on the manufacturer's website or on the warranty certificate.

© 2023 Schonbek. All rights reserved.

Related Documents - 3771-76

	<u>Schonbek Chantant CH1232N- Chandelier Installation and Parts Guide</u> Comprehensive guide for installing the Schonbek Chantant CH1232N- chandelier, featuring specifications, electrical details, assembly steps, and a detailed parts list.
	<u>Schonbek BPD74232 Fixture Assembly and Installation Instructions</u> Comprehensive guide for installing the Schonbek BPD74232 lighting fixture. Includes safety warnings, step-by-step assembly, wiring instructions, and hardware details.
	<u>Schonbek Sarella RS8352N- Chandelier Installation Manual & Guide</u> Comprehensive installation guide for the Schonbek Sarella RS8352N- series chandeliers (RS8352N-H, RS8352N-R, RS8352N-S). Includes step-by-step assembly, wiring instructions, crystal placement details, and product specifications for this 11-light fixture.
	<u>Schonbek BWS71216 Beyond Magnate LED Wall Sconce Installation Guide</u> Detailed assembly and installation instructions for the Schonbek BWS71216 Beyond Magnate LED wall sconce, including safety warnings, preparation steps, mounting, wiring, and hardware details.
	<u>Schonbek Sterling 2994-S Aurelia Chandelier Installation and Specifications</u> Detailed installation guide and specifications for the Schonbek Sterling 2994-S Aurelia Chandelier, featuring 6 lights, a 21-inch diameter, and a Sterling finish. Includes safety precautions and parts list.
	<u>Schonbek Kodo S7822/S7832 Installation Guide</u> Detailed installation instructions for the Schonbek Kodo chandelier, including wiring diagrams and component lists. This guide covers the S7822 and S7832 models.

