

Givi 31335

GIVI MP60N 31335 Resin Motorcycle Baseplate User Manual

For Monolock Cases, Universal Fitment

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your GIVI MP60N 31335 Resin Motorcycle Baseplate. This baseplate is designed to securely attach GIVI Monolock cases to your motorcycle's rear carrier. Please read this manual thoroughly before installation and use to ensure proper function and safety.



Figure 1: GIVI MP60N Resin Motorcycle Baseplate. This image shows the top view of the black resin baseplate, featuring the GIVI logo and mounting points for Monolock cases.

2. SAFETY INFORMATION

- Always ensure the baseplate is securely fastened to the motorcycle's carrier before attaching a Monolock case.
- Do not exceed the maximum load capacity specified for your Monolock case or motorcycle carrier.
- Regularly inspect all mounting hardware for tightness and signs of wear or damage.
- Ensure the Monolock case is properly locked onto the baseplate before riding.
- Distribute weight evenly within the Monolock case to maintain motorcycle stability.

3. PACKAGE CONTENTS

The GIVI MP60N 31335 Resin Motorcycle Baseplate package typically includes the following components:

- GIVI MP60N Resin Baseplate

- Universal Mounting Hardware Kit (brackets, screws, washers, nuts)

モノロックケースがカンタン装着



お買い上げ前に必ずフィッティングをご確認ください。

Figure 2: GIVI MP60N Baseplate and Universal Mounting Hardware. This image displays the black resin baseplate alongside various metal brackets, screws, and washers that comprise the universal fitting kit.

4. SETUP AND INSTALLATION

Follow these steps to install the GIVI MP60N baseplate onto your motorcycle's rear carrier:

1. **Prepare the Baseplate and Hardware:** Unpack all components and ensure you have the GIVI MP60N baseplate and the complete universal mounting hardware kit.
2. **Position the Baseplate:** Place the GIVI MP60N baseplate on your motorcycle's existing rear carrier or rack. Ensure it is centered and positioned optimally for balance and access.
3. **Secure to Carrier:** Use the provided universal mounting hardware (brackets, screws, washers, nuts) to firmly attach the baseplate to the motorcycle's carrier. Depending on your carrier type, you may need to adjust the bracket positions. Tighten all fasteners securely, but do not overtighten.
4. **Verify Stability:** After installation, gently shake the baseplate to ensure it is stable and does not wobble. Re-tighten any loose fasteners if necessary.

「モノロックシリーズのケース」のみ装着可能。

モノロックケースを、純正キャリアの付いた原付スクーターや市販キャリアのあるオフ車などに、お手軽簡単取り付け。

1 汎用ベースを用意**2** 純正や市販のキャリアに固定**3** モノロックケースを装着

お買い上げ前に必ずフィッティングをご確認ください。

Figure 3: GIVI MP60N Installation Overview. This diagram illustrates the three main steps: 1) Preparing the universal base, 2) Fixing it to the motorcycle's genuine or aftermarket carrier, and 3) Attaching a Monolock case.

5. OPERATING THE MONOLOCK SYSTEM

Once the GIVI MP60N baseplate is installed, you can easily attach and detach GIVI Monolock cases.

- **Attaching a Monolock Case:** Align the Monolock case with the baseplate's locking mechanism. Press the case down firmly until you hear a click, indicating it is securely locked. Verify by gently pulling upwards on the case.
- **Detaching a Monolock Case:** Insert your key into the Monolock case's lock and turn it to the unlock position. Press the release button (usually located near the lock) and lift the case upwards to remove it from the baseplate.

モノロック汎用ベース MP6N 装着例

GIVI モノロックシリーズを装着可能



B47 / 94832



B37 / 78036



B270N / 99912 など



モノロックケース側のフィッティングをご確認ください。

Figure 4: Examples of Compatible GIVI Monolock Cases. This image displays various GIVI Monolock top cases (e.g., B47, B37, B270N) that are compatible with the MP60N baseplate.

6. MAINTENANCE

Proper maintenance ensures the longevity and reliable performance of your GIVI MP60N baseplate.

- **Cleaning:** Clean the baseplate with mild soap and water. Avoid abrasive cleaners or solvents that could damage the resin material.
- **Inspection:** Periodically inspect the baseplate and all mounting hardware for any signs of wear, cracks, corrosion, or loose fasteners. Replace any damaged components immediately.
- **Lubrication:** The locking mechanism typically does not require lubrication, but if it becomes stiff, a small amount of silicone spray can be applied to moving parts.

7. TROUBLESHOOTING

If you encounter issues with your GIVI MP60N baseplate, consider the following:

- **Baseplate is Loose:** Check all mounting bolts and nuts. Ensure they are tightened securely to the

motorcycle's carrier.

- **Monolock Case Not Attaching Securely:** Ensure the baseplate is correctly installed and not obstructed. Check the locking mechanism on both the baseplate and the Monolock case for debris or damage.
- **Difficulty Detaching Case:** Ensure the key is fully turned to the unlock position and the release button is fully depressed. Check for any obstructions.

8. SPECIFICATIONS

Feature	Detail
Brand	Givi
Model	MP60N (31335)
Material	Resin
Color	Black
Compatibility	GIVI Monolock Cases
Mounting Type	Universal (Handlebar Mount listed in product data, but for baseplate it's rear carrier mount)
Item Weight	690 g
Package Dimensions	29.4 x 25 x 6.6 cm
Country of Origin	Italy

9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your GIVI MP60N 31335 Resin Motorcycle Baseplate, please refer to the official GIVI website or contact your authorized GIVI dealer. Keep your purchase receipt as proof of purchase.