Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lamin-x CH015T

Lamin-x CH015T Headlight Film Covers Instruction Manual

Model: CH015T

1. Product Overview

The Lamin-x CH015T Headlight Film Covers are pre-cut protective films designed to safeguard your vehicle's headlights from road debris, scratches, and environmental elements. These films are engineered for a precise fit on compatible vehicle models, offering a layer of protection while maintaining optical clarity.





Image 1.1: Lamin-x CH015T pre-cut headlight film covers shown alongside a vehicle headlight, illustrating the product's form and intended application area.

IMPORTANT DISCLAIMER:
The C6 Corvette features headlight lenses that are highly sensitive and prone to cracking. General Motors (GM) advises against covering these lenses with any material due to potential cracking issues. Consequently, this specific kit is non-refundable and carries no warranty when applied to C6 Corvette models.

2. Installation Guide

2.1 Tools and Materials Required

- Spray bottle with a mild soap and water solution (approximately 5 drops of dish soap per 16 oz of water)
- Squeegee or soft plastic card
- Clean microfiber cloths
- Heat gun (optional, for complex curves or stubborn bubbles)
- Rubbing alcohol or automotive surface cleaner

2.2 Surface Preparation

1. Thoroughly clean the headlight surface using automotive surface cleaner or rubbing alcohol to remove all dirt, wax, and residues.

2. Rinse the headlight with water and dry completely with a clean microfiber cloth. Ensure no lint or dust remains.

2.3 Film Application Steps

1. **Spray Solution:** Liberally spray the soap and water solution onto the clean headlight surface. Also, spray the adhesive side of the Lamin-x film after peeling it from its backing liner. This solution allows for repositioning.
2. **Position Film:** Carefully place the film onto the wet headlight. Slide and adjust the film until it is perfectly aligned with the contours of the headlight.



Image 2.1: A hand carefully positioning the Lamin-x protective film onto a vehicle's headlight, demonstrating the initial placement stage of installation.

3. **Squeegee Out Solution:** Once positioned, begin to squeegee the solution and air bubbles out from under the film. Start from the center and work your way outwards, applying firm, even pressure. Overlap your strokes to ensure all liquid is removed.



Image 2.2: A close-up view of a hand using a squeegee tool to smooth out the Lamin-x film on a headlight, removing air and water for a flush application.

4. **Edge Sealing (Optional):** For stubborn edges or complex curves, a heat gun can be used sparingly to gently warm the film, making it more pliable. Press down firmly on the edges to ensure a secure seal.
5. **Final Wipe:** Use a clean, dry microfiber cloth to gently wipe away any excess solution from the film and surrounding areas.

3. Post-Installation Care and Maintenance

3.1 Curing Period

Allow the film to cure for at least 24-48 hours before washing the vehicle or exposing it to harsh weather conditions. During this time, the adhesive will fully bond to the headlight surface.

3.2 Cleaning and Maintenance

- Clean the film using mild automotive soap and water.
- Avoid using abrasive cleaners, brushes, or high-pressure washers directly on the film, as this can damage the surface or lift the edges.
- For stubborn dirt, use a soft cloth and gentle rubbing.



Image 3.1: A white car showcasing headlights with Lamin-x tinted film covers applied, illustrating the finished appearance after installation.

4. Troubleshooting

4.1 Common Issues and Solutions

- **Bubbles:** Small bubbles may appear immediately after installation. Most will dissipate naturally over a few days as the film cures. For larger, persistent bubbles, gently lift the nearest edge of the film, re-spray with solution, and re-squeegee.
- **Lifting Edges:** If edges begin to lift, clean the area thoroughly. Re-spray with solution, press the edge down firmly, and if available, use a heat gun on a low setting to gently warm the film and reactivate the adhesive, then press firmly.
- **Haze/Cloudiness:** A slight haze might be present immediately after installation due to residual moisture. This should clear as the film dries and cures. Ensure adequate drying time.

5. Product Specifications

- **Manufacturer:** Lamin-x
- **Brand:** Lamin-x
- **Item Model Number:** CH015T
- **Manufacturer Part Number:** CH015T
- **Item Weight:** 249 g
- **Parcel Dimensions:** 34.04 x 8.89 x 8.89 cm

- **ASIN:** B004BUMOLI
- **Date First Available:** June 25, 2015

6. Warranty and Support

As stated in the Product Overview, due to the specific sensitivities of C6 Corvette headlight lenses, this particular kit is non-refundable and holds no warranty when applied to C6 Corvette models. For all other applications, please refer to the standard Lamin-x warranty policy available on their official website.

For further assistance, technical support, or inquiries regarding your Lamin-x CH015T Headlight Film Covers, please contact Lamin-x customer service directly through their official channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004BUMOLI

More documents and user manuals: **https://manuals.plus/**