

[manuals.plus](#) /

› [Phonocar](#) /

› [Phonocar 4/361 Adhesive Smooth Carpet User Manual](#)

Phonocar 04361

Phonocar 4/361 Adhesive Smooth Carpet User Manual

Model: 04361 | Brand: Phonocar

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, usage, and maintenance of your Phonocar 4/361 Adhesive Smooth Carpet. Designed for various interior applications, this anthracite carpet offers a practical and aesthetic solution. Please read these instructions carefully before proceeding with installation to ensure optimal results and product longevity.

2. PRODUCT OVERVIEW

The Phonocar 4/361 is a smooth, adhesive carpet designed for interior lining applications, such as in vehicles. Its self-adhesive backing simplifies installation, providing a clean and finished look. The carpet is made from durable moquette material and comes in an anthracite color.

- **Dimensions:** 140 cm (Length) x 70 cm (Width)
- **Color:** Anthracite
- **Material:** Moquette (Carpet)
- **Installation Type:** Self-Adhesive
- **Pile Height:** Low pile



Figure 1: The Phonocar 4/361 adhesive smooth carpet. This image displays the texture and color of the Phonocar 4/361 adhesive smooth carpet. It features a uniform anthracite gray, low-pile surface, suitable for various interior applications.

3. SETUP AND INSTALLATION

Proper preparation and installation are crucial for the longevity and appearance of the adhesive carpet. Follow these steps carefully:

1. **Surface Preparation:** Ensure the surface where the carpet will be applied is clean, dry, and free from dust, grease, or any loose particles. A clean surface ensures optimal adhesion.
2. **Measure and Cut:** Carefully measure the area to be covered. Using a sharp utility knife or scissors, cut the carpet to the required dimensions. It is advisable to cut slightly larger and trim precisely after initial placement.
3. **Test Fit:** Before removing the adhesive backing, place the cut carpet piece on the desired surface to ensure it fits correctly and to identify any necessary adjustments.
4. **Peel and Apply:** Begin by peeling back a small portion of the protective film from the adhesive side. Align the carpet piece and carefully press it onto the surface, working from one edge to the other. Gradually peel off more of the backing while smoothing the carpet down.
5. **Smooth Out:** Use a clean, soft cloth or a roller to firmly press the carpet onto the surface, working from the center outwards to remove any air bubbles or wrinkles. Ensure all edges are securely adhered.
6. **Trimming (if necessary):** For precise edges, use a sharp utility knife to trim any excess material once the carpet is fully adhered.

For best results, perform installation in a well-ventilated area with moderate temperature.

4. OPERATING AND USAGE

Once installed, the Phonocar 4/361 Adhesive Smooth Carpet serves as a durable and protective surface. It is suitable for lining various interior components, such as car trunks, speaker boxes, or other automotive interior panels. The smooth finish provides a neat appearance and helps to dampen vibrations or sounds.

- **Protection:** Protects underlying surfaces from scratches, wear, and minor impacts.
- **Aesthetics:** Enhances the interior appearance with a uniform anthracite finish.
- **Sound Dampening:** Can contribute to minor sound absorption in enclosed spaces.

5. MAINTENANCE

To maintain the appearance and extend the life of your Phonocar 4/361 Adhesive Smooth Carpet, follow these simple maintenance guidelines:

- **Regular Cleaning:** Vacuum the carpet regularly to remove dust and loose debris.
- **Spot Cleaning:** For spills or stains, blot immediately with a clean, damp cloth. Use a mild carpet cleaner if necessary, applying it to the cloth first, not directly to the carpet. Test any cleaner on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use harsh chemicals, abrasive cleaners, or stiff brushes, as these can damage the carpet fibers or adhesive.
- **Drying:** Allow the carpet to air dry completely after cleaning. Avoid excessive moisture.

6. TROUBLESHOOTING

If you encounter issues with your adhesive carpet, consider the following:

- **Poor Adhesion:**
 - Ensure the surface was thoroughly cleaned and dry before application.
 - Verify that the surface material is compatible with pressure-sensitive adhesives.
 - Apply firm, even pressure during installation to activate the adhesive.
- **Wrinkles or Bubbles:**
 - These often occur if the carpet was not smoothed out properly during application. Try gently lifting the affected area and re-applying, smoothing carefully from the center outwards.
 - Small bubbles might be pricked with a fine needle and then pressed down.
- **Edges Lifting:**
 - Ensure edges were firmly pressed during initial installation.
 - For persistent lifting, a compatible spray adhesive designed for carpets might be used sparingly on the underside of the lifting edge, then pressed firmly.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	Phonocar
Model Number	04361
Color	Anthracite
Material	Moquette (Carpet)
Product Dimensions	140 cm (Length) x 70 cm (Width)
Installation Type	Adhesive
Pile Height	Low Pile
International Article Code	08020065043615

8. WARRANTY AND SUPPORT

Information regarding specific warranty terms for the Phonocar 4/361 Adhesive Smooth Carpet is not available in the provided product details. For any support inquiries or further assistance, please refer to the official Phonocar website or contact your retailer.