



[Manuals.plus](#) /

› [Bushwacker](#) /

› Bushwacker OE Style Fender Flares Installation and Care Manual for Toyota Rav4 (2009-2011)

Bushwacker 31926-02

Bushwacker OE Style Fender Flares Installation and Care Manual

Model: 31926-02

For 2009-2011 Toyota Rav4 (Base Model Only)

INTRODUCTION

These Bushwacker OE Style Fender Flares are designed to provide enhanced tire coverage and body protection for your 2009-2011 Toyota Rav4. Crafted from durable Dura-Flex 2000 TPO material, these flares offer a smooth, matte black finish that can be painted to match your vehicle's color. This manual outlines the installation process, maintenance guidelines, and product specifications to ensure optimal performance and longevity.

WHAT'S IN THE BOX

Verify that all components are present before beginning installation:

- Fender Flares (4 pieces)
- Installation Hardware
- Instruction Manual (this document)

INSTALLATION INSTRUCTIONS

Installation of Bushwacker OE Style Fender Flares requires minor drilling and precision fitment. Please read all instructions thoroughly before beginning.

Preparation

1. Clean the vehicle's fender areas where the flares will be installed. Ensure surfaces are free of dirt, debris, and wax.
2. Gather all necessary tools. Refer to the included hardware kit for specific tool requirements.
3. Perform a test fit of each fender flare to its corresponding wheel well to familiarize yourself with the fitment and attachment points.

BUSHWACKER®



OE STYLE™ FLARES



Image: Bushwacker OE Style Fender Flares providing tire coverage on a vehicle.

Mounting the Flares

1. Carefully align the fender flare with the wheel well. The flares are precision-engineered using CAD data for a specific vehicle fit.
2. Mark the drilling locations as indicated in the detailed instructions provided with the hardware kit. Minor drilling into the vehicle's fender lip may be required.
3. Drill pilot holes at the marked locations. Ensure proper drill bit size is used to avoid damage.
4. Attach the fender flares using the provided hardware. Ensure all fasteners are securely tightened, but do not overtighten.
5. Repeat the process for all four fender flares.

BUSHWACKER®

OE STYLE™ FLARES



Premium Tire Coverage for Body Protection



Unique and Understated



Made from Dura-Flex 2000 ABS Material



100% UV Protected Matte Black Smooth Finish



Image: Features of Bushwacker OE Style Fender Flares, including Dura-Flex 2000 TPO material and 100% UV protection.

Final Checks

- Verify that all flares are securely attached and properly aligned.
- Ensure there are no gaps or loose areas that could allow debris or water to accumulate.
- Clean any residue from the installation process.

Installation Video Resources

For a visual guide on installing Bushwacker OE Style Fender Flares, please refer to the official video below:

Your browser does not support the video tag.

Video: Official Bushwacker guide for installing OE Style Fender Flares. This video demonstrates the general installation process and highlights key features.

Another helpful video demonstrating Bushwacker Fender Flares:

Your browser does not support the video tag.

Video: General overview of Bushwacker Fender Flares, showcasing their design and benefits.

OPERATING AND MAINTENANCE

Once installed, your Bushwacker OE Style Fender Flares require minimal operational considerations and simple maintenance to retain their appearance and protective qualities.

General Care

- Regularly clean the fender flares with mild soap and water. Avoid abrasive cleaners or harsh chemicals that could damage the finish or UV protection.
- Periodically inspect the flares and all mounting hardware for tightness. Re-tighten any loose fasteners to ensure secure attachment.
- The Dura-Flex 2000 TPO material is 100% UV-protected to prevent chalking. However, prolonged exposure to extreme sunlight without regular cleaning can still affect appearance over time.



Image: Illustration detailing the tire coverage provided by the front and rear fender flares.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Loose Fitment	Fasteners not tightened sufficiently or improper installation.	Re-check all mounting points and tighten fasteners. Ensure flares are correctly seated against the vehicle body.
Discoloration/Chalking	Extreme prolonged UV exposure or use of harsh cleaning agents.	Clean with mild soap and water. While UV protected, extreme conditions can still cause wear. Consider using a UV protectant spray designed for automotive plastics.
Gaps between Flare and Body	Incorrect alignment during installation.	Remove and re-install the flare, ensuring precise alignment before tightening fasteners.

SPECIFICATIONS

Attribute	Detail
Brand	Bushwacker
Model Number	31926-02
Compatible Vehicle	2009-2011 Toyota Rav4 (Base Model Only)
Material	Dura-Flex 2000 TPO
Finish	Smooth Matte Black (Paintable)
UV Protection	100% UV-protected
Auto Part Position	Front, Rear
Item Weight	14 Pounds
Item Dimensions (L x W x H)	46 x 9 x 29 inches

WARRANTY AND SUPPORT

Bushwacker OE Style Fender Flares are backed by an industry-leading **Limited Lifetime Warranty**. This warranty covers defects in material and workmanship under normal use and service.

For warranty claims, technical assistance, or any questions regarding your product, please contact Bushwacker customer support directly. Refer to the official Bushwacker website for the most current contact information.

You can visit the official Bushwacker store for more information: [Bushwacker Store](#)