

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [PHONOCAR](#) /

› [PHONOCAR 03333 Car Radio Fascia for BMW X3 \(Pre-2011\) - Instruction Manual](#)

PHONOCAR 3/333

PHONOCAR 03333 Car Radio Fascia for BMW X3 (Pre-2011)

Model: 3/333 | Brand: PHONOCAR

[Introduction](#)

[Setup & Installation](#)

[Usage](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

The PHONOCAR 03333 Car Radio Fascia is designed to allow the installation of a standard ISO car radio into a BMW X3 model manufactured before 2011. This fascia provides a seamless and integrated look for your new car audio unit, ensuring proper fitment and aesthetic continuity with your vehicle's dashboard.



Image 1.1: The PHONOCAR 03333 Car Radio Fascia. This image displays the black ISO frame designed for car radio installation in compatible BMW X3 models.

2. SETUP & INSTALLATION

This section provides general guidelines for installing the PHONOCAR 03333 car radio fascia. Professional installation is recommended for optimal results and to avoid damage to your vehicle or the product.

2.1. Compatibility Check

- Ensure your vehicle is a BMW X3 model manufactured **before 2011**. This fascia is specifically designed for these models.
- Verify that your new car radio is a standard ISO size to fit the fascia's opening.

2.2. Required Tools (Not Included)

- Dashboard trim removal tools
- Screwdrivers (Phillips and flathead)
- Wire cutters/strippers (if wiring harness modification is needed)

- Electrical tape or heat shrink tubing

2.3. Installation Steps

1. **Disconnect Battery:** Before starting any electrical work, disconnect the negative terminal of your vehicle's battery to prevent electrical shorts.
2. **Remove Existing Radio/Fascia:** Carefully use trim removal tools to pry off the existing dashboard trim and remove the factory radio. Refer to your vehicle's service manual for specific instructions on removing dashboard components.
3. **Prepare Wiring:** Connect the wiring harness for your new car radio to the vehicle's wiring. Ensure all connections are secure and properly insulated.
4. **Attach Fascia to New Radio:** Slide your new ISO-sized car radio into the PHONOCAR 03333 fascia. The fascia should snap or screw into place around the radio, creating a single unit.
5. **Install Radio and Fascia Assembly:** Carefully slide the combined radio and fascia assembly into the dashboard opening. Ensure all clips and mounting points align.
6. **Secure Assembly:** Secure the radio and fascia assembly using the appropriate screws or clips.
7. **Reinstall Trim:** Reattach any removed dashboard trim pieces, ensuring they snap back into place securely.
8. **Reconnect Battery:** Reconnect the negative terminal of your vehicle's battery.
9. **Test Functionality:** Turn on your vehicle and test the new car radio to ensure it functions correctly.

Note: Always consult your vehicle's specific service manual for detailed instructions on removing and installing dashboard components. Improper installation can lead to damage.

3. USAGE

The PHONOCAR 03333 fascia serves as a cosmetic and functional adapter for your car radio. Once installed, it provides a secure and aesthetically pleasing frame for your aftermarket ISO-sized head unit. Its primary function is to bridge the size and shape difference between the vehicle's original radio opening and the new radio, ensuring a factory-like finish.

4. MAINTENANCE

The car radio fascia requires minimal maintenance to retain its appearance.

- **Cleaning:** Use a soft, damp cloth to wipe the surface of the fascia. Avoid abrasive cleaners or solvents, as these can damage the finish.
- **Inspection:** Periodically check the fascia for any signs of loosening or damage. Ensure it remains securely fitted around your car radio.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fascia does not fit the dashboard opening.	Incorrect vehicle model or year.	Verify that your vehicle is a BMW X3 manufactured before 2011. This fascia is not compatible with other models or newer X3 versions.
New radio does not fit into the fascia.	Non-standard ISO radio size.	Ensure your aftermarket car radio conforms to the standard ISO single-DIN size.
Fascia appears loose after installation.	Improper securing during installation.	Re-check all mounting clips and screws. Ensure the fascia is fully seated and secured according to installation steps.

6. SPECIFICATIONS

Feature	Detail
Model Number	3/333
Product Code	03333
Brand	PHONOCAR
Compatibility	BMW X3 models manufactured before 2011
Radio Standard	ISO (Single-DIN)
Color	Black
Dimensions (Packaging)	35.6 x 16 x 2.6 cm
Weight (Packaging)	120 grams

7. WARRANTY & SUPPORT

7.1. Warranty Information

Specific warranty details for the PHONOCAR 03333 fascia are typically provided at the point of purchase or within the product packaging. Please retain your proof of purchase for any warranty claims. General consumer rights and guarantees apply as per local regulations.

7.2. Customer Support

For further assistance, technical support, or inquiries regarding the PHONOCAR 03333 car radio fascia, please contact PHONOCAR customer service or visit their official website. You can find more information about PHONOCAR products and support on their [official store page](#).

