

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Acme](#) /

› [Acme Sunburst Queen Canopy Bed Headboard and Footboard Assembly Manual](#)

Acme AC-02084Q

Acme Sunburst Queen Canopy Bed Headboard and Footboard Instruction Manual

Model: AC-02084Q

1. PRODUCT OVERVIEW

The Acme Sunburst Queen Canopy Bed Headboard and Footboard is a decorative metal component designed to attach to a standard queen-size bed frame. This product includes the headboard, footboard, and canopy posts with a sandy black finish and a distinctive sunburst design. Please note that this product consists only of the headboard, footboard, and canopy posts; a separate queen-size bed frame with side rails, mattress, and related accessories are required and sold separately.



Image 1: The Acme Sunburst Queen Canopy Bed Headboard and Footboard, shown assembled with a mattress and bedding (not included). This image illustrates the complete aesthetic when combined with a compatible bed frame.

2. SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Keep all small parts and packaging materials away from children.
- Assemble the product on a soft, clean surface to prevent scratches.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the bed frame or canopy structure.
- This product is designed for indoor use only.
- Two adults are recommended for assembly to ensure safety and ease of installation.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact Acme customer support.

- Headboard (1)
- Footboard (1)
- Canopy Posts (4)
- Canopy Rails (4)
- Connecting Hardware (bolts, washers, nuts, clips for attaching to a standard bed frame)

Note: A queen-size bed frame with side rails, mattress, and bedding are NOT included with this product and must be purchased separately.

4. ASSEMBLY INSTRUCTIONS

Assembly requires two people. Please follow these steps carefully.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface. Refer to the parts list to identify each piece.
2. **Attach Headboard and Footboard to Existing Bed Frame:** Position your existing queen-size bed frame. Align the headboard with the designated attachment points on your bed frame's head end. Use the provided bolts, washers, and nuts to securely fasten the headboard to the bed frame. Repeat this process for the footboard at the foot end of your bed frame. Ensure all connections are tight.
3. **Assemble Canopy Posts:** Insert the bottom sections of the four canopy posts into the designated receivers on the headboard and footboard. Ensure they are firmly seated.
4. **Install Canopy Rails:** Connect the four canopy rails to the top sections of the canopy posts. Secure them using the provided hardware. Ensure all connections are stable and level.
5. **Final Check:** Once all components are assembled, gently shake the entire structure to ensure stability. Retighten any loose connections.



Image 2: A detailed view of the sunburst design on the headboard and footboard, highlighting the sandy black finish and decorative elements.

5. CARE AND MAINTENANCE

- **Cleaning:** Wipe the metal surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or polishes that may damage the finish.
- **Dusting:** Regularly dust the frame with a dry, soft cloth to prevent buildup.
- **Hardware Check:** Periodically inspect all bolts and connections to ensure they remain tight. Re-tighten as needed to maintain structural integrity.
- **Avoid Moisture:** Keep the bed frame away from excessive moisture or humidity to prevent rust or damage to the finish.

6. TROUBLESHOOTING

- **Instability/Wobbling:** Ensure all bolts and connections are fully tightened. Verify that the headboard and footboard are properly attached to a stable queen-size bed frame. Uneven flooring can also contribute to instability; consider using furniture pads or shims.
- **Missing Parts:** If any parts are missing upon unpacking, do not proceed with assembly. Contact Acme customer support immediately for assistance.
- **Difficulty Assembling:** Review the assembly instructions carefully. Ensure you are using the correct hardware for each step. Sometimes, parts may appear similar but have subtle differences. If instructions are unclear, refer to diagrams or contact support.

7. SPECIFICATIONS

Model Number	AC-02084Q
Product Dimensions	85"L x 60"W x 80"H (Assembled with standard queen frame)
Material	Metal
Finish Type	Painted, Sandy Black
Assembly Required	Yes
Item Weight	39 pounds (Headboard/Footboard/Canopy components only)

8. WARRANTY AND SUPPORT

For warranty information, missing parts, or technical support, please contact Acme Furniture directly. Refer to your purchase documentation for specific warranty terms and contact details. Keep your proof of purchase for any warranty claims.