

Rockwood 471.26D

Rockwood 471.26D Brass Wall Mount Door Stop Instruction Manual

Model: 471.26D

1. INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of your Rockwood 471.26D Brass Wall Mount Door Stop. Please read these instructions carefully before installation and retain them for future reference.

The Rockwood 471.26D is a durable wall-mounted door stop designed to prevent door handles or knobs from damaging walls. It features a concealed mounting system and a convex DuraFlex bumper for effective impact absorption.

2. SAFETY INFORMATION

Observe the following safety precautions during installation and use:

- Always wear appropriate personal protective equipment, such as safety glasses, when drilling or using tools.
- Ensure the mounting surface is structurally sound and free from electrical wires or plumbing before drilling.
- Keep small parts and fasteners out of reach of children to prevent choking hazards.
- Do not overtighten fasteners, as this may damage the door stop or the mounting surface.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x Rockwood 471.26D Brass Wall Mount Door Stop (Satin Chrome Plated)
- 1 x #8 x 3/4" OH SMS Fastener
- 1 x Plastic Anchor



An image showing the Rockwood 471.26D Brass Wall Mount Door Stop with a satin chrome plated finish. The door stop features a cylindrical base and a convex DuraFlex bumper.

4. SETUP AND INSTALLATION

Tools required for installation (not included):

- Pencil
- Drill

- Drill bit appropriate for plastic anchor (typically 3/16" or 1/4", refer to anchor packaging)
- Phillips head screwdriver

Installation Steps:

1. **Determine Mounting Location:** Open the door to its maximum desired swing or until the door handle/knob makes contact with the wall. Mark the center point of the door handle/knob on the wall with a pencil. This is where the center of the door stop should be placed.
2. **Prepare Mounting Surface:** Hold the door stop base against the marked location on the wall. Use a pencil to mark the center of the mounting hole on the wall.
3. **Drill Pilot Hole:** Using the appropriate drill bit, drill a pilot hole at the marked location. The depth should be sufficient to fully insert the plastic anchor.
4. **Insert Plastic Anchor:** Gently tap the plastic anchor into the drilled hole until it is flush with the wall surface.
5. **Mount Door Stop:** Align the door stop's mounting hole with the plastic anchor. Insert the #8 x 3/4" OH SMS fastener through the door stop and into the plastic anchor.
6. **Secure Door Stop:** Use a Phillips head screwdriver to tighten the fastener until the door stop is firmly secured to the wall. Do not overtighten. The back plate of the door stop is designed to prevent damage to the wall.

5. OPERATING INSTRUCTIONS

The Rockwood 471.26D Door Stop operates passively. Once installed, it functions by providing a physical barrier to prevent the door from opening beyond a certain point, protecting the wall from impact damage caused by the door handle or knob. The convex DuraFlex bumper absorbs the impact, minimizing noise and wear.

6. MAINTENANCE

The Rockwood 471.26D Door Stop requires minimal maintenance:

- **Cleaning:** Wipe the door stop periodically with a soft, damp cloth to remove dust and dirt. Avoid abrasive cleaners or harsh chemicals, as these may damage the satin chrome plated finish.
- **Inspection:** Periodically check the door stop for any signs of loosening. If the door stop feels loose, gently tighten the mounting screw with a Phillips head screwdriver.
- **Bumper Condition:** Inspect the DuraFlex bumper for any signs of wear or damage. While designed for durability, extreme impact or prolonged use may cause wear. Replacement bumpers may be available from the manufacturer.

7. TROUBLESHOOTING

If you encounter issues with your door stop, consider the following:

- **Door Stop is Loose:** If the door stop becomes loose, gently tighten the mounting screw. If it continues to loosen, the plastic anchor may be stripped or the wall material may be compromised. Consider relocating the door stop slightly or using a larger anchor if appropriate for the wall material.
- **Door Still Hits Wall:** Ensure the door stop is installed at the correct height and distance to intercept the door handle or knob effectively. Re-evaluate the mounting location if necessary.
- **Bumper Damaged:** If the DuraFlex bumper is damaged, contact Rockwood customer support for

information on replacement parts.

8. SPECIFICATIONS

Model Number	471.26D
Brand	Rockwood
Material	Brass
Finish Type	Satin Chrome Plated
Mounting Type	Wall Mount
Base Diameter	2-1/2 inches
Height	3 inches
Fastener	#8 x 3/4" OH SMS Fastener with Plastic Anchor
Features	Back plate prevents damage to wall, convex DuraFlex Bumper
Product Dimensions	4.3 x 2.8 x 2.5 inches (overall package)
Item Weight	10.4 ounces

9. WARRANTY AND SUPPORT

Rockwood products are manufactured to high standards and are typically covered by a manufacturer's warranty against defects in materials and workmanship. For specific warranty details, duration, and terms, please refer to the warranty information provided with your purchase or visit the official Rockwood Manufacturing Company website.

For technical support, replacement parts, or further assistance, please contact Rockwood Manufacturing Company directly through their official channels.