Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Jones Stephens /
- > Jones Stephens B07113 Chrome Plated Two-Hole Touch Bath Waste, Standard Half STD ABS W&O 1/2 KIT W/CP TOE POP

Jones Stephens B07113

Jones Stephens B07113 Bath Waste Kit Instruction Manual

Model: B07113

PRODUCT OVERVIEW

The Jones Stephens B07113 Chrome Plated Two-Hole Touch Bath Waste Kit is designed for easy replacement and installation in standard bathtubs. This kit features a durable chrome-plated finish and a convenient toe-touch stopper for effortless operation. It includes essential components for a hassle-free setup, manufactured from corrosion-resistant materials to ensure long-lasting reliability.



Figure 1: Components of the Jones Stephens B07113 Bath Waste Kit. This image displays the chrome-plated two-hole overflow faceplate with two screws, and the lower drain assembly with a chrome toe-touch stopper and black ABS piping.

SETUP AND INSTALLATION

This kit is designed for straightforward installation. No special tools are required for the replacement process. Ensure all necessary components are present before beginning installation.

Components Included:

- · Chrome-plated two-hole faceplate
- · Faceplate screws
- · Drain assembly with toe-touch stopper

- Bushing
- Pipe and elbow (as part of the drain assembly)

Note: This is a standard half kit; it does not include the main overflow pipe or tee connection to the main drain line. The bolt holes on the top elbow are pre-threaded for convenience. The 3/8" thread size is for testing purposes.

Installation Steps:

- 1. **Preparation:** Ensure the existing bath waste assembly is completely removed and the tub drain and overflow openings are clean and free of debris.
- Install Overflow Faceplate: Position the two-hole faceplate over the overflow opening. Align the screw holes and secure it with the provided screws. Ensure a watertight seal, using plumber's putty or silicone sealant as recommended by local plumbing codes.
- 3. Assemble Drain: Connect the drain assembly, including the bushing, pipe, and elbow, to the tub drain opening.
- 4. Secure Drain: Tighten the drain assembly securely to create a watertight seal. Do not overtighten.
- 5. **Test for Leaks:** Fill the bathtub with water and check for any leaks around the overflow faceplate and the drain assembly. Address any leaks before proceeding.

OPERATING INSTRUCTIONS

The Jones Stephens B07113 features a toe-touch stopper for easy operation of the tub drain.

- To Close the Drain: Gently press down on the top of the chrome stopper with your foot or hand until it clicks into the closed position. This will seal the drain, allowing the tub to fill with water.
- **To Open the Drain:** Gently press down on the top of the chrome stopper again until it clicks into the open position. This will release the seal, allowing water to drain from the tub.

The toe-touch mechanism is designed for smooth and reliable operation without the need for bending or reaching into the tub.

MAINTENANCE

Regular maintenance will ensure the longevity and proper function of your bath waste kit.

- **Cleaning:** Clean the chrome-plated surfaces regularly with a soft cloth and a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive scrubbers, as these can damage the finish.
- **Stopper Inspection:** Periodically check the toe-touch stopper for any debris or hair accumulation that might impede its sealing function. The stopper can typically be unscrewed for cleaning if necessary.
- Seal Integrity: Inspect the seals around the overflow faceplate and drain assembly annually for any signs of wear or degradation. Replace seals if necessary to prevent leaks.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Water Leaks Around Drain or Overflow	Improperly sealed connections; loose fittings; damaged gasket/seal.	Ensure all connections are tight. Apply plumber's putty or silicone sealant as needed. Inspect and replace any damaged gaskets or seals.

Problem	Possible Cause	Solution
Drain Stopper Not Sealing Properly	Debris under stopper; stopper mechanism malfunction; worn seal on stopper.	Remove stopper and clean any debris. Check if the stopper mechanism is operating freely. Replace the stopper if the seal is worn or the mechanism is faulty.
Slow Draining	Hair or debris accumulation in the drain pipe.	Remove the stopper and clear any obstructions from the drain opening. Use a drain snake if the blockage is further down the pipe.

SPECIFICATIONS

Model Number: B07113

Finish: Chrome Plated

Faceplate Type: Two-Hole

Stopper Type: Toe Touch

Material: ABS (Acrylonitrile Butadiene Styrene)

Item Weight: 1.3 pounds (approx.)

Product Dimensions: 3.71 x 3.37 x 3.24 inches (approx.)

Manufacturer: Jones Stephens

WARRANTY INFORMATION

Jones Stephens products are manufactured to high-quality standards. For specific warranty details regarding the B07113 Bath Waste Kit, please refer to the official Jones Stephens warranty policy available on their website or contact their customer support directly. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For technical assistance, replacement parts, or any questions regarding your Jones Stephens B07113 Bath Waste Kit, please contact Jones Stephens customer support.

Website: www.jonesstephens.com

Phone: Refer to the Jones Stephens website for current contact numbers.

© 2024 Jones Stephens. All rights reserved.

Related Documents - B07113



Jones Stephens Tub Drain Conversion Trim Kit Installation Instructions

Comprehensive installation guide for Jones Stephens tub drain conversion trim kits. This document provides step-by-step instructions in English and Spanish for replacing old overflow plates and installing new drain assemblies, ensuring a proper seal. Compatible with various models including B51038 and B51031.



Schedule 40 Flexible Bath Waste Kit with Quick Test Installation Guide

Step-by-step instructions for installing a Schedule 40 Flexible Bath Waste Kit with Quick Test, including parts list and assembly guidance.



Jones Stephens Snap-On Bathtub Faceplate with Conversion Bar Installation Instructions

Step-by-step installation guide for the Jones Stephens Snap-On Bathtub Faceplate with Conversion Bar, detailing how to replace existing faceplates for 1-hole and 2-hole configurations.



PlumBite® Push-On Repair Coupling Installation Instructions

Detailed installation guide for PlumBite Push-On Repair Coupling by Jones Stephens, covering pipe preparation, fitting installation, and removal procedures. Includes specifications and warnings.



Jones Stephens Universal Toilet Flapper Installation Guide for TOTO®

Comprehensive instructions for installing the Jones Stephens Universal Flapper, designed to fit TOTO® toilets. Includes preparation, installation, and adjustment steps.



Jones Stephens Ice Maker Box Installation Instructions

Step-by-step guide for installing a Jones Stephens ice maker supply box. Includes tools needed, cautions, and details on connecting supply lines.